

Service Manual

Inverter Pair Wall Mounted Type E-Series





[Applied Models]
●Inverter Pair : Heat Pump

Inverter Pair E-Series

●Heat Pump

Indoor Units

FTXR28EV1B FTXR42EV1B FTXR50EV1B

Outdoor Units

RXR28EV1B RXR42EV1B RXR50EV1B

Table of Contents i

	1.	Introduction	
Part 1	List of	Functions	1
	1.	Functions	2
Part 2	Specifi	cations	3
	1.	Specifications	4
Part 3	Printed	Circuit Board Connector Wiring Diagram	7
	1.	Printed Circuit Board Connector Wiring Diagram	8
Part 4	Functio	on and Control	13
	1.	Description of Operation	15
	2.	Main Functions 2.1 "URURU" Humidifying / Humid Heating Operation 2.2 "SARARA" Drying Operation 2.3 Comfort Sleep Operation 2.4 MOISTURIZING Operation 2.5 Automatic Operation 2.6 Comfort Airflow Mode 2.7 Cooling Breeze Operation	17 26 30 31 32
		2.8 Power-airflow Dual Flaps	36 37 38
		2.14 Monitor Brightness Setting 2.15 Information Display 2.16 MOLD PROOF Operation 2.17 Mold Proof Stick 2.18 MOLD SHOCK Operation	40 41 43
		2.19 HOME LEAVE Ventilation 2.20 FLASH STREAMER AIR PURIFYING Operation 2.21 Fresh Air Supply Ventilation 2.22 Wipe-clean Flat Panel 2.23 Filter Cleaning Indicator (Remote Controller)	48 51 53
		2.24 TIMER Operation	54 55 56
		2.29 Draft Prevention (HOT Start)	61

	3.	Cont	rol Specification	62
		3.1	Frequency Control	62
		3.2	Preheating Operation (Quick Warming Function)	63
		3.3	Four-way Valve Operation	64
		3.4	Compressor Start up Protection	65
		3.5	Fan Speed Control for Outdoor Unit	66
		3.6	Fin Thermistor Control	66
		3.7	Input Current Control	67
		3.8	Peak-cut Control	68
		3.9	Indoor Coil Freeze-up Protection	69
		3.10	Dew Prevention	70
		3.11	Liquid Compression Protection 2	71
		3.12	Discharge Pipe Temperature Control	72
		3.13	Automatic Defrosting	73
		3.14	Electronic Expansion Valve Control	75
Part 5	Svstem	Co	nfiguration	81
	_		ıllation Manual	
		1.1	Indoor Units	
		1.2	Outdoor Units	
	2		em Configuration	
		-	_	
	3.		uction	
		3.1	Safety Precautions	
		3.2	Names and Functions of Parts	
		3.3	Preparation before Operation	
		3.4	Cooling · "SARARA" DRYING Operation	
		3.5	Heating · "URURU" HUMIDIFYING Operation	
		3.6	AUTO / MOISTURIZING Operation	
		3.7	Adjusting Airflow Direction · Comfort Airflow Mode · Cooling Breeze Airflow Rate	
		3.8	FLASH STREAMER AIR PURIFYING · FRESH AIR SUPPLY	1 10
		0.0	VENTILATION Operation / HOME LEAVE VENTILATION	116
		3.9	TIMER Operation	
			COMFORT SLEEP / POWERFUL Operation	
			SET UP	
			MOLD PROOF Operation	
			MOLD SHOCK Operation / INFORMATION DISPLAY	
			Care and Cleaning	
			Troubleshooting	
- 10	•			
Part 6			ignosis	
			venient Service Check Function	
	2.		bleshooting	
		2.1	Error Code Indication by Remote Controller	
		2.2	Air conditioner does not run.	
		2.3	Air conditioner runs but does not get cooling (heating)	
		2.4	When operation starts, safety breaker works	
		2.5	Air conditioner makes big noise and vibration	
		2.6	Air does not humidified enough	
		2.7	Indoor Unit PCB Fault	
		28	Peak-cut Control or Freeze-up Protection	151

Table of Contents iii

~ ~	F 11 . 0 (DO11 :) = ::	
	Fan Motor System (DC Motor) Fault	
	Streamer Unit Fault	
	Thermistor System Fault	
	Front Panel Open / Close Fault	
	Humidity Sensor Fault	
	Signal Transmission Error (Indoor Unit - Outdoor Unit)	
	Incompatible Power Supply between Indoor Unit and Outdoor Unit	
	Incomplete Setting for Hose Length	
	Outdoor Unit PCB Fault	
	OL Activation (Compressor Overload)	
	Compressor Lock	
	DC Fan Lock	
	Input Over Current Detection	
	Four Way Valve Fault	
	Discharge Pipe Temperature Control	
	High Pressure Control in Cooling	
	Compressor Sensor System Fault	
	Damper Fault	
	Position Sensor Fault	
	DC Voltage / DC Current Sensor Fault	
	Thermistor System Fault	
	Abnormal Temperature in Electrical Box	
	Temperature Rise in Radiation Fin	
	Output Overcurrent	
	Insufficient Gas	
	Over Voltage Protection / Low Voltage Protection	
	Outdoor Unit PCB Fault or Communication Circuit Fault	
	Signal Transmission Error on Outdoor Unit PCB	
	Fan Motor System Fault / Fan Lock	
	Heater Wire Fault	197
2.39	Humidification Fan Outlet Thermistor Fault /	
	Abnormal Heater Temperature	
2.40	Lights-out of Microcomputer Status Lamp	201
Chec	ck	
3.1	Thermistor Resistance Check	202
3.2	Installation Condition Check	
3.3	Outdoor Fan System Check (DC Motor)	203
3.4	Power Supply Waveform Check	204
3.5	Capacitor Voltage Check	204
3.6	Main Circuit Electrolytic Capacitor Check	205
3.7	Refrigerant System Check	
3.8	"Inverter Checker" Check	206
3.9	Power Transistor Check	207
3.10	Discharge Pressure Check	208
	Electronic Expansion Valve Check	
	Indoor Unit PCB Output Check	
	Rotating Pulse Input on Outdoor Unit PCB Check	
	Humidity Sensor Check	
3.15	Main Circuit Short Check	212
3.16	Four-way Valve Performance Check	213
	Solenoid Valve for Dehumidification Check	

iv Table of Contents

3.

Part 7	Remov	al Procedure	215
	1.	Indoor Unit	216
		1.1 Removal of the Air Filters / Front panel	216
		1.2 Removal of the Upper Panel	
		1.3 Removal of the Front Grille	
		1.4 Removal of the Assembly of the Open/Close Mechanism	
		1.5 Removal of the Assembly of the Reduction Motor	
		1.6 Removal of the Electrical Box	
		1.7 Removal of the PCB	
		1.8 Removal of the Dehumidifying Solenoid Valve Coil	
		1.9 Removal of the Connecting Duct	
		1.10 Removal of the Drain Hose	
		1.11 Removal of the Swing Motor	
		1.13 Removal of the Propeller Fan / Fan Motor	
		1.14 Removal of Horizontal Blades / Vertical Blades	
		1.15 Removal of the Streamer Unit	
	2	Outdoor Unit	
	۷.	2.1 Removal of the Humidify Unit	
		2.2 Removal of the Heater Assembly / Humidifying Rotor	200
		(Moisture Absorption Element) / Humidifying Rotor Motor	266
		2.3 Removal of the Humidifying Assembly	
		2.4 Removal of the Moisture Absorption Fan Motor	
		2.5 Removal of the Propeller Fan / Fan Motor	
		2.6 Removal of the Duct in Humidifier	
		2.7 Removal of the Electrical Box	280
		2.8 Removal of the PCB	284
		2.9 Removal of the Sound Blanket	287
		2.10 Remove the Thermistor Assembly	289
		2.11 Removal of the Reactor / Partition Plate	
		2.12 Removal of the Four Way Valve	
		2.13 Removal of the Expansion Valve	
		2.14 Removal of the Compressor	295
Part 8	Others		297
	1.	Others	298
		1.1 Test Run from the Remote Controller	298
		1.2 Field Setting	299
Part 9	Append	lix	301
	1.	Piping Diagrams	302
	••	1.1 Indoor Units	
		1.2 Outdoor Units	
	2	Wiring Diagrams	
	<u>-</u> .	2.1 Indoor Units	
		2.2 Outdoor Units	

Table of Contents v

Index		 	i
Drawin	gs & Flow Charts	 	iii

vi Table of Contents

SiBE04-624 Introduction

1. Introduction

1.1 Safety Cautions

Cautions and Warnings

- Be sure to read the following safety cautions before conducting repair work.
- The caution items are classified into "♠ Warning" and "♠ Caution". The "♠ Warning" items are especially important since they can lead to death or serious injury if they are not followed closely. The "♠ Caution" items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.
- About the pictograms
- \triangle This symbol indicates an item for which caution must be exercised.
 - The pictogram shows the item to which attention must be paid.
- This symbol indicates a prohibited action.
 - The prohibited item or action is shown inside or near the symbol.
- This symbol indicates an action that must be taken, or an instruction. The instruction is shown inside or near the symbol.
- After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer.

1.1.1 Caution in Repair

Warning	
Be sure to disconnect the power cable plug from the plug socket before disassembling the equipment for a repair. Working on the equipment that is connected to a power supply can cause an electrical shook. If it is necessary to supply power to the equipment to conduct the repair or inspecting the circuits, do not touch any electrically charged sections of the equipment.	B -Ç
If the refrigerant gas discharges during the repair work, do not touch the discharging refrigerant gas. The refrigerant gas can cause frostbite.	
When disconnecting the suction or discharge pipe of the compressor at the welded section, release the refrigerant gas completely at a well-ventilated place first. If there is a gas remaining inside the compressor, the refrigerant gas or refrigerating machine oil discharges when the pipe is disconnected, and it can cause injury.	
If the refrigerant gas leaks during the repair work, ventilate the area. The refrigerant gas can generate toxic gases when it contacts flames.	0
The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit. Be sure to discharge the capacitor completely before conducting repair work. A charged capacitor can cause an electrical shock.	A
Do not start or stop the air conditioner operation by plugging or unplugging the power cable plug. Plugging or unplugging the power cable plug to operate the equipment can cause an electrical shock or fire.	

Introduction SiBE04-624

L Caution	
Do not repair the electrical components with wet hands. Working on the equipment with wet hands can cause an electrical shock.	\bigcirc
Do not clean the air conditioner by splashing water. Washing the unit with water can cause an electrical shock.	\bigcirc
Be sure to provide the grounding when repairing the equipment in a humid or wet place, to avoid electrical shocks.	•
Be sure to turn off the power switch and unplug the power cable when cleaning the equipment. The internal fan rotates at a high speed, and cause injury.	8.5
Do not tilt the unit when removing it. The water inside the unit can spill and wet the furniture and floor.	\bigcirc
Be sure to check that the refrigerating cycle section has cooled down sufficiently before conducting repair work. Working on the unit when the refrigerating cycle section is hot can cause burns.	
Use the welder in a well-ventilated place. Using the welder in an enclosed room can cause oxygen deficiency.	0

1.1.2 Cautions Regarding Products after Repair

N Warning	
Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to conduct repair work. Never attempt to modify the equipment. The use of inappropriate parts or tools can cause an electrical shock, excessive heat generation or fire.	
When relocating the equipment, make sure that the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength and if the installation work is not conducted securely, the equipment can fall and cause injury.	
Be sure to install the product correctly by using the provided standard installation frame. Incorrect use of the installation frame and improper installation can cause the equipment to fall, resulting in injury.	For integral units only
Be sure to install the product securely in the installation frame mounted on a window frame. If the unit is not securely mounted, it can fall and cause injury.	For integral units only

SiBE04-624 Introduction


A Warration	
V i Warning	
Be sure to use an exclusive power circuit for the equipment, and follow the technical standards related to the electrical equipment, the internal wiring regulations and the instruction manual for installation when conducting electrical work. Insufficient power circuit capacity and improper electrical work can cause an electrical shock or fire.	
Be sure to use the specified cable to connect between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections can cause excessive heat generation or fire.	
When connecting the cable between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section can cause an electrical shock, excessive heat generation or fire.	
Do not damage or modify the power cable. Damaged or modified power cable can cause an electrical shock or fire. Placing heavy items on the power cable, and heating or pulling the power cable can damage the cable.	
Do not mix air or gas other than the specified refrigerant (R-410A / R22) in the refrigerant system. If air enters the refrigerating system, an excessively high pressure results, causing equipment damage and injury.	
If the refrigerant gas leaks, be sure to locate the leak and repair it before charging the refrigerant. After charging refrigerant, make sure that there is no refrigerant leak. If the leak cannot be located and the repair work must be stopped, be sure to perform pump-down and close the service valve, to prevent the refrigerant gas from leaking into the room. The refrigerant gas itself is harmless, but it can generate toxic gases when it contacts flames, such as fan and other heaters, stoves and ranges.	0
When replacing the coin battery in the remote controller, be sure to disposed of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.	

(Laution	
Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.	
Do not install the equipment in a place where there is a possibility of combustible gas leaks. If a combustible gas leaks and remains around the unit, it can cause a fire.	\bigcirc
Be sure to install the packing and seal on the installation frame properly. If the packing and seal are not installed properly, water can enter the room and wet the furniture and floor.	For integral units only

1.1.3 Inspection after Repair

(I) Warning	
Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet all the way. If the plug has dust or loose connection, it can cause an electrical shock or fire.	0
If the power cable and lead wires have scratches or deteriorated, be sure to replace them. Damaged cable and wires can cause an electrical shock, excessive heat generation or fire.	0

Introduction SiBE04-624



<u>İ</u> Caution	
Check to see if the parts and wires are mounted and connected properly, and if the connections at the soldered or crimped terminals are secure. Improper installation and connections can cause excessive heat generation, fire or an electrical shock.	
If the installation platform or frame has corroded, replace it. Corroded installation platform or frame can cause the unit to fall, resulting in injury.	
Check the grounding, and repair it if the equipment is not properly grounded. Improper grounding can cause an electrical shock.	
Be sure to measure the insulation resistance after the repair, and make sure that the resistance is 1 Mohm or higher. Faulty insulation can cause an electrical shock.	
Be sure to check the drainage of the indoor unit after the repair. Faulty drainage can cause the water to enter the room and wet the furniture and floor.	

1.1.4 Using Icons

Icons are used to attract the attention of the reader to specific information. The meaning of each icon is described in the table below:

1.1.5 Using Icons List

Icon	Type of Information	Description
Note:	Note	A "note" provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
Caution	Caution	A "caution" is used when there is danger that the reader, through incorrect manipulation, may damage equipment, loose data, get an unexpected result or has to restart (part of) a procedure.
Warning	Warning	A "warning" is used when there is danger of personal injury.
5	Reference	A "reference" guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.

Part 1 List of Functions

		_
1	Functions	つ
Ι.	1 UTICUOTIS	_

List of Functions 1

Functions SiBE04-624

1. Functions

	T	T m			T _m
Category	Functions	FTXR28/42/50EV1B RXR28/42/50EV1B	Category	Functions	FTXR28/42/50EV1B RXR28/42/50EV1B
	Inverter (with Inverter Power Control)	0			1
Basic	Operation Limit for Cooling (°CDB)	21 ~43	-	Air Purifying Filter with Bacteriostatic, Virustatic Functions	-
Function	Operation Limit for Heating (°CWB)	−20 ~24		Photocatalytic Deodorizing Filter	_
	PAM Control	0		Air Purifying Filter with Photocatalytic Deodorizing Function	_
	Oval Scroll Compressor	_		Titanium Apatite Photocatalytic	0
Compressor	Swing Compressor	0		Air Purifying Filter	U
Compressor	Rotary Compressor	_		Air Intake Filter	0
	Reluctance DC Motor	0		Flash Streamer Air Purifying	0
	Power-Airflow Flap	_	Health &	Mold Proof Air Filter	0
	Power-Airflow Dual Flaps	0	Clean	Wipe-clean Flat Panel	0
	Power-Airflow Diffuser	T —		Washable Upper Grille	0
	Wide-Angle Louvers	0		Filter Cleaning Indicator (Remote Controller)	0
Comfortable	Vertical Auto-Swing (Up and Down)	0	1	Mold Proof Operation	0
Airflow	Horizontal Auto-Swing (Right and Left)	0		Mold Shock Operation	0
	3-D Airflow	0	1	Mold Proof Stick	0
	Comfort Airflow Mode	0	1	Comfort Sleep Operation	0
	Cooling Breeze Operation	0		Fresh Air Supply Ventilation	0
	3-Step Airflow (H/P Only)	_	1	Home Leave Ventilation	0
	Auto Fan Speed	0	1	Heating Dry Operation	† –
	Indoor Unit Quiet Operation	0	1	Good-Sleep Cooling Operation	+ —
	Night Quiet Mode (Automatic)	_		24-Hour ON/OFF Timer	0
Comfort Control	Outdoor Unit Quiet Operation (Manual)	_	Timer	Count Up-down ON/OFF Timer	OFF only
Control	Intelligent Eye —			Night Set Mode	0
	Quick Warming Function	0		Quiet Control	0
	Hot-Start Function O			Auto-Restart (after Power Failure)	0
	Automatic Defrosting	0	Worry Free	Self-Diagnosis (Remote Controller) Display	0
	Automatic Operation	0	"Reliability & Durability"	Wiring Error Check	1 —
	URURU Humidifying Operation	0	Durabina	Anticorrosion Treatment of Outdoor Heat	
	Moisturizing Operation	0	1	Exchanger	0
0	SARARA Drying Operation	0		Made Oall / Oall Oanna all a landa and lait	
Operation	Dry Cooling Operation	0	1	Multi-Split / Split Compatible Indoor Unit	-
	Programme Dry Function	_	1	Flexible Voltage Correspondence	T —
	Fan Only		Flexibility	High Ceiling Application	_
	Air Purifying Operation	0	1 1	Chargeless	0
	New Powerful Operation (Non-Inverter)	+ -	1	Either Side Drain (Right or Left)	0
	Inverter Powerful Operation	0	1	Power Selection	
	Dry Keep	JP set		5-Rooms Centralized Controller (Option)	0
	Priority-Room Setting	_	1_	Remote Control Adaptor	_
	Cooling / Heating Mode Lock	1 —	Remote	(Normal Open-Pulse Contact) (Option)	0
	Home Leave Operation	_	Control	Remote Control Adaptor	
	ECONO Mode	_	1	(Normal Open Contact) (Option)	0
Lifestyle	Indoor Unit ON/OFF Switch	0	1	DIII-NET Compatible (Adaptor) (Option)	0
Convenience	Multi-colored Indicator	0	Remote	Wireless	0
	Monitor Brightness Setting	0	Controller	Wired	1 —
	Signal Reception Indicator	0			1
	Temperature & Humidity Level Information Display (Remote Controller)	0			
	Childproof Lock	0			
	Temperature Display	 			
	Another Room Operation	1 —			1
	O : Holding Functions		1	1	

Note: O : Holding Functions

— : No Functions

Part 2 Specifications

1.	Specifications	.4	Ļ
----	----------------	----	---

Specifications 3

Specifications SiBE04-624

1. Specifications

50Hz 220-230-240V

	Indoor Units		FTXR2	8EV1B	FTXR42EV1B		
Model	Outdoor Units		RXR28			2EV1B	
			Cooling	Heating	Cooling	Heating	
Conneity		kW	2.8 (1.55~3.60)	3.6 (1.30~5.00)	4.2 (1.55~4.60)	5.1 (1.30~5.60)	
Capacity Rated (Min.~N	Max)	Btu/h	9,600 (5,300~12,300)	12,300 (4,400~16,400)	14,300 (5,300~15,700)	17,400 (4,400~19,100)	
		kcal/h	2,410 (1,330~3,100)	3,100 (1,120~4,130)	3,610 (1,330~3,960)	4,390 (1,120~4,820)	
Moisture Rem	oval	L/h	1.6	_	2.3	_	
Running Curre	ent (Rated)	Α	3.2-3.1-3.0	3.9-3.8-3.7	5.3-5.2-5.1	5.9-5.8-5.7	
Power Consur	mption	W	560 (250~800)	700 (200~1,410)	1,050 (260~1,320)	1,180 (220~1,600)	
Rated (Min.~N	/lax.)	%	79.5-78.5-77.8	81.6-80.1-78.8	90.1-87.8-85.8	90.9-88.5-86.3	
COP		w/w					
Rated (Min.~N			5.00 (6.20~4.50)	5.14 (5.91~3.55)	4.00 (5.96~3.48)	4.32 (5.91~3.50)	
Piping	Liquid	mm	φ6			6.4	
Connections	Gas	mm	φ 9			9.5	
	Drain	mm		3.0		8.0	
Heat Insulation			•	nd Gas Pipes	•	ind Gas Pipes	
Max. Interunit		m	1			0	
	Height Difference	m		3		8	
Amount of Add	ditional Charge	g/m	Charc	jeless	Char	geless	
of Refrigerant		3			· ·	_	
Indoor Unit	-1		FTXR2			2EV1B	
Front Panel C	olor			nite		hite	
	1	Н	11.1 (392)	12.4 (438)	12.4 (438)	12.9 (456)	
Air Flow Rate	m³/min	M	8.8 (311)	9.8 (346)	9.6 (339)	10.2 (360)	
, ai i iow nate	(cfm)	L	6.5 (230)	7.3 (258)	6.8 (240)	7.7 (272)	
		SL	5.7 (201)	6.5 (230)	6.0 (212)	6.8 (240)	
	Type	•	Cross Flow Fan	(With Saw Edge)	Cross Flow Fan	(With Saw Edge)	
Fan	Motor Output	W	5	7	5	57	
	Speed	Steps	5 Steps, C	Quiet. Auto	5 Steps. 0	Quiet, Auto	
Air Direction C			Right, Left, Horiz			ontal, Downward	
Air Filter			Removable / Wash			nable / Mildew Proof	
Running Curre	ent (Rated)	Α	0.15-0.14-0.13	0.15-0.14-0.13	0.17-0.16-0.15	0.17-0.16-0.15	
	mption (Rated)	W	30-30-30	30-30-30	35-35-35	35-35-35	
Power Factor	ription (Hateu)	%	90.9-93.2-96.2	90.9-93.2-96.2	93.6-95.1-97.2	93.6-95.1-97.2	
Temperature (Control	/0	Microcomp			uter Control	
Dimensions (F		mm		90×209		90×209	
	nensions (H×W×D)	mm	280×95			56×378	
Weight		kg	14 20			4	
Gross Weight	1	kg	2	0	2	20	
Operation Sound	H/M/L/SL	dBA	39/33/26/23	41/35/28/25	42/35/27/24	42/36/29/26	
Sound Power	Н	dBA	55	57	58	58	
Outdoor Unit			RXR28EV1B		RXR4	2EV1B	
Casing Color			Ivory White		lvorv	White	
calcaring carea	Type		Hermetically Sea		,	aled Swing Type	
Compressor	Model		2YC3			6CXD	
00p.:0000.	Motor Output	W		00		100	
Refrigerant	Model	_ ' ''	FVC		,	050K	
Oil	Charge	L	0.			1.4	
	Model	-		10A	R-410A		
Refrigerant	Charge	kg		4		.4	
		Ng	33.8		36.2		
Air Flow Rate (HH)	m³/min			31.4		31.9	
(1 11 1)	cfm		800 750		850 760		
Fan Type		147	Propeller 60		Propeller 60		
D	Motor Output	W				-	
Running Curre		A	3.05-2.96-2.87	3.75-3.66-3.57	5.13-5.04-4.95	5.73-5.64-5.55	
	mption (Rated)	W	530-530-530	670-670-670	1,015-1,015-1,015	1,145-1,145-1,145	
Power Factor		%	79.0-77.8-76.9	81.2-79.6-78.2	89.9-87.6-85.4	90.8-88.3-86.0	
Starting Current A		3.9			.9		
Dimensions (H×W×D) mm		_	693×79			95×285	
Packaged Dimensions (H×W×D) mm			35×410		35×410		
Weight		kg		8		18	
Gross Weight		kg	5	5	5	55	
Operation Sound	Н	dBA	46	46	48	48	
Sound Power	Н	dBA	60	60	62	62	
Drawing No.	1	3D/ (3D054			4160A	
uming 140.			3503-		3003		

Note:

\blacksquare The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/ Outdoor ; 35°CDB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae kcal/h=kW×860 Btu/h=kW×3414 cfm=m³/min×35.3 SiBE04-624 Specifications

50Hz 220-230-240V

	Indoor Units		FTXR50EV1B			
Model	Outdoor Units		RXR50EV1B			
		134/	Cooling	Heating		
Capacity		kW	5.0 (1.55~5.50)	6.0 (1.30~6.20)		
Capacity Rated (Min.~N	Max.)	Btu/h	17,100 (5,300~18,800)	20,500 (4,400~21,200)		
4		kcal/h	4,300 (1,330~47,300)	5,160 (1,120~5,330)		
Noisture Rem		L/h	2.8	7.170.70		
Running Curre		A	7.2-7.1-7.0	7.4-7.3-7.2		
Power Consur Rated (Min.~N	nption Max)	W	1,460 (260~1,800)	1,510 (230~1,770)		
Power Factor	ncot.)	%	92.2-89.4-86.9	92.8-89.9-87.4		
COP						
Rated (Min.~N	Max.)	W/W	3.42 (5.96~3.06)	3.97 (5.65~3.50)		
,	Liquid	mm		φ 6.4		
Piping Connections	Gas	mm		φ 9.5		
onnections	Drain	mm		φ18.0		
leat Insulation	1	1	Both Liqui	d and Gas Pipes		
Max. Interunit	Piping Length	m	·	10		
	Height Difference	m		8		
	ditional Charge		0			
f Refrigerant		g/m		argeless		
ndoor Unit			FTX	R50EV1B		
ront Panel Co	olor			White		
		Н	13.3 (470)	14.0 (494)		
V. E	m³/min	М	10.3 (364)	11.1 (392)		
Air Flow Rate	(cfm)	L	7.3 (258)	8.3 (293)		
	,	SL	6.5 (230)	7.3 (258)		
	Type			an (With Saw Edge)		
an	Motor Output	T W	0.0001.0111	57		
ai i	Speed	Steps	5 Stens	s, Quiet, Auto		
ir Direction C	<u>. ' </u>	Окоро		prizontal. Downward		
ir Filter	Ontio		9 7 - 7	ashable / Mildew Proof		
Running Curre	ant (Dated)	A	0.20-0.19-0.18	0.20-0.19-0.18		
	, ,	W	40-40-40			
	mption (Rated)			40-40-40		
Power Factor	2 1 1	%	90.9-91.5-92.6	90.9-91.5-92.6		
emperature (Microcomputer Control 305x890x209			
Dimensions (F		mm				
	nensions (H×W×D)	mm	280×956×378			
Veight		kg		14		
Gross Weight		kg		20		
Operation	H/M/L/SL	dBA	44/37/29/26	44/38/31/28		
Sound						
Sound Power	Н	dBA	60	60 R50EV1B		
Outdoor Unit			7-1-2			
Casing Color	T		-	ory White		
	Туре			Sealed Swing Type		
Compressor	Model			C36CXD		
	Motor Output	W		1,100		
Refrigerant	Model		F	VC50K		
Dil -	Charge	L		0.4		
Refrigerant	Model		F	R-410A		
	Charge	kg		1.4		
ir Flow Rate	m³/min		36.2	34.3		
HH)	cfm		850	810		
an	Туре		P	ropeller		
-	Motor Output	W		60		
Running Curre		A	7.0-6.91-6.82	7.2-7.11-7.02		
ower Consur	mption (Rated)	W	1,420-1,420-1,420	1,470-1,470-1,470		
ower Factor		%	92.2-89.3-86.8	92.8-89.9-87.3		
Starting Curre	nt	Α		7.4		
Dimensions (H	H×W×D)	mm	693	×795×285		
Packaged Dim	nensions (H×W×D)	mm		×935×410		
Veight	· ··-/	kg		48		
Gross Weight		kg		55		
POIGHOII	Н	dBA	48	50		
Sound						
Operation Sound Sound Power	Н	dBA	62	64		

Note:

■ The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3 Specifications SiBE04-624

Part 3 Printed Circuit Board Connector Wiring Diagram

1.	Print	ted Circuit Board Connector Wiring Diagram	8
		Indoor Unit	
		Outdoor Unit	

1. Printed Circuit Board Connector Wiring Diagram

1.1 Indoor Unit

Connectors

A1P (Control PCB)

1) S1 Connector for fan motor

2) S21 Connector for centralized control (HA)

3) S32 Connector for heat exchanger thermistor (R1T)4) S41, S51 Connector for swing motor (horizontal, vertical)

5) S43 Connector for solenoid valve6) S46 Connector for display PCB

7) S48 Connector for humidity sensor PCB

8) S51 Connector for reduction motor, limit switch (front panel)

9) S52 Connector for streamer unit

A2P (Display PCB)

1) S56 Connector for control PCB

2) S57 Connector for signal receiver / transmitter PCB

3) S63 (H1P) Connector for LED PCB (multi monitor)

A3P (Signal Receiver/Transmitter PCB)

1) S58 Connector for display PCB

A4P (Humidity Sensor PCB)

1) CN1 Connector for control PCB

A5P (High Voltage Unit PCB)

1) S401 Connector for control PCB

2) S402 Connector for limit switch for streamer

3) S403 Connector for streamer

Note:

Other designations

A1P (Control PCB)

V1 Varistor
 FU1 Fuse (3.15A)

3) LED A LED for service monitor (green)

4) JB Fan speed setting when compressor is OFF on thermostat

JC Power failure recovery function (auto-restart)

*Refer to page 300 for detail.

A2P (Display PCB)

1) JA Address setting jumper

2) SW1 Forced operation ON / OFF switch

3) LED2 LED for timer (yellow)


4) LED3 LED for moisture operation (green)

A4P (Humidity Sensor PCB)

1) R2T Room temperature thermistor


PCB Detail

PCB(1): Control PCB




PCB(2): Display PCB


PCB(3): Signal Receiver / Transmitter PCB



PCB(4): Humidity sensor PCB



PCB(5): High Voltage Unit PCB



1.2 Outdoor Unit

Connectors


1) S20	Connector for electronic expansion valve coil
2) S21	Connector for rotor motor
3) S22	Connector for damper motor
4) S45	Connector for thermal fuse
5) S70	Connector for DC fan motor
6) S72	Connector for humidification fan motor
7) S80	Connector for four way valve coil
8) S90	Connector for thermistor (outdoor, heat exchanger, discharge pipe)
9) S91	Connector for humidifying thermistor
10)S501	Connector for limit switch
11)HR1, HR2	Connector for reactor
12)HK1, HK2, HK3	Connector for fan motor
13)HH1, HH2	Connector for heater

Note: Other designations

1) FU1, FU2 Fuse (3.15A) 2) FU3 Fuse (30A) 3) V2, V3 Varistor

4) LED A, LED5 LED for service monitor (green)

PCB Detail PCB(1): Control PCB FU3 (30A) V2 HK1 HH1




Part 4 Function and Control

1.	Desc	cription of Operation	.15
	1.1	Indoor Unit	.15
	1.2	Outdoor Unit	.16
2.	Main	Functions	.17
	2.1	"URURU" Humidifying / Humid Heating Operation	
	2.2	"SARARA" Drying Operation	
	2.3	Comfort Sleep Operation	.28
	2.4	MOISTURIZING Operation	
	2.5	Automatic Operation	.31
	2.6	Comfort Airflow Mode	.32
	2.7	Cooling Breeze Operation	.34
	2.8	Power-airflow Dual Flaps	.35
	2.9	Wide-angle Louvers	.36
	2.10	3-D Airflow	.37
	2.11	POWERFUL Operation	.38
	2.12	Indoor Unit Quiet Operation	.39
	2.13	Multi-colored Indicator Lamp	.39
	2.14	Monitor Brightness Setting	.40
	2.15	Information Display	.40
	2.16	MOLD PROOF Operation	.41
	2.17	Mold Proof Stick	.43
	2.18	MOLD SHOCK Operation	.44
	2.19	HOME LEAVE Ventilation	.47
	2.20	FLASH STREAMER AIR PURIFYING Operation	.48
	2.21	Fresh Air Supply Ventilation	.51
		Wipe-clean Flat Panel	
	2.23	Filter Cleaning Indicator (Remote Controller)	.53
	2.24	TIMER Operation	.54
	2.25	Night Set Mode	.55
	2.26	Table for Special Modes	.56
		Thermostat Control	
	2.28	Fan Speed Control for Indoor Units	.59
	2.29	Draft Prevention (HOT Start)	.61
3.	Cont	rol Specification	.62
	3.1	Frequency Control	
	3.2	Preheating Operation (Quick Warming Function)	.63
	3.3	Four-way Valve Operation	.64
	3.4	Compressor Start up Protection	.65
	3.5	Fan Speed Control for Outdoor Unit	.66
	3.6	Fin Thermistor Control	.66
	3.7	Input Current Control	.67
	3.8	Peak-cut Control	
	3.9	Indoor Coil Freeze up Protection	.69
		Dew Prevention	
	3.11	Liquid Compression Protection 2	.71

3.12 Discharge Pipe Temperature Control	72
3.13 Automatic Defrosting	73
3.14 Electronic Expansion Valve Control	75


1. Description of Operation

1.1 Indoor Unit



(R3387)

1.2 Outdoor Unit




SiBE04-624 Main Functions

2. Main Functions

2.1 "URURU" Humidifying / Humid Heating Operation

Operation



* Refer to the operation manual for details.

Features

A world first new humidifying method has adopted

What is new in this method is to intake vapor in the outdoor air with the hygroscopic element mounted in outdoor unit, and send indoors. This has enabled powerful and speedy humidification apart from other company's methods which just absorb moisture in the indoor air.



■ The room is uniformly humidified.

Humidifier + heating operation by air conditioner
 Moisture gathers around the ceiling, as it is lighter than the air even if the humidifier is operated. The air on the floor is kept dry.



When using humidifier, moisture gathers around the ceiling. (R3325)

Main Functions SiBE04-624

· "Humid heating" by URURU / SARARA

This air conditioner enables uniformly humidifying the room by circulating vapor with warm air.



The room is uniformly humidified.

(R3326)

■ Powerful humidifying ability

The humidifying capacity is 450 ml/h (5.0 kW class) and equivalent to that of a normal humidifier.

Model	FTXR28E	FTXR42E	FTXR50E
Humidifying Capacity	400ml/h	425ml/h	450ml/h

The values above are measured at 7°C DB / 6°C WB of outdoor air and with 7.5 m of humidifying hose length.

■ No need for water supply nor cleaning

Water supply and cleaning are unnecessary as it does not have water tank, unlike humidifiers, and there is no proliferations of bacteria.

■ Humidity control

The FTXR-E series model performs the humidifying operation, targeting the humidity level of 40 to 50%.

(You can select the remote controller setting from Low, Standard, High and Continue. The target humidity (%) cannot be set.)



- When the outdoor temperature and humidity are low, the humidifying capacity is decreased. In addition, the moisture in the room may not attain sufficient humidity when the ventilation volume is high, the preset temperature is high, or the preset humidity is HIGH.
- After the "humid heating" operation starts, the relative humidity in the room lowers temporarily. This phenomenon is caused by the increase of the saturation water vapor. Therefore, the humidity raises gradually after the temperature reaches the preset temperature.
- In the humidifying operation, the operation sound increases by about 2 dB both in the indoor and outdoor units. (When the air flow rate is in L or SL, the operation sound increases by about 3 dB in the indoor unit.)
- This system does not suppose the storage of musical instruments or the like.

Conditions for Humidifying Operation

While heating mode, humidifying operation can be available when the following conditions 1~5 are met at the same time.

- 1. Indoor heat exchanger temperature is 12°C or more.
- 2. Outdoor temperature is from -10°C to 24°C (meanwhile, in test operation, up to 34°C is possible). Humidifying operation does not work under -10°C.
- 3. Approx. 1 minute has already passed after heating operation startup. (See Note.)
- 4. Heating operation does not work to its full capacity. (Meanwhile, the "continuous" humidification is selected, humidifying operation has the priority.)
- 5. Room humidity is under 70%RH.



■ Exclude the case when it is recovered from thermostat-off or when the defrosting operation finished.

SiBE04-624 Main Functions

How to Check the Motion of Humidifying Operation

You can check whether the humidifying unit is in good working order. If you set "the humidifying only test operation" (refer to the installation manual for details), you can check even beyond the range of the conditions for humidifying operation mentioned above.

- 1. Hygroscopic fan Air is exhaled from the front exhaust outlet of outdoor unit.
- 2. Humidifying fan/heater/damper... Warm air is blown from the duct of outdoor unit.
- 3. Humidification rotor The rotor is rotating with top panel off.

As for the performance, estimate from psychrometric chart with the measured temperature and humidity of the outdoor air and of the humidified air (in front of the indoor outlet) using thermal hygrometer.

Performance class	Air flow rate (m³/min)	
2.8kW	0.40	
4.2, 5.0kW	0.44	


Humidity Fluctuation by Temperature Settings

At Humidifying Heating Operation, as room temperature rises, relative humidity is temporarily lowered. This is because as room temperature rises, relative humidity is lowered even if the moisture content is the same.

e.g.) The rise in the room temperature from 15° C to 25° C will result in the rise in humidity from 40%RH to about 22%RH.

As humidifying operation starts concurrently with heating, humidity rises gradually as shown in the figure below.


Some room conditions (floor space, ventilation frequency, number of residents, etc.) and temperature settings (mostly higher settings) may result in unsatisfactory humidity settings.



Main Functions SiBE04-624

Time chart for humidifying operation control

Approx. 1min. after heating operation start up, it repeats humidifying and drying alternately (to protect condensation for inside the hose).



a. Humidifying time	Approx. 70min.	Decide time according to the outdoor temperature and hose length set by remote controller.	
b . Drying time	Approx. 2~10min.	Decide time according to the hose length set by remote controller.	
b '. Drying time	Approx. 2~10min.		

★ "Humidifying only operation" has no 1min-delay, it immediately starts up from ⑤', and works in the same sequence as others .

■ Time chart for "humidifying only test operation"

"Humidifying only test operation" on trial mode works in the same sequence as humidifying operation, but about 30 min. later it automatically stops.

■ Remarks

- 1. When a room is spacious such as loft style or partitioned by accordion style curtain, the ventilation volume is large and may not sometimes reach the set humidity.
- 2. When room temperature falls (12°C or lower), though "humidifying only test operation" is functionally possible, humidifying heating operation continues to keep room temperature.

SiBE04-624 Main Functions


Humidification performance by outdoor temperature

The humidifying of this system is different from that of the normal humidifier. Therefore, the humidifying performance varies with the outdoor temperature or installation condition. Sufficient humidifying capacity may not be attained depending on the weather condition in operation.


When the outdoor temperature lowers by 5°C, the humidifying capacity is decreased by about 15%.

When the outdoor humidity lowers by 20%, the humidifying capacity is decreased by about 20%.


28 class (rated: 400ml/h)



42 class (rated: 425ml/h)




50 class (rated: 450ml/h)



Main Functions SiBE04-624

Reachable humidity by outdoor condition


• The ability of humidification drops when the outdoor temperature and humidity are low. **28 class**



Condition; Model:FTXR28EV1B Indoor temperature setting:20°C Airflow rate:Max Room volume:70m³ Air change rate:0.5/hour humidifying hose length:7.5m

(R5957)

42 class




Condition; Model:FTXR42EV1B Indoor temperature setting:20°C Airflow rate:Max Room volume:100m³ Air change rate:0.5/hour humidifying hose length:7.5m

(R5958)

SiBE04-624 Main Functions

50 class




Condition; Model:FTXR50EV1B Indoor temperature setting:20°C Airflow rate:Max Room volume:120m³ Air change rate:0.5/hour humidifying hose length:7.5m

(R5959)

Performance compensation by hose length

The max. piping length is set to 10 m, but the humidifying performance varies with the length of the humidifying hose.

When the hose length increases by 2 m, the humidifying capacity decreases by about 10%.




Main Functions SiBE04-624

Reference


■ Room humidity (discharged air humidity) by ventilation cycle (16m², hose length: 4m, 28 class)

1. Outdoor temp. 0°CDB, 50% RH



(R3335)


2. Outdoor temp. 7°CDB, 87% RH




SiBE04-624 Main Functions

■ Room humidity (discharged air humidity) by outdoor temperature (16m², hose length: 4m, ventilation cycle: 0.75 times/h, 28 class)


1. Room temp. 17°CDB



2. Room temp. 20°CDB




3. Room temp. 23°CDB



2.2 "SARARA" Drying Operation

Operation




* Refer to the operation manual for details.

Features


Reheating dehumidifying method is applied.

Powerful evaporator eliminates the humidity in your room exclusively. Dry cool air is mixed with warm air from the reheater, thereby blowing in optimal and comfortable dry air.



■ Adjustable at your preferred humidity even on cooling

You can get comfortable coolness even with the moderate cooling because you can adjust the indoor humidity as you like. By decreasing temperature difference to outdoors, it enabled to avoid a heat shock. It is recommended for ladies and elders who are sensitive to cooling and for families with a baby as well as energy saving.




■ Differences on "dehumidification" and "cooling dehumidification" operation

	-	· · · · · · · · · · · · · · · · · · ·
	"SARARA" Drying	Dry Cooling
Method	Puts a pressure reducing device (solenoid valve) in the center of the heat exchanger of indoor unit to separate it into upper and lower side. The upper side acts as a condenser to heat the air.	As is the cooling mechanism, the Dry Cooling Operation raises latent heat capacity with controlling sensible heat capacity by adjusting the compressor frequency and indoor air flow rate.
	The heat exchanger in the lower perform the usual Dry Cooling Operation to make low-temperature and low-humidity air.	
	The both types of air are mixed to make moderate-temperature and low-humidity air for blowing.	
Case by case use for dehumidification and cooling dehumidification	As this is a reheating method, it is recommended in such a case to eliminate humidity without lowering room temperature as possible (this is recommended when cooling load is small).	The dry cooling does not use reheating method. In order to eliminate humidity, it is recommended to use at the set temperature lowered by several °C from the room temperature at operation starting up (this is recommended when cooling load is large).
Mechanism		
	Outdoor Unit Indoor Unit Open Close* Heat Exchanger Compressor Solenoid valve for dehumidifying *Pressure is reduced by the gap in the close condition	Outdoor Unit close* open Heat Exchanger * Depends on the condition (R5964)
	(R5963)	
Humidity adjusting method	Adjust by operation frequency of the compressor. When operation frequency increases, humidity falls, and when the frequency decreases, humidity fall is suppressed.	Adjust by operation frequency of the compressor and indoor air flow rate. When operation frequency increases and indoor air flow rate decreases, the humidity falls. When operation frequency decreases and the air flow rate increases, humidity fall is suppressed.
Room temperature adjusting method	Adjust by outdoor air flow rate. When outdoor air flow rate increases, room temperature falls, and when it decreases, room temperature fall is suppressed.	Adjust by operation frequency of the compressor. When operation frequency increases, the room temperature falls, and when operation frequency decreases, the room temperature fall is suppressed.
Thermostat OFF condition	 When room temperature falls. Room temp. ≤ preset temp2.5 or Room temp. ≒ preset temp. and the humidity is lower than target humidity (lower by more than 5%). 	When room temperature falls. • Room temp. ≤ preset temp.–2.0 or • Preset temp.–1.5 < room temp. ≤ preset temp.–1.0 continues for 10 min.
Thermostat OFF → ON condition	When thermostat OFF condition is not satisfied	Room temp. ≥ preset temp0.5 or Preset temp1.5 < room temp. ≤ preset temp1.0 continues for 10 min.
Time to reach the target humidity	Approx.1hour consecutive as a standard (depending on the conditions)	Approx.1hour consecutive as a standard (depending on the conditions)
Remarks (FAQ)	The humidity does not decrease. According to the load conditions of your room, the temperature sometimes falls and thermostat ON/OFF repeats. As a result, the room may not be dehumidified enough. Set the temperature lower.	The humidity does not decrease. (Thermostat ON/OFF are repeated.) As the reheating method is not used, if you set the temperature close to the room temperature, thermostat ON/OFF are repeated according the load conditions of the room. As a result, the room may not be dehumidified enough. In cooling dehumidification mode, set the temperature lower than the room temperature by several degrees. If you do not want to lower the room temperature too much, reheating dehumidification operation method is recommended.

2.3 Comfort Sleep Operation

Operation



- Effective mode for COMFORT SLEEP operation
 - Cooling
 - · Dry cooling
 - Moisture cooling
 - Heating
 - · Humid heating
 - · Moisture heating
- * Refer to the operation manual for details.

Features


Outline of function

The temperature is controlled in unique V-shape pattern within the range of about 2°C upper and lower. First the room temperature is gradually lowered at the beginning of sleep to induce the lowering of body temperature in sleeping.

Then, the room temperature is kept constant, and when the preset wake-up time approaches, the room temperature is gradually raised to induce the raising of body temperature before waking.

- V-shape pattern temperature control system
 - The air conditioner controls the room temperature showing V-shape pattern.

<V shape temperature control>




(R5089)

Change in body temperature in human sleep is controlled in ideal V-shape pattern by airconditioner's temperature control.

(Reference: Control system adopted for JAL First Class flight)

Human sleep


Sleep cycle and change in body temperature



The body temperature lowers after falling asleep and rises before wake-up. (Changes in V-shape)


(Changes in v-snape)

(R5090)




Reference

■ Effect



2.4 MOISTURIZING Operation


Operation



- Effective mode for MOISTURE COOLING
 - Cooling
 - · Dry cooling
- Effective mode for MOISTURE HEATING
 - Heating
 - · Humid heating
- * Refer to the operation manual for details.


Features

- "Relatively high humidity" setting, "Comfort Airflow Mode" giving no airflow to the body, and "emission of vitamins and hyaluronic acid" --- These 3 types of operations are performed simultaneously to create skin-friendly environment.
- MOISTURIZING operation is to make the room condition friendly to your skin. It is not for beauty and beautiful skin treatment, and prevention of skin roughness.
- Details of operation



- Operation to keep the humidity 65%
- Being unlike ordinary dry cooling, it prevents the room from drying.

(R5093)




- Operation to keep the humidity 60%
- It creates a space more moisturized than by ordinary humid heating.

(R5094)

2.5 Automatic Operation

Operation



* Refer to the operation manual for details.

Features

When the AUTO mode is selected with the remote controller, the microcomputer automatically determines the operation mode from cooling and heating according to the room temperature and setting temperature at the time of the operation startup, and automatically operates in that mode.

The unit automatically switches the operation mode to cooling or heating to maintain the room temperature at the main unit setting temperature.

Details

- 1. Remote controller setting temperature is set as automatic cooling / heating setting temperature (18 to 30°C).
- 2. Main unit setting temperature equals remote controller setting temperature plus correction value (correction value: 0 deg).
- 3. Operation ON / OFF point and mode switching point are as follows.
 - Heating → Cooling switching point:


Room temperature ≥ Main unit setting temperature +2.5 deg.

② Cooling → Heating switching point:

Room temperature < Main unit setting temperature -2.5 deg.


- ③ Thermostat ON / OFF point is the same as the ON / OFF point of cooling or heating operation.
- 4. During initial operation

Room temperature \geq Remote controller setting temperature: Cooling operation Room temperature < Remote controller setting temperature: Heating operation



2.6 Comfort Airflow Mode

Operation



- Effective mode for comfort airflow mode
 - Heating
 - · Humid heating
 - Cooling
 - · "SARARA" drying
 - · Dry cooling
 - Moisturizing
- Flap motion
 - Upper and lower flaps halt at the fixed position of the upper side or lower side of the swing.
 - · Left and right flaps move according to the settings of remote controller.
- Airflow rate
 - · Airflow rate is at "automatic".
- * Refer to the operation manual for details.


Features


Draftless operation prevents direct blow to human

Draftless operation sustains direct blow to skins. Cool air is blown up in the room and changed into slow downward flow, circulating into entire room. Meanwhile the warm air is blown down vertically to our foot, warming the room from the floor.

■ Feel cold on cooling operation


■ When comfort airflow mode is carried out in cooling · · ·







(R3355

■ Feel air on heating








Note

In heating operation, it takes time to transmit heat to a distant place because the airflow direction is controlled not to blow direct on human. It is recommended that this operation mode is used after the room has been warmed up.

2.7 Cooling Breeze Operation

Operation



- Effective mode for cooling breeze airflow
 - Cooling
 - "SARARA" drying
 - Dry cooling
 - · Flash streamer air purifying



On automatic mode, when actual operation mode is heating, this cool air fluctuation operation does not work. (Indication on remote controller is shown.)

■ Flap operation

As shown in the graph above, the standard point is the upper limit of the swing so that the air do not touch directly.

Depending on the room temperature or the thermostat on/off state, swing interval is changed.

(The lower the temperature, the longer the swing interval, thereby comfort is maintained.) Left and right flaps move as set at the settings of remote control.

Airflow rate

Airflow rate is controlled automatically.


* Refer to the operation manual for details.

Features

1/f fluctuation rhythms switches air flow direction


By fluctuating air flow direction you can feel cool even the room temperature is set rather high.

By1/f fluctuation rhythm, upper and lower flaps move up and down unlike the conventional up and down swing, and this movement brings you a comfortable air like a breeze in nature.



2.8 Power-airflow Dual Flaps

■ Triple air flow by the combination with wide-angle louvers



(R5970)


2.9 Wide-angle Louvers

Wider airflow eliminates disagreeable irregular temperature distribution.


For the right and left flaps, the wide-angle louver which produces wider airflow is adopted. Since it veers flexibly and swings horizontally at a wide angle, comfortable airflow spreads to every corner of the room.

■ Wide-angle Louvers


Direction of airflow changes greatly along the shape of curved vane.



■ Flap angle




It can send the airflow to the center of the room even when the air-conditioner is installed at a corner of the room.



2.10 3-D Airflow

Alternative swing of flaps in vertical and horizontal directions circulates the airflow to every corner of the room and prevents uneven temperature distribution.


Use of the 3-D airflow control prevents uneven temperature distribution in the whole room. Particularly, the comfortable zone 10 cm above the floor is widened 1.5 times of the conventional zone.



- If it is used at the start of operation, a flow of draft may feel you chilly.
- It is recommended to use it after the room temperature is stabilized.

2.11 POWERFUL Operation

Operation



(R5971)

- Effective mode for POWERFUL COOLING
 - Cooling
 - · Dry cooling
 - Moisture cooling
- Effective mode for POWERFUL HEATING
 - Heating
 - · Humid heating
 - · Moisture heating
- * Refer to the operation manual for details.



- Operating sound becomes slightly loud.
- It is impossible to change the airflow rate, temperature, and humidity.

Features

The airflow rate and the compressor rotating speed are increased from the normal operation for 20 min. This operation is convenient when you just come back home. (Normal operation will be resumed automatically in 20 min.)

2.12 Indoor Unit Quiet Operation

Features

Forced dropping of the fan tap decreases the airflow rate and reduces airflow noise. (Noise is reduced by about 3 dB as compared to that in L tap.)




- Airflow rate can not be set.
- Since the performance is somewhat lowered as compared to that in normal operation (70% under rated conditions), the room may not be cooled (or heated) when this operation is used for a long time.
- The indoor unit quiet operation is kept in memory even when the power supply is turned OFF.

The indication remains on the display of the wireless remote controller and the indoor unit quiet operation works when the power is turned ON again.

2.13 Multi-colored Indicator Lamp

Features

Current operation mode is displayed in color of the lamp of the indoor unit which changes in 8 colors. Operating status can be monitored even in automatic operation in accordance with the content of actual operation.



- The lamp color changes according to the operation.
 - HEATING.....Red
 - "URURU" HUMIDIFYING /
 - HUMID HEATINGOrange
 - COOLINGGreen
 - "SARARA" DRYING /

DRY COOLING......Yellow

- The lamp color also changes according to the optional function.
 - FLASH STREAMER AIR PURIFYING/


FRESH AIR SUPPLY VENTILATION White

(Only for the first 2 seconds during operation of the air conditioner.)

- MOLD PROOF......Purple & blue → Blue & light blue → Light blue & white → White
- MOLD SHOCK......Blue & light blue & white

2.14 Monitor Brightness Setting


The brightness of the multi-colored indicator lamp can be adjusted HIGH, LOW, or OFF. It is convenient when it is excessively bright while asleep.



* Refer to the operation manual for details.

2.15 Information Display

Operation



* Refer to the operation manual for details.

Features

- Room temperature, indoor humidity, and outdoor temperature are displayed.
- Point the remote controller at the indoor unit for 2 seconds.



- Outdoor temperature during operation may be displayed relatively high in cooling or "SARARA" drying, and relatively low in heating (particularly when the outdoor unit is frosted) by influence of air blown out from the outdoor unit and temperature of the heat exchanger.
- Lowest displayable outdoor temperature is -9°C. Even if the outdoor temperature is lower than this, "-9" is displayed. Highest displayable outdoor temperature is 39°C. Even if the outdoor temperature is higher than this, "39" is displayed.
- Displayed temperature and humidify are those near the sensor.
- Displayed temperature or humidity may be different from the actual temperature or humidity depending on the conditions of indoor unit and outdoor unit installation (due to obstacle near the sensor or influence of direct sunlight).
 Take it as a rough standard.

2.16 MOLD PROOF Operation

This is an integrated naming of functions such as inside drying, moist air exhaustion, mold-prevention stick. Drying inside the air conditioner prevents mold or odors to be generated.

Operation

Operation can be selected from automatic / manual.


Auto operation

(approximately once every 2 weeks)

If the unit is set to "MOLD PROOF ON", the MOLD PROOF operation will start automatically after the unit has been run is "SARARA" DRYING or COOLING mode, depending on the amount of time the unit has been run (approximately once every 2 weeks.)

The default is set to "MOLD PROOF OFF".

■ Manual operation




* Refer to the operation manual for details.

Features

■ Time chart

Operation runs about for 3 hours while changing colors of the multi-colored indicator lamp.



Inside Drying



1. Drained water discharge Drained water in drain pan is discharged.



2. Inside drying operation
After the drained water discharged, the moisture etc.
which are left on drain pan or heat exchanger are dried
by evaporation.


Exhausting Moisture



3. Moisture exhaustion
Exhaust moisture to outdoors using the humidification hose.

Switching air supply / exhausting

We have developed this function on a damper inside the humidification unit, by leaving conventional air intake fan in place that supplies air from outdoor to indoor as it is.



■ Condition for operation

- 1. Accumulated operation time: 21,600 min. (approx.15 days)
- 2. Accumulated cooling/dehumidifying operation time: 5,400 min. (approx.15 days x 6 hours) This function starts when both conditions are met.




- This is not the function for eliminating dust or mold attached inside the air conditioner.
- During operation, smells may occur.
- This function sometimes does not begin when outdoor temperature or indoor humidity is extremely high.
- Depending on the temperature conditions, moisture exhaustion function is not carried out.

2.17 Mold Proof Stick

Features

■ Drain pan which prevents mold proliferation


The drain pan of the main unit which easily goes moldy is equipped with a "Stick" having mildew-proof, antibacterial and antivirus effect.



Since mildew-proof, antibacterial and antivirus agent of silver group which is the compound of highly safe titanium oxide and silver is used as a single agent, drain water is not affected by this agent.

The mildew-proof, antibacterial and antivirus agent is applied to a stick which is covered further with extremely thin resin skin of several microns (resin section without mildew-proof agent on the surface of the resin). The active ingredient is dissolved gradually for about 10 years by immersion and penetration of stick and drain water. Thus, the stick continues working.

Image




* The efficacy of the stick has been proved by Hallo's Method test conducted at Kyoto Microbiological Research Center.

2.18 MOLD SHOCK Operation

The room is kept clean by removing excessive moisture by rapidly lowering the humidity in the room for 1 hour, and keeping operation for 2 hours (total 3 hours).

Operation

It is not self-starting operation.



* Refer to the operation manual for details.

The test was conducted at DAIKIN's lab with use of the mold

sensor of Environmental Biological Research Institute.

Features

■ Dry shock method (Mold Shock Operation)

Method to prevent the generation of mold by suddenly drying the humid environment. It is generally said that the growth of mold can be prevented by lowering the humidity to half and continuing the operation for 3 hours.

Mold before mold shock operation



Without mold shock operation



With mold shock operation




Fewer molds grow as compared with in the case without Mold Shock Operation.

(R5107)

■ Time chart

- Operation runs about for 3 hours in rotal while charging colors of the multi-colored indicator lamp.
- Reheating dehumidifying which dehumidifies continuously.




<Note> The room temperature becomes about 5° C lower than the temperature at the start of operation.


(R5108)

■ Comparison with cooling operation and mold shock operation

Normal cooling operation
The humidity in the room returns to original level when cooling operation is stopped.




Mold shock operation after cooling The humidity in the room is lowered suddenly by Mold Shock Operation.



Reference


■ Effect



(R5112)

2.19 HOME LEAVE Ventilation

Operation



* Refer to the operation manual for details.

■ Ventilate your room while you are out

This function refreshes your room by ventilating while you are out.

■ Operation


- •To take a fresh air from outdoors via outdoor unit, air is heated with a heater on humidification unit contained in the outdoor unit to decompose exhaust gas components (NOx) and the like, and passed through air intake filter to eliminate pollens and mold.
- •OFF timer allows to set operation time ranging from 1 to 9 hours (Factory set: 4 hours).



- 1. Outdoor sound may be heard or air may have a smell, as the air is taken from outdoors. Compared with the other operations, operating sound is rather high.
- 2. According to the outdoor temperature/humidity operating sound sometimes changes.

2.20 FLASH STREAMER AIR PURIFYING Operation

Operation




(R5980)

* Refer to the operation manual for details.

■ Flash Streamer Air-Purifying

The technology for the real air purifier is adopted for the air conditioner. Our original technology "Flash Streamer" system used for our Daikin's air purifiers is incorporated. This technology realizes the air purifying exceeding far from the air purifying performance of the normal air conditioner.

Powerfully analyses and removes the diesel dust, NOx, mold, virus, etc.




■ Mechanism of Flash Streamer Air-Purifying

The streamer discharging high energy electron analyzes and removes powerfully odor, unwanted bacteria and hazardous chemical materials at the oxidative distraction speed of 1000 times higher than the generally used glow discharge.

Air purification flow

New air purification system incorporating the streamer


(Image)



Powerfully decompose and remove molecules of allergens or odors by collision with high-speed electrons discharged from streamer unit.

(R5982)

■ Removing Formaldehyde




The formaldehyde concentration in the laboratory (10 m²) at 0.5-time ventilation and the initial concentration setting of 0.3 ppm (Observed by Daikin using the FTXR28E) (Nozaki laboratory, Graduate Course of Health and Society System, Tohoku Bunka Gakuen University)

(R5983)

■ Deodorizing Performance of Flash Streamer and Titanium Apatite Photocatalyst
Unpleasant odor daily generating in the room such as pet odor or garbage odor is powerfully removed. Speedy deodorization: 90% or more odor has been removed in 10 minutes.
Cigarette odor of 80% or more has been removed.


Daily odor removal performance by streamer air purifying (%)



	Ammonia	Acetaldehyde	Acetic Acid	Cigarette Odor
Removal	90.6%	76.5%	87.2%	82.7%

2.21 Fresh Air Supply Ventilation

Operation



(R5977)


* Refer to the operation manual for details.

Features

Air Supply Ventilation

The air supply ventilation system using only fresh air.

Any contaminated outdoor air is purified in two stages of indoor unit and outdoor unit. Fresh air from which bacteria were removed is supplied into the room.



1. Purifying air in the outdoor unit

Thermal catalyst containing in the humidifying rotor analyzes unpleasant odor and also removes exhaust gases (NOx, SOx).

Manganese catalyst used to treat the automotive exhaust gas is adopted for the thermal catalyst.

2. Purifying air in the indoor unit

The air supply filter is placed at the humidifying hose outlet of the indoor unit side. The air supply filter removes about 97% pollen and dust.

3. Controlling temperature


The fresh air passed through the air supply filter is cooled (or heated) in the indoor unit and supplied into the room.

You can keep comfortable temperature and also replace air because the ventilation is performed while temperature is controlled.

Pollen, exhaust gas and odor that could not be removed by the thermal catalyst and air supply filter will be analysed by the flash streamer and photocatalyst.

■ Ventilation System

The ventilation type is mainly divided into two. The convenient system is supply ventilation.




- Quiet because the ventilation fa is located in the outdoor unit
- Energy saving system due to low heat loss
- The room temperature changes little because no wind enters
- Operation noise is heard because the ventilation fan is located in the room.
- Electricity charges are high because heat loss is high.
- Draft enters easily to prevent comfortable temperature from being kept.

2.22 Wipe-clean Flat Panel

It wipes off dirt in an instant. The grill-less panel is easy to clean and can be dismounted easily for washing.

Dismount the panel in the procedure as mentioned below, wipe it lightly with soft cloth impregnated with lukewarm water or cold neutral detergent solution and dry it in the shade. Note: If it is washes with use of polishing powder or scrubber, or in the water hotter than 40°C, it may be scratched, discolored or deformed.



Caution

- When mounting or dismounting the front panel, use a robust and stable stand and watch out your step.
- Proceed to work while supporting the front panel securely by hand.
- Do not use the water hotter than 40°C, benzin, gasoline, thinner or other volatiles, polishing powder or scrubber.
- Make sure that the front panel is mounted securely.

2.23 Filter Cleaning Indicator (Remote Controller)

When the unit is operated for about 2 weeks (about 340 hours), the filter cleaning indication appears to inform you that the time of maintenance comes.

If the filter is left dirty, the power consumption increases by about 10%. It is recommended to maintain it periodically for energy-saving operation.

How to reset the filter cleaning indicator




When the "FILTER LED RESET" button of the remote control is kept pressed for about 2 sec. toward the air-conditioner main unit after maintenance of the filter, the filter cleaning indication disappears.

(R5118)

2.24 TIMER Operation

2.24.1 24-hour ON/OFF Timer

Operation



(R5986)

* Refer to the operation manual for details.

Features


- Time can be set in the unit of 10 min.
- When the 24-hour ON/OFF is set, the indication of present time disappears.
- Time is kept in memory in the next operation unless it is cancelled.
- The clock error is ±30 sec. per month.

ON Timer

The microcomputer monitors the indoor temperature and outdoor temperature before preset time and the operation is started automatically 1 hour before at maximum so that the room temperature becomes optimum at the preset time.

2.24.2 COUNTDOWN OFF Timer

Operation



(R5987)

* Refer to the operation manual for details.

Features

■ The COUNTDOWN OFF timer sets the time by simple button pressing. The operation is stopped when the set time comes. The time can be set in the unit of 0.5 hour for maximum 9.5 hours. It can be used in combination with the ON timer.


2.24.3 Combination of ON Timer and OFF Timer

■ ON timer and OFF timer, or ON timer and COUNTDOWN OFF timer can be used in combination.


Refer to the operation manual for details.

2.25 Night Set Mode

■ When you set the COUNTDOWN OFF TIMER or OFF TIMER, the unit is operated automatically in night set mode.




(R5123)



(R5124)

2.26 Table for Special Modes

■ Operation of indoor unit ON/OFF button and buttons of remote controller To enter a specific mode, press one of the buttons below for more than 5 sec.



- A. Diagnosis mode is improved to enable one-touch indication by applying two-way communication.
- B. Forced operation mode is the same as the conventional one. (But buzzer beeps, timer and multi-monitor illuminate)
- C. In indoor unit demonstration mode, the color of multi monitor changes regularly and the sequence of events (front panel open \rightarrow flaps swing \rightarrow front panel close) repeats. It takes about 10 minutes for 1 period.
- D. In humidifying demonstration mode, the color of the multi-colored indicator changes regularly.
 - Select "URURU" HUMIDIFYING or HUMID HEATING for demonstration.
 - (This mode can be used for demonstration of humidification operation at shops.)
- E. Trial operation mode is improved in such a way that the conventional 3 buttons to be pressed simultaneously are integrated into one button.
 - The time to start compressor can be set by "▲ (forward)" button by 0 min., 1 min. or 3 min. later.

Select the desired operation mode to start operation.

- F. For humidifying hose length setting(*), refer to page 93.
- G. In forced humidifying drying mode, drying operation continues for approx. 30 min. for service.
- Start this operation after removing all moisture inside the hose.
- During forced drying operation, cooling, heating or dehumidifying operation is unavailable.
- H. Humidifying air flow rate fine adjusting mode allows to fine-tune the speed of the humidification fan around ± 10 % relative to AUTO. If you want to increase the air flow rate, set to [H], and to decrease the air flow rate, set to [L].

2.27 Thermostat Control

Outline

When COOLING or HEATING mode is selected with the remote controller, the micro computer prevents the unit from turning OFF until the requested room temperature could be obtained.


Detail

In the table below you can find the thermostat ON and OFF conditions for a set point of 21°C.

		OFF	ON	Monitor	ing
Cooling	Set point temperature 21°C> shift 0.5°C	19.5°C	21°C	20~20.5°C	10min
Heating	Set point temperature 21°C> shift 2.0°C	24.5°C	23°C	23.5~24°C	10sec

Cooling operation:

The unit will turn OFF by thermostat when the room temperature reaches 19.5°C. When the room temperature rises above 21°C, the thermostat turns back ON and the unit resumes its operation. When the room temperature is between 20 <=> 20.5°C, it is in the monitoring zone. If for cooling, the room temperature stays in the monitoring zone for more then 10 min, the thermostat will also turn back ON and the unit will resumes its operation.



Between the indoor unit and the position of the end user, there is taken into calculation a temperature shift of 0.5°C. This means that at thermostat OFF, the temperature at the end user is e.g. 20°C.

Heating operation:

The unit will turn ON by thermostat when the room temperature reaches its set value + a shift of 2.0°C (e.g. room temperature = 21°C => thermostat ON temperature = 23°C). When the room temperature rises above 24.5°C , the thermostat turns back OFF. When the room temperature is between $24 \iff 23.5^{\circ}\text{C}$, it is in the monitoring zone. If for heating, the room temperature stays in the monitoring zone for more then 10 sec, the thermostat will also turn back ON and the unit will resumes its operation.

2.28 Fan Speed Control for Indoor Units

Control mode

The airflow can be automatically controlled depending on the difference between the set temperature and the room temperature. This is done through speed control and Hall IC control.

Phase steps

Speed control and fan speed control contains different steps:

Step Cooling Heating Dry mode LLL LL SL (Silent) 28 · 42 · 50kW class : ML 1000 rpm No powerful Μ MΗ Н (R4085) HH (Powerful)

- = Within this range the airflow rate is automatically controlled when the FAN setting button is set to automatic.
- 1. During powerful operation, fan rotates at H tap + 80 rpm.
- 2. Fan stops during defrost operation.
- In time of thermostat OFF, the fan rotates at the following speed.
 Cooling: The fan keeps rotating at the set tap.
 Heating: The fan stops.

28 class	LLL	LL	SL	L	ML	М	HM	Ι	HH
Cooling		590	720	790	890	990	1090	1190	1270
Heating	350	590	790	860	970	1080	1190	1300	1380


42 class	LLL	LL	SL	L	ML	М	HM	Η	HH
Cooling		590	750	820	940	1060	1180	1300	1380
Heating	350	590	820	890	1000	1110	1220	1340	1420

50 class	LLL	LL	SL	L	ML	М	НМ	Н	HH
Cooling		590	790	860	990	1120	1250	1380	1460
Heating	350	590	860	950	1070	1190	1310	1440	1520

In the above table you can see all the different fan speeds of the indoor units fan motor.

When selecting AUTOMATIC air flow control on the remote controller, the indoor fan speed will be regulated according to the difference between the room temperature and the required set point on cooling mode. On heating mode, the indoor fan speed will be regulated according to the indoor heat exchanger temperature and the difference between the room temperature and the required set point.


Cooling



Heating


Room		In	door heat ex	changer tem	nperature are	a	
temp.area	G	F	Е	D	С	В	Α
Α	OFF	OFF	OFF	OFF	OFF	OFF	OFF
В	MH	LM	LM	L	L	L	2L
С	MH	LM	LM	L	L	L	2L
D	MH	М	LM	LM	L	L	2L
Е	MH	М	М	LM	LM	L	2L
F	MH	MH	М	М	LM	L	2L
G	MH	MH	MH	М	LM	L	2L
Н	MH	MH	MH	MH	М	L	2L
I	MH	MH	MH	MH	М	L	2L
J	MH	MH	MH	MH	MH	L	2L
K	MH	MH	MH	MH	MH	L	2L
L	MH	MH	MH	MH	MH	L	2L

Room temperature area



The value will increases when the operation starts.

Indoor heat exchanger temperature area




2.29 Draft Prevention (HOT Start)

Outline


Draft prevention control is done to prevent a cold draft feeling when the unit is started up in heating operation. This will happen if the indoor coil temperature drops.

Detail

The outdoor unit will prevent a cold draft by monitoring the indoor heat-exchanger thermistor. It will increase the minimum compressor frequency if the indoor heat exchanger drops below 33°C. If the coil is not hot enough, the indoor fan will not be started at the set speed.



The fan speed will be released step by step. The limitation of the fan speed will be lifted when the indoor heat exchanger temperature rises above $F^{\circ}C$.



	А	В	С	D	E	F
28 class	10	25	33	34	35	36
42 class	10	25	35	37	38	39
50 class	10	25	35	37	38	39

3. Control Specification

3.1 Frequency Control

Outline

Once the timers of the compressor start-up have elapsed, the unit will determine its compressor frequency out of the following parameters;

- 1. ΔD : The difference between the room temperature and the set-point.
- 2. Td: The discharge temperature.

Indoor frequency command

The indoor command frequency is determined by the difference between the room temperature, and the temperature set by the remote controller. Out of this difference a ΔD value (D from difference) is calculated which is then send to the outdoor unit.

Underneath you'll find a table, which relates the different ΔD values to the temperature differences.

Temperature difference	ΔD signal	Temperature difference	ΔD signal	Temperature difference	ΔD signal	Temperature difference	∆D signal
0	*Th OFF	2.0	4	4.0	8	6.0	С
0.5	1	2.5	5	4.5	9	6.5	D
1.0	2	3.0	6	5.0	Α	7.0	Е
1.5	3	3.5	7	5.5	В	7.5	F

*Th OFF = Thermostat OFF Table: ΔD value summary table

Initial frequency setting

When starting the compressor, the frequency must be (re-) initialized in accordance to the ΔD value. Out of this parameters, the micro-controller will determine the initial compressor frequency.

The frequency changes because of the decreasing ΔD values of the indoor units. The frequency will also be changed through limiting functions, which are protecting the unit. Some of these directly control the operating frequency.

Other functions will change the upper or lower frequency limit, preventing the unit from going into a certain operation frequency that will damage it.

PI Control

The PI control will ensure a fast and efficient way of determining the compressor frequency build up.

Detail

I control

This regulator will look at the temperature difference between the room temperature and the set point (ΔD).

- $\Delta D > 4$ then the compressor frequency will rise with ΔD Hz per 120 sec.
- $\Delta D = 4$ then there is no change.
- ΔD < 4 then the compressor frequency will drop with 4 Hz per 120 sec.

P control

This regulator will look at the differences between the room temperatures and the set points (ΔD) in time.

Compare the current ΔD and the last ΔD (20 seconds before). If any change is observed, correct the value calculated by the following formula.

• $(\Delta D \text{ currently - } \Delta D \text{ last measurement }) \times 4$

3.2 Preheating Operation (Quick Warming Function)

Outline

Operate the inverter in the open phase operation with the conditions including the preheating command from the discharge pipe temperature.

Detail

On condition

The preheating operation starts when the discharge pipe temperature drops below 10°C. At that time, the inverter in open phase operation starts. This means that a small current is send through one of the compressor windings in order to heat up the inside of the compressor. This is done in order to prevent liquid compression at start up of the compressor when the outdoor temperature is low.

OFF condition

When the discharge temperature is higher than 12°C, the inverter in open phase operation stops.


This function is applicable for cooling only as for heat pump units.

The inverter in open phase control consumes approximately 25~40W.


Note

When the preheating operation is active, there is the possibility that a frequency noise can be noticed at the outdoor unit site due to the open phase control.

outdoor temperature ≥ 7°C



outdoor temperature < 7°C



3.3 Four-way Valve Operation

Outline

Because the four-way valve only operates properly when there is an adequate pressure difference, the four-way valve compensation function has been implemented to insure this minimal pressure difference.

Detail

The four-way valve compensation function insures a good four-way valve operation by demanding a certain minimal operation frequency for a certain time. By doing this, the unit is ensuring the switching of the four-way valve.

When this function is enabled, the unit will not look at the other safeties (with the exception of input current control).

The four-way valve function compensation is engaged in four cases

- When starting the compressor for heating.
- When the operation mode is changed.
- When starting the compressor for defrosting.
- When starting the compressor after a power failure (auto-restart).

No power to the valve --> cooling. Power to the valve --> heating.

		Frequency [Hz]	Time [sec]
Cooling		52	
Heating	outdoor temperature < 16°C	52	60
	outdoor temperature ≥ 16°C	- 0.9 x outdoor temperature + 68	1

3.4 Compressor Start up Protection

Detail

The gradual build-up of the upper operation frequency is illustrated in the graph below.




Fig. : Compressor protection function graph.

Timers and frequencies for the compressor protection function

	RXR(28-50)		
	Cooling	Heating	
FCG1	52	48	
FCG2	54	58	
FCG3	78	80	
FCG4	98	98	
TCG1	220	220	
TCG2	140	140	
TCG3	60	60	
TCG4	60	60	

3.5 Fan Speed Control for Outdoor Unit

Outline


The fan speed control regulates the speed of the outdoor fan.

Detail

Fan control is carried out according to the following conditions.

- 1. Fan ON control for electric component cooling fan
- 2. Fan control when defrosting
- 3. Fan OFF delay when stopped
- 4. ON/OFF control when cooling operation
- 5. Fan control during heating operation

Cooling



Class	Cooling
28	800rpm
42	850rpm
50	850rpm

The fan speed is fixed.

Heating

Class	Heating
28	750rpm
42	760rpm
50	810rpm


The fan speed is fixed.

3.6 Fin Thermistor Control

Outline

This function is only applicable for inverters. The temperature sensor is located on the top of the radiation fins connected to the power elements of the electronic inverter circuit (PAM & PWM).

Detail




Step down area:

The frequency decreases with 2 Hz every 15 seconds.

3.7 Input Current Control


Detail



Class	Cooling			Heating			
Class	28	42	50	28	42	50	
I1 (A)	14	14	14	14	14	14	
I2 (A)	5.5	7.5	10.0	10.5	10.5	10.5	
13	4.5	6.5	9.0	9.5	9.5	9.5	

Stop zone

• After 5 seconds in this zone the compressor is stopped



Step down zone

- The maximum limit of the compressor frequency in this control is defined as operation frequency - 2 Hz.
- After this, the output frequency is pulled down by 2 Hz every second until it reaches the steady zone.

Steady zone

• Keeping the present maximum frequency.

Return zone

Limit of the frequency is cancelled.

3.8 Peak-cut Control

Outline

In heating operation, malfunctioning of the unit (for example dirty filters) can cause the discharge pressure to rise excessively and reach unacceptable levels. To avoid this, peak-cut control will monitor the condensing temperature and when necessary decrease the operating frequency in an attempt to lower the discharge pressure at an early stage.

Detail

In a similar way as with the freeze protection function, the peak-cut control function regulates the maximum operation frequency as indicated in the picture underneath.




Fig. : Peak-cut control function graph

When recovering from a total stop (return area):

• Frequency settings remain unchanged.

Up-area:

• The maximum frequency increases with approximately 2Hz every 2 minute.

Steady area:

• The maximum frequency remains constant.

Step down area:

• The maximum frequency decreases with approximately 4Hz every 20sec.

Stop area:

• The compressor, indoor fan and outdoor fan will stop.


3.9 Indoor Coil Freeze-up Protection

Outline

During cooling or dry operation, a malfunction of the unit may cause the indoor heat exchanger's temperature to drop excessively. To prevent the indoor heat exchanger from freezing up, the freeze protection function will reduce the compressor's maximum operation frequency.

Detail

The freeze protection function regulates the maximum operation frequency as indicated in the picture underneath.



When recovering from a total stop (return area):

• Frequency settings remain unchanged.

Up-area:

• The maximum frequency increases with approximately 2Hz every 90 seconds.

Steady area:

The maximum frequency remains constant.

Step down area:

• The maximum frequency decreases with approximately 2Hz every minute.

Stop area:

 The compressor stops completely and the outdoor unit fan will stop. The indoor unit fan operates at 590 rpm. The system will stay OFF until the indoor heat exchanger temperature goes to the reset zone. (13°C)

3.10 Dew Prevention

Outline

Cooling the air around us means that the air is dehumidified (condensation of water on the coil). But because the air is cooled down, less water can be absorbed by the air and as a consequence the relative humidity of the air rises. When the relative humidity of the outlet air nears 100%, you will have water being blown in. To prevent this from happening, the unit will, under certain circumstances, change its target evaporating temperature and the frequency of the compressor. Normally speaking, even under these conditions (dew prevention safety active), the room should still be cooled down, only slower. Of course, if the indoor unit is rather on the small size in comparison to the heat load, this will not be the case and capacity shortage complaints will follow.

Detail

1. Conditions for initiating the dew prevention function.

- ①Operation mode is in cooling/dry.
- ②Compressor is running.
- When the temperature of indoor heat exchanger is lower than the target temperature of heat exchanger, the compressor frequency will be pulled down by 2 Hz in every minute.
- The target temperature of heat exchanger is calculated by the following formula with using the room temperature and indoor humidity.

Target temp. of heat exchanger = 0.94 x room temp. + 0.27 x indoor humidity - 32.5

2. Conditions for ending the dew prevention function

- ①Operation mode is not in cooling/dry.
- ②Compressor is not running.

3.11 Liquid Compression Protection 2

Outline

The function will ensure a pressure differential between the high pressure and the low pressure. This is required when cooling with low outdoor ambient temperature because HP gets weak and you will have small capacity and a high power input.

The compressor stops according to the conditions of the outdoor ambient temperature and the outdoor heat exchanger temperature.

Details

Outdoor ambient temperature and outdoor heat exchanger temperature

- Cooling or Dry mode
- · Compressor on
- Outdoor ambient < 10°C
- Outdoor heat exchanger < 17°C

If all of these are fulfilled for 11 minutes, the compressor is stopped, the system is reset and restarted after 3 minutes.

Outdoor ambient temperature only

- Cooling or Dry mode
- Not in forced cooling mode
- Outdoor ambient < 0°C

If all of these are fulfilled , the compressor is stopped, the system resumes operation when the outdoor ambient temperature rises above 0° C.


3.12 Discharge Pipe Temperature Control

Outline

Overheating has a negative influence on the operating lifetime of a compressor. That's why this function will limit the maximum operating frequency of the compressor if deemed necessary.


Detail

Discharge pipe temperature (°C)




Correction value (a) = correction value by operation frequency (b) +correction value by outdoor temperature (c)

Correction value by operation frequency (b)



Correction value by outdoor temperature (c)



When recovering from a total stop (return area):

Frequency settings remain unchanged.

Up-area:

• The maximum frequency increases with 2Hz / 60 seconds

Steady area:

Present frequency is maximum frequency.

Step down area:


• The maximum frequency decreases with 4Hz per 30 seconds.

Stop area:

 The compressor stops and will only restart when the sensor senses a temperature below set point.

3.13 Automatic Defrosting

Defrost Control Start Condition



 \triangle is calculated by the following formula:

 $_{\triangle}=-17/256\times$ compressor operation frequency + 43/64 × outside air temperature - 6 However, when the calculated value is less than the lower limit indicated in the table below, the lower limit is adopted as $_{\triangle}$.

Outside air temperature condition	Lower limit
-4°C ≤ outdoor air temp	−15°C
-10°C ≤ outdoor air temp. < -4°C	−20°C
outdoor air temp. < −10°C	−22°C

Operation during Defrosting and Termination Condition


- Operation should be conducted at 64Hz during defrosting.
- Defrosting operation must be conducted for 2 minutes, and after that, defrosting operation is conducted until the outdoor heat exchanger temperature reaches the defrost cancellation temperature at B°C.
- After the temperature has reached the defrost cancellation temperature, the defrosting should be terminated.

 $\ensuremath{\mathbb{B}}$ is calculated by the following formula:

 $\mathbb{B} = 18 - 22/64 \times \text{outside air temperature}$

However, when the calculated value is outside the range between 6°C and 22°C, if it is less than 6°C, 6 should be adopted and if it is more than 22°C, 22 is adopted, as the defrost cancellation temperature.

Defrosting Time Chart



3.14 Electronic Expansion Valve Control

Outline

The following items are included in the electronic expansion valve control.

Electronic expansion valve is fully closed

- Electronic expansion valve is fully closed when turning on the power.
- Pressure equalizing control

Open Control

- Electronic expansion valve control when starting operation
- Control when frequency changed
- Control for defrosting (only for heat pump model)
- Control when a discharge pipe temperature is abnormally high
- Control when the discharge pipe thermistor is disconnected

Feedback Control

- Discharge pipe temperature control
- Maximum electronic expansion valve opening: 470 pulses
- Minimum electronic expansion valve opening: 52 pulses

Detail

The gray squares indicate which secondary functions are active or can be activated.

Operation pattern	Main operation control	Control when frequency is changed	Control for abnormally high discharge temperature
Power ON	Power initialization control	×	×
Cooling 1 room	Control when starting	×	0
operation	Control of target discharge temp.	0	0
Stop	Pressure equalization control	×	×
Heating 1 room	Control when starting	×	0
operation	Control of target discharge temp.	0	0
Stop	Pressure equalization control	×	×
Heating operation discharge sensor disconnected	Control when starting	0	
	Control of target discharge temp.	×	×
Stop	pressure equalization control	×	×

3.14.1 Power Initialization Control

Outline

When turning on the power to the unit, the expansion valve is initialized to a certain starting position.

Detail

At initialization the following steps are executed.

- The electronic expansion valve is closed by 700 pulses (to make sure it is closed shut).
- After closing the valve, it is opened again by 400 pulses.

3.14.2 Control when Starting

Outline

Obviously when the unit is switched on, some adjustments to the expansion valve opening have to be made in order to prevent excessive heating or moisture.

Cooling

 $EV = Kevopf x \Delta Fcom+ Kevopdce x DA+ Kevopdoa x DOA+ P5$

Heating

In 2 min. from the operation starts.

 $EV = K_{evopf} \times \Delta F_{com} + P_5$

After 2 min. from the operation starts.

Doa ≤ doaopf	$EV = Kevopf \ x \Delta F_{com} + P_5$
$d_{oaopf} < D_{OA} \le d_{oaopf} + dd_{oaopf}$	$EV = K_{evopf} \times \Delta F_{com} + P_{5} + K_{evopdoa} \times (Doa - doaopf)$
doaopf + ddoaopf < DOA	$EV = K_{evopf} \times \Delta F_{com} + P_{5} + K_{evopdoa} \times dd_{oaopf}$

Ending Condition

After 6 minutes from the time compressor starts.

or

Discharge temperature +6 > condensation temperature > 36°C

Kevopf
 P5
 A constant depending on the outdoor unit type
 Kevopdce
 Kevopdoa
 A constant depending on the outdoor unit type.
 Kevopdoa
 A constant depending on the outdoor unit type.

 $\begin{array}{ll} \text{doaopf} & : A \text{ constant} \\ \text{ddoaopf} & : A \text{ constant} \end{array}$

 $\begin{array}{lll} \mathsf{DA} & : \mathsf{The}\;\mathsf{room}\;\mathsf{temperature}. \\ \mathsf{DOA} & : \mathsf{The}\;\mathsf{outdoor}\;\mathsf{temperature}. \\ \Delta \mathsf{F}_\mathsf{com} & : \mathsf{Compressor}\;\mathsf{frequency}\;\mathsf{change}. \end{array}$

3.14.3 Control when Frequency is Changed

Outline

Because the operation frequency is one of the variables in the calculation of the original opening of the expansion valve, the opening will have to be recalculated when the operation frequency is changed. During this recalculation, the target discharge temperature control will be deactivated.

Detail

This control will engage when the operation frequency is changed during the target discharge temperature control. When this happens, a 10 seconds timer is set. Once this timer expires, the expansion valve opening is recalculated using the formulas below:

PHNHZ = PHNHZZ + KEVOPF x (FMK - FMKZ)

Where:

PHNHZZ = expansion valve opening before change

PHNHZ = expansion valve opening after change

KEVOPF = constant value (cooling:2.7, heating:2.0)

FMK = operation frequency after change

FMKZ = operation frequency before change

The expansion valve opening is only changed when FMK - FMKZ > 4.

3.14.4 Target Discharge Pipe Temperature Control

Outline

Superheat (SH) is required to insure that only gas and not liquid is sucked up by the compressor. Because of the direct link between the SH and the discharge temperature (see Fig. target discharge temperature), a control on the discharge temperature was made to be one of the main control systems of Daikin air-conditioners. The discharge temperature and SH are regulated by the expansion valve.




Fig.: Target discharge pipe temperature control graph

Detail

The adjustment to the expansion valve opening is determined by the difference between the actual discharge temperature and the target discharge temperature.

Starting conditions for this operation are:

- The starting control and the 'operation room change' control (only for multi system) are inactive.
- The frequency changing control, high discharge temperature control and disconnected discharge thermistor control are inactive
- The defrost operation is inactive
- · The compressor is active

Target discharge temperature = α cond. temp. - β evap. temp. + γ

 $\alpha,\!\beta,\!\gamma$; predetermined constants related to different model types.

Discharge temp > target discharge temp, exp. valve will open. Discharge temp < target discharge temp, exp. valve will close.

The target superheat (SH) will be 5° C ~ 7° C in cooling operation and 0° C in heating operation. The discharge superheat always have to be larger then 10° C. Otherwise the unit will have liquid compression. (depends on compressor type)

3.14.5 Pressure Equalization Control

Outline

The pressure difference between the condenser and evaporator works as an extra load when restarting the compressor. To limit the load on the compressor when restarting it and consequently limit the starting current, a pressure-equalization is performed after deactivating the compressor. Pressure equalization is achieved by opening the expansion valve to a certain level and then closing it again.

Detail

As soon as the compressor is stopped due to an OFF command, the motorized valve is controlled as follows.




Fig.: Pressure equalization control graph in cooling mode

	A
OFF command by remote controller, mode change	24
Thermostat OFF	0

3.14.6 Control for Abnormally High Discharge Temperature

Outline

An abnormally high discharge temperature is an indication for a too high suction temperature or super-heat. Making adjustments to the expansion valve opening can solve this problem.

Detail

Increasing the expansion valve opening will increase the refrigerant flow through the evaporator and decrease the superheat and the discharge temperature.

The unit is operating in the 'dropping zone' when all the following conditions are met:

- The compressor is operating
- the discharge temperature exceeds A°C

The unit is operating in the 'reset zone' when one of the following conditions are met:

- The compressor has stopped
- the discharge temperature is below B°C

A = 104 - correction value (a) B = 100 - correction value (a)

For the correction value (a), refer to the Page72 "High Discharge Pipe Temperature Control".




Fig.: Abnormal high discharge temperature control graph

In the dropping zone the unit will react as follows:

- Prohibit the discharge pipe temperature control
- When entering the dropping zone from the reset zone, it will add 20 pulses the expansion valve opening and set a 30 seconds 'opening adjustment timer'.
- Each time the opening adjustment timer reaches zero without leaving the dropping zone, 20
 pulses will be added to the expansion valve opening and the opening adjustment timer will
 be reset.

Part 5 System Configuration

٦.	Insta	llation Manual	82
	1.1	Indoor Units	82
		Outdoor Units	
2.	Syste	em Configuration	.106
3.	Instru	uction	.107
	3.1	Safety Precautions	.107
	3.2	Names and Functions of Parts	.108
	3.3	Preparation before Operation	.110
		Cooling · "SARARA" DRYING Operation	
	3.5	Heating · "URURU" HUMIDIFYING Operation	.113
	3.6	AUTO / MOISTURIZING Operation	.114
	3.7	Adjusting Airflow Direction \cdot Comfort Airflow Mode \cdot Cooling Breeze \cdot	
		Airflow Rate	.115
	3.8	FLASH STREAMER AIR PURIFYING · FRESH AIR SUPPLY	
		VENTILATION Operation / HOME LEAVE VENTILATION	.116
		TIMER Operation	
	3.10	COMFORT SLEEP / POWERFUL Operation	.118
	3.11	SET UP	.119
	3.12	MOLD PROOF Operation	.120
		MOLD SHOCK Operation / INFORMATION DISPLAY	
	3.14	Care and Cleaning	.122
	3.15	Troubleshooting	.130

1. Installation Manual

1.1 Indoor Units

Safety Precautions

- Read these Safety Precautions carefully to ensure correct installation.
- This manual classifies the precautions into WARNING and CAUTION.
 Be sure to follow all the precautions below: they are all important for ensuring safety.

WARNING......Failure to follow any of WARNING is likely to result in such grave consequences as death or serious injury.

↑ CAUTION.....Failure to follow any of CAUTION may result in grave consequences in some cases.

• The following safety symbols are used throughout this manual:

Be sure to observe this instruction.

Be sure to establish an earth connection.



After completing installation, test the unit to check for installation errors. Give the user adequate instructions concerning the use and cleaning of the unit
according to the Operation Manual.

№ WARNING

- Installation should be left to the dealer or another professional.
 Improper installation may cause water leakage, electrical shock, or fire.
- Install the air conditioner according to the instructions given in this manual.
 Incomplete installation may cause water leakage, electrical shock, or fire.
- Be sure to use the supplied or specified installation parts.

Use of other parts may cause the unit to come to lose, water leakage, electrical shock, or fire

- Install the air conditioner on a solid base that can support the weight of the unit.
 An inadequate base or incomplete installation may cause injury in the event the unit falls off the base.
- Electrical work should be carried out in accordance with the installation manual and the national electrical wiring rules or code of practice. Insufficient capacity or incomplete electrical work may cause electrical shock or fire.
- · Be sure to use a dedicated power circuit. Never use a power supply shared by another appliance.
- For wiring, use a cable length enough to cover the entire distance with no connection.
 Do not use an extension cord. Do not put other loads on the power supply, use a dedicated power circuit.
 (Failure to do so may cause abnormal heat, electric shock or fire.)
- Use the specified types of wires for electrical connections between the indoor and outdoor units.
 Firmly clamp the interconnecting wires so their terminals receive no external stresses. Incomplete connections or clamping may cause terminal overheating or fire.
- After connecting interconnecting and supply wiring be sure to shape the cables so that they do not put undue force
 on the electrical covers or panels.

Install covers over the wires. Incomplete cover installation may cause terminal overheating, electrical shock, or fire.

If any refrigerant has leaked out during the installation work, ventilate the room.
 (The refrigerant produces a toxic gas if exposed to flames.)



After all installation is complete, check to make sure that no refrigerant is leaking out.
 (The refrigerant produces a toxic gas if exposed to flames.)



- When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), such as air.
- (Any presence of air or other foreign substance in the refrigerant circuit causes an abnormal pressure rise or rupture, resulting in injury.)
- During pump-down, stop the compressor before removing the refrigerant piping.
 If the compressor is still running and the shut-off valve is open during pump-down, air will be sucked in when the refrigerant piping is removed, causing abnormal pressure in the freezer cycle which will lead to breakage and even injury.
- During installation, attach the refrigerant piping securely before running the compressor.
 If the compressor is not attached and the shut-off valve is open during pump-down, air will be sucked in when the compressor is run, causing abnormal pressure in the freezer cycle which will lead to breakage and even injury.
- Be sure to establish an earth. Do not earth the unit to a utility pipe, arrester, or telephone earth.
 Incomplete earth may cause electrical shock, or fire. A high surge current from lightning or other sources may cause damage to the air conditioner.



Failure to install an earth leakage breaker may result in electric shocks, or fire.

⚠ CAUTION

• Do not install the air conditioner in a place where there is danger of exposure to inflammable gas leakage. If the gas leaks and builds up around the unit, it may catch fire.



- Establish drain piping according to the instructions of this manual.
 Inadequate piping may cause flooding.
- Note for installing the outdoor unit. (For heat pump model only.)
 In cold area where the outside air temperature keep below or around freezing-point for a few days, the outdoor unit's drain may freeze.
 If so, it is recommended to install an electric heater in order to protect drain from freezing.
- Tighten the flare nut according to the specified method such as with a torque wrench.
 If the flare nut is tightened too hard, the flare nut may crack after a long time and cause refrigerant leakage.

1

SiBE04-624 Installation Manual

Accessories

Mounting plate	1	Air supply filter frame	1	AAA dry-cell batteries	2
B Deodorizing filter for streamer	1	F) Indoor unit fixing screws (M4 × 12L)	3	(K) Operation manual	1
© Titanium apatite photocatalytic air-purifying filter	1	Wireless remote controller	1	(Installation manual	1
Air supply filter	1	(H) Remote controller holder	1		

Choosing an Installation Site

· Before choosing the installation site, obtain user approval.

1. Indoor unit.

- The indoor unit should be sited in a place where:
 - 1) the restrictions on installation specified in the indoor unit installation drawings are met,
 - 2) both air intake and exhaust have clear paths met,
 - 3) the unit is not in the path of direct sunlight,
 - 4) the unit is away from the source of heat or steam,
 - 5) there is no source of machine oil vapour (this may shorten indoor unit life),
 - 6) cool (warm) air is circulated throughout the room,
 - 7) the unit is away from electronic ignition type fluorescent lamps (inverter or rapid start type) as they may shorten the remote control range,
 - 8) the unit is at least 1 metre away from any television or radio set (unit may cause interference with the picture or sound),
- 9) install at the recommended height (1.8m).

2. Wireless remote controller.

1) Turn on all the fluorescent lamps in the room, if any, and find the site where remote control signals are properly received by the indoor unit (within 7 metres).

Indoor Unit Installation Drawings

1. Precautions for humidifying hose installation work.

- When embedding humidifying hose:
 - 1) Cannot be installed to the existing embedded piping. Embedding work is separately necessary.
- · The length of the humidifying hose is marked on the hose packing material.
 - 1) Use an extension hose (sold separately) when extending the humidifying hose.
- 2) The length of the humidifying hose needs to be set to ensure humidifying capacity. Cut off any excess hose. Use the remote controller to set the hose length. (Refer to page 12.)
- If the humidifying hose needs to be cut to be laid, cut it, lay it, and connect it using the joint or elbow included with the
 outdoor unit. When doing this, wrap it to prevent air leaks with the binding band included with the outdoor unit.
 (Refer to page 9.)
- When laying the humidifying hose inside the wall, block the ends of the humidifying hose with tape or the like to prevent water or anything else from entering it until it is connected to the indoor unit and outdoor unit ducts.
- $\bullet\,$ Do not bend the humidifying hose more than 90°.

2

Indoor Unit Installation Drawings


2. Removing and installing indoor unit.


Installation method

- Using the △ marks (3 locations) on top of the indoor unit, attach the ⓐ mounting plate hooks onto the indoor unit.
- Attach the tabs on the bottom frame onto the
 mounting plate. If the tabs are not hooked onto the plate, remove the front grille to hook them.
 (Check to see if the tabs are hooked securely.)

Removal method

Push up the mark part on the bottom of the front grille, discharge the tabs, and then remove the unit while lifting it up.





3

SiBE04-624 Installation Manual

Installation Tips

1. Removing and installing front panel.


Removal method

- 1) Open the front panel.
- 2) Spread out the shaft hole on the left side and remove the rotating shaft.
 - Spread out the shaft hole on the right side as well and remove the rotating shaft.

· Installation method

Insert the right and left rotating shafts on the front panel into the shaft holes one at a time and slowly close the panel.

(Press on both sides of the front panel.)




2. Removing and installing the upper panel.

Removal method

- 1) Remove the front panel and air filter.
- Hold and pull forward 2 tabs on both sides to discharge them, discharge the center tab, and then lift up the upper panel.

Installation method

- Push in the upper panel along the guide on the top of the front grille and insert the 3 tabs into the slots on the front grille.
- 2) Push the upper panel down until it clicks.
- 3) Attach the air filter and front panel.



4

Installation Tips


3. Removing and installing the front grille.

· Removal method

- 1) Remove the front panel, air filter and upper panel.
- 2) Fully open the top and bottom horizontal louvers. (See Fig. 1)
- 3) Remove the 3 screws in the front grille.
- Lift the hooks (3 locations) on the front grille with a flathead screwdriver to discharge the tab. (Look for the OOO mark.) (See Fig. 2)
- 5) Pull forward the front grille to remove.

· Installation method

- 1) Open the top louver fully and close the bottom louver fully.
- 2) Store the gear case arm in the front grille. (See Fig. 3)
- 3) Attach the front grille to the lower part of the unit. (Use caution not to pinch the horizontal louver.)
- 4) Make sure to firmly latch the top hooks (3 locations).
- 5) Tighten with the 3 front grille screws.
- 6) Attach the upper panel, air filter and front panel.







Fig. 3 Gear case arm



Be sure to store the gear case arm before attaching the front grille.


4. Installing the air supply filter.


- 1) Open the front panel to remove the left air filter.
- 2) Set the ① air supply filter to the ② air supply filter
- 3) Attach the © air supply filter frame.
- 4) Replace the left air filter to its original position and close the front panel.



5. Installing the titanium apatite photocatalytic air-purifying filter and deodorizing filter for streamer.

- 1) Open the front panel to pull out the air filter.
- 2) Attach the © titanium apatite photocatalytic airpurifying filter.
- 3) Attach the ® deodorizing filter for streamer.
- Replace the air filter to its original position and close the front panel.






5

SiBE04-624 Installation Manual

6. How to replace the drain plug and drain hose.


- · Replacing onto the left side
 - 1) Remove the insulation fixing screws on the right to remove the drain hose.
 - Reattach the insulation fixing screw on the right as it was.
 - *(Forgetting to attach this may cause water leakages.)
 - 3) Remove the drain plug on the left side and attach it to the right side.
 - 4) Insert the drain hose and tighten with includedf) indoor unit fixing screw.






7. How to set the different addresses.

- When 2 indoor units are installed in one room, the 2 wireless remote controllers can be set for different addresses.
 - 1) Remove the front grille. (3 screws)
 - 2) Cut the address jumper "JA". (See Fig. 1)
 - 3) Remove the remote controller lid and cut the address jumper "J4". (See Fig. 2)






6

Indoor Unit Installation

1. Installing the mounting plate.

- The (A) mounting plate should be installed on a wall which can support the weight of the indoor unit.
 - 1) Temporarily secure the (a) mounting plate to the wall, make sure that the panel is completely level, and mark the boring points on the wall.
 - 2) Secure the (A) mounting plate to the wall with screws.

Recommended mounting plate retention spots and Dimensions



2. Boring a wall hole and installing wall embedded pipe.


- For walls containing metal frame or metal board, be sure to use a wall
 embedded pipe and wall cover in the feed-through hole to prevent possible
 heat, electrical shock, or fire.
- Be sure to caulk the gaps around the pipes with caulking material to prevent water leakage.
 - 1) Bore a feed-through hole of 70mm in the wall so it has a down slope toward the outside.
 - 2) Insert a wall pipe into the hole.
 - 3) Insert a wall cover into wall pipe.
 - 4) After completing refrigerant piping, wiring, and drain piping, caulk pipe hole gap with putty.

Wall embedded pipe (Field supply) Wall hole cover (Field supply) Wall embedded pipe (Field supply)

3. Installing inter-unit wiring.

- 1) Open the front panel and remove the service lid.
- Pull out the inter-unit wiring from the back of the indoor unit to the front. It is easier to pull out if bending up the wire edge in advance.
- 3) To connect the inter-unit wiring after hooking the unit onto the

 mounting plate, connect the inter-unit wiring as shown in the figure at right.




7


SiBE04-624 Installation Manual

4. Laying piping, hoses, and wiring.

- Connect the humidifying hose to the indoor unit duct.
 See 5. Humidifying hose installation work for details.
- Lay the piping, drain hose and humidifying hose according to the orientation of the piping coming out of the unit, as shown below.
- Make sure the drain hose is sloped downward.
- Wrap the piping, drain hose and humidifying hose together using insulation tape.




4-1. Right-side, right-back, or right-bottom piping.




- 1) Wrap the piping, hose and inter-unit wiring using insulation tape as shown in the piping bundle diagram.
- 2) Put all the pipes through the through-hole in the wall and hook the indoor unit onto the (A) mounting plate.
- 3) Connect the pipes.

4-2. Left-side, left-back, or left-bottom piping.



- Replace the drain plug and drain hose. (How to replace the drain plug and drain hose.)
- 2) Pull in the refrigerant piping and lay it so that it matches the liquid and gas piping marked on the (a) mounting plate.
- 3) Hook the indoor unit onto the (A) mounting plate.
- 4) Connect the pipes. If it is difficult to do, remove the front panel first.
- 5) Wrap the insulation on the piping with insulation tape. If you are not replacing the drain hose, store it in the location shown below.

Left-bottom piping




When securing the indoor unit with screws

- 1) Remove the front grille.
- 2) Secure the indoor unit with the (F) indoor unit fixing screws.
- 3) Install the front grille.



4-3. Left-back piping.




Indoor Unit Installation

4-4. Wall embedded piping.

Follow the instructions given under

Left-side, left-back, or left-bottom piping

1) Insert the drain hose to this depth so it won't be pulled out of the drain pipe.




MARNING

Do not bundle the power code with a binding band, a twist tie or other method. This may cause heat, electric shock or fire.

5. Humidifying hose installation work.

5-1. Connecting to the indoor unit.


· Connect the cuff side of the humidifying hose to the indoor unit duct.



Left-back piping



(If it is too long, cut the humidifying hose and bond the separately sold cuff with adhesive for vinyl to adjust the length.)




⚠ CAUTION

Use caution not to deform the cuff while installing the humidifying hose.

5-2. Connecting the cut humidifying hoses.

When install the cut humidifying hoses, follow the instructions below.





Use not more than two elbows to ensure humidifying capacity.

SiBE04-624 Installation Manual

6. Wiring.

- 1) Strip wire ends (15mm).
- 2) Match wire colours with terminal numbers on indoor and outdoor unit's terminal blocks and firmly screw wires to the corresponding terminals.
- 3) Connect the earth wires to the corresponding terminals.
- 4) Pull wires to make sure that they are securely latched up, then retain wires with wire retainer.
- In case of connecting to an adapter system. Run the remote control cable and attach the S21. (Refer to 7. Connecting to the HA system.)
- 6) Shape the wires so that the service lid fits securely, then close service lid.





⚠ WARNING


- 1) Do not use tapped wires, strand wires, extensioncords, or starburst connections, as they may cause overheating, electrical shock, or fire.
- 2) Do not use locally purchased electrical parts inside the product. (Do not branch the power for the drain pump, etc., from the terminal block.) Doing so may cause electric shock or fire.

7. Connecting to the HA system.

- 1) Remove the front grille. (3 screws)
- Remove the decelerator assembly parts. (1 screw)
 - 2-1) Remove the decelerator assembly part screws. (See Fig. 1)
 - 2-2) Remove the decelerator assembly part connector. Remove by pressing on the tabs on the bottom of the connector.

(See the tab position diagram 1)


- 3) Remove the electric parts box.
 - (1 screw, 2 tabs)
 - 3-1) Remove the electric parts box fixing screw.
 - 3-2) Pull the electric parts box toward you and discharge the tab 2.




10

Indoor Unit Installation

- Remove the electric parts box cover.
 (3 tabs) (Refer to Fig. 2)
 - 4-1) Discharge the tab 3.
 - 4-2) Pull up the electric parts box cover slowly, discharge the tab 4, slide up, and discharge the tab 5.
- Insert the connection cord into the HA connector "S21".
- 6) Lay the connection cord as shown in "Fig. 3"
- 7) Replace the electric parts box cover and electric parts box as they were.
- 8) Attach the decelerator assembly part along with the guide rail. (Refer to Fig. 2)
- 9) Install the front grille.






8. Drain piping.

- 1) Connect the drain hose, as described right.
- 2) Remove the air filters and pour some water into the drain pan to check the water flows smoothly.
- When drain hose requires extension, obtain an extension hose commercially available.

Be sure to thermally insulate the indoor section of the extension hose.







9. Improving installation strength.

- We recommend screwing the indoor unit onto a

 \(\text{\text{a}} \) mounting plate in order to improve the installation strength.
- 1) Remove the front grille.
- 2) Screw in the indoor unit with (F) fixing screws.
- 3) Attach the front grille.





The drain hose should

No trap is permitted.

Do not put the end

n drain hose

11


SiBE04-624 Installation Manual

Setting the Humidifying Hose Length

1. Setting the humidifying hose length.

Set the humidifying hose length to ensure humidifying capacity. Use the remote controller to set the humidifying hose length. When doing this, power on the unit as communication is established between the unit and the remote controller.

(The humidifying hose length includes the rear of the indoor unit.)




1) Hold "CLOCK button" for more than 5 seconds. (To cancel, do not operate the button for 10 seconds. The display will return to

2) Press "SELECT ▲ button". Select "SETTING2, PIPE".


3) Press "CLOCK button" to activate the hose length setting mode. (Be sure to direct the remote controller toward the main unit while operating it.) The display will show the currently set hose length. (Default is no setting.)

4) Press "SELECT ▲ button" to set the humidifying hose length. Pressing "SELECT ▲ button" changes the hose length. You may set the hose length to 5 levels, ~3M, 3.1~4M, 4.1~6M, 6.1~8M, 8.1~10M.



6) Hold "CLOCK button" for more than 5 seconds. The humidifying hose length setting is complete.

If you set the wrong humidifying hose length, cancel the setting displaying



Matrix display













(10:00 a m)

2. When the unit cannot be powered on.

• When setting the humidifying hose length without powering on the unit, the display shows

PIPE LEN " with the step 5) operation shown above but the remote controller remembers the set hose length. UNDEF

(When the customer uses the unit, the humidifying hose length information is sent to the indoor unit to be set.)


12

Refrigerant Piping Work

1. Flaring the pipe end.

- 1) Cut the pipe end with a pipe cutter.
- 2) Remove burrs with the cut surface facing downward so that the chips do not enter the pipe.
- 3) Put the flare nut on the pipe.
- 4) Flare the pipe.
- 5) Check that the flaring is properly made.






№ WARNING

- 1) Do not use mineral oil on flared part.
- 2) Prevent mineral oil from getting into the system as this would reduce the lifetime of the units.
- 3) Never use piping which has been used for previous installations. Only use parts which are delivered with the unit.
- 4) Do never install a drier to this R410A unit in order to guarantee its lifetime.
- 5) The drying material may dissolve and damage the system.
- 6) Incomplete flaring may cause refrigerant gas leakage.

2. Refrigerant piping.

- Align the centres of both flares and tighten the flare nuts 3 or 4 turns by hand. Then tighten them fully with the torque wrenches.
 - Use torque wrenches when tightening the flare nuts to prevent damage to the flare nuts and escaping gas.
- To prevent gas leakage, apply refrigeration oil on both inner and outer surfaces of the flare. (Use refrigeration oil for R410A.)

Flare nut tightening torque			
Gas side	Liquid side		
3/8 inch	1/4 inch		
32.7-39.9N • m	14.2-17.2N • m		
(330-407kgf • cm)	(144-175kgf • cm)		



Be sure to

place a cap.

If no flare cap is

the flare mouth

2-1. Caution on piping handling.

- 1) Protect the open end of the pipe against dust and moisture.
- All pipe bends should be as gentle as possible. Use a pipe bender for bending.

(Bending radius should be 30 to 40mm or larger.)

2-2. Selection of copper and heat insulation materials.

- · When using commercial copper pipes and fittings, observe the following:
- 1) Insulation material: Polyethylene foam
 Heat transfer rate: 0.041 to 0.052W/mK (0.035 to 0.045 kcal/(mh•°C))
 Refrigerant gas pipe's surface temperature reaches 110°C max.
 Choose heat insulation materials that will withstand this temperature.

Finishing tape Inter-unit wiring

Gas pipe Drain hose

Gas pipe Inter-unit wiring

Humidifying hose

2) Be sure to insulate both the gas and liquid piping and to provide insulation dimensions as below.

Gas side	Liquid side	Gas pipe thermal insulation	Liquid pipe thermal insulation
O.D. 9.5mm	O.D. 6.4mm	I.D. 12-15mm	I.D. 8-10mm
Thickness 0.8mm		Thickness	10mm Min.

3) Use separate thermal insulation pipes for gas and liquid refrigerant pipes.

13

SiBE04-624 Installation Manual

Trial Operation and Testing

1. Trial operation and testing.

- 1-1. Measure the supply voltage and make sure that it falls in the specified range.
- 1-2. Trial operation should be carried out in either cooling or heating mode.
- In cooling mode, select the lowest programmable temperature; in heating mode, select the highest programmable temperature.
 - Trial operation may be disabled in either mode depending on the room temperature.
 Use the remote controller for trial operation as described below.
 - 2) After trial operation is complete, set the temperature to a normal level (26°C to 28°C in cooling mode, 20°C to 24°C in heating mode).
 - 3) For protection, the system disables restart operation for 3 minutes after it is turned off.
- 1-3. To perform a test run for humidifying operation, activate test run mode from the remote controller following the instructions below and press the "HUMIDIFY" button.
- 1-4. Operate the unit in accordance with the operation manual to check that it operates normally.
 - Even when the air conditioner is not operating, it consumes some electric power. If the customer is not going to use the unit soon after it is installed, turn off the breaker to avoid wasting electricity.

Trial operation from remote controller

- 1) Hold the "CLOCK" button for 5 seconds.
 - (The matrix display will appear on the remote controller.)
- 2) Display "SETTING on the matrix display of the remote controller and press the "CLOCK" button. 1. TEST
- 3) "7" will be displayed and the unit will enter test run mode.
- 4) Press the button for test run mode.
 - Test run mode will stop automatically after around 30 minutes.
 Press the ON/OFF button to force the test-run to stop.

2. Test items.

Test items	Symptom (diagnostic display on RC)	Check
Indoor and outdoor units are installed properly on solid bases.	Fall, vibration, noise	
Did you install the air supply filter?	Noise, water leakage	
id you install the deodorizing filter for the streamer and the titanium obtite photocatalytic air-purifying filter? Noise, water leakage		
Have you performed a gas leak test?	Incomplete cooling/heating function	
No refrigerant gas leaks.	Incomplete cooling/heating function	
Refrigerant gas and liquid pipes and indoor drain hose extension are hermally insulated. Water leakage		
Draining line is properly installed.	Water leakage	
Does the drain hose produce abnormal noise (perking sound) when using the ventilation fan or others?	Use of separately sold air cut drain plug.	
System is properly earthed.	Electrical leakage	
The specified wires are used for inter-unit wiring connections. Inoperative or burn dam		
loor or outdoor unit's air intake or exhaust has clear path of air. ut-off valves are opened. Incomplete cooling/heating function		
Indoor unit properly receives remote controller commands.	Inoperative	
Did you check the address setting?	Inoperative	
Did you set the humidifying hose length?	LED lamp blinks at power on. The buzzer sounds during a test run. Poor performance and noise	

14

3P177302-1

1.2 Outdoor Units

Safety Precautions

- · Read these Safety Precautions carefully to ensure correct installation.
- This manual classifies the precautions into WARNING and CAUTION.
 Be sure to follow all the precautions below: they are all important for ensuring safety.

MARNING......Failure to follow any of WARNING is likely to result in such grave consequences as death or serious injury.

↑ CAUTION.....Failure to follow any of CAUTION may result in grave consequences in some cases.

The following safety symbols are used throughout this manual:

Be sure to observe this instruction.

Be sure to establish an earth connection.

Never attempt.

 After completing installation, test the unit to check for installation errors. Give the user adequate instructions concerning the use and cleaning of the unit according to the Operation Manual.

∱ WARNING

- Installation should be left to the dealer or another professional.
 Improper installation may cause water leakage, electrical shock, or fire.
- Install the air conditioner according to the instructions given in this manual.
 Incomplete installation may cause water leakage, electrical shock, or fire.
- Be sure to use the supplied or specified installation parts.
 Use of other parts may cause the unit to come to lose, water leakage, electrical shock, or fire.
- Install the air conditioner on a solid base that can support the weight of the unit.
 An inadequate base or incomplete installation may cause injury in the event the unit falls off the base
- Electrical work should be carried out in accordance with the installation manual and the national electrical wiring rules or code of practice. Insufficient capacity or incomplete electrical work may cause electrical shock or fire.
- · Be sure to use a dedicated power circuit. Never use a power supply shared by another appliance.
- For wiring, use a cable length enough to cover the entire distance with no connection.
 Do not use an extension cord. Do not put other loads on the power supply, use a dedicated power circuit.
 (Failure to do so may cause abnormal heat, electric shock or fire.)
- Use the specified types of wires for electrical connections between the indoor and outdoor units. Firmly clamp the interconnecting wires so their terminals receive no external stresses. Incomplete connections or clamping may cause terminal overheating or fire.
- After connecting interconnecting and supply wiring be sure to shape the cables so that they do not put undue force on the electrical covers or panels. Install covers over the wires. Incomplete cover installation may cause terminal overheating, electrical shock, or fire.
- If any refrigerant has leaked out during the installation work, ventilate the room.
 (The refrigerant produces a toxic gas if exposed to flames.)

0

After all installation is complete, check to make sure that no refrigerant is leaking out.
 (The refrigerant produces a toxic gas if exposed to flames.)

0

- When installing or relocating the system, be sure to keep the refrigerant circuit free from substances other than the specified refrigerant (R410A), such as air.
 (Any presence of air or other foreign substance in the refrigerant circuit causes an abnormal pressure rise or rupture, resulting in injury.)
- During pump-down, stop the compressor before removing the refrigerant piping.
 If the compressor is still running and the stop valve is open during pump-down, air will be sucked in when the refrigerant piping is removed,
- causing abnormal pressure in the freezer cycle which will lead to breakage and even injury.
 During installation, attach the refrigerant piping securely before running the compressor.
 If the compressor is not attached and the stop valve is open during pump-down, air will be sucked in when the compressor is run, causing
- abnormal pressure in the freezer cycle which will lead to breakage and even injury.

 Be sure to establish an earth. Do not earth the unit to a utility pipe, arrester, or telephone earth.
- Incomplete earth may cause electrical shock, or fire. A high surge current from lightning or other sources may cause damage to the air conditioner.

 Be sure to install an earth leakage breaker. Failure to install an earth leakage breaker may result in electric shocks, or fire.

4

O

♠ CAUTION

- Do not install the air conditioner in a place where there is danger of exposure to inflammable gas leakage. If the gas leaks and builds up around the unit, it may catch fire.
- Establish drain piping according to the instructions of this manual. Inadequate piping may cause flooding.
- Note for installing the outdoor unit. (For heat pump model only.)
 In cold area where the outside air temperature keep below or around freezing-point for a few days, the outdoor unit's drain may freeze.
 If so, it is recommended to install an electric heater in order to protect drain from freezing.
- Tighten the flare nut according to the specified method such as with a torque wrench.
 If the flare nut is tightened too hard, the flare nut may crack after a long time and cause refrigerant leakage.
- Make sure to provide for adequate measures in order to prevent that the outdoor unit be used as a shelter by small animals.
 Small animals making contact with electrical parts can cause malfunctions, smoke or fire. Please instruct the customer to keep the area around the unit clean.
- Do not squeeze the top plate of the outdoor unit while removing it Sharp metal plates may cause injury.

1

SiBE04-624 Installation Manual

Accessories

Accessories supplied with the outdoor unit:

		B Drain plug	
(A) Installation Manual	1		1
© Humidifying hose		① Joint	
	1		1
E Elbow		F Binding band	
	1		5

Precautions for Selecting the Location

- 1) Choose a place solid enough to bear the weight and vibration of the unit, where the operation noise will not be amplified.
- 2) Choose a location where the hot air discharged from the unit or the operation noise will not cause a nuisance to the neighbors of the user.
- 3) Avoid places near a bedroom or similar, so that the operation noise will cause no trouble.
- 4) There must be sufficient spaces for carrying the unit into and out of the site.
- 5) There must be sufficient space for air passage and no obstructions around the air inlet and the air outlet.
- 6) The site must be free from the possibility of flammable gas leakage in a nearby place.
- 7) Install units, power cords and inter-unit cables at least 3 meter away from television and radio sets. This is to prevent interference to images and sounds. (Noises may be heard even if they are more than 3 meter away depending on radio wave conditions.)
- 8) In coastal areas or other places with salty atmosphere of sulfate gas, corrosion may shorten the life of the air conditioner.
- 9) Since drain flows out of the outdoor unit, do not place under the unit anything which must be kept away from moisture.

NOTE

Cannot be installed hanging from ceiling or stacked.



When operating the air conditioner in a low outdoor ambient temperature, be sure to follow the instructions described below.

- To prevent exposure to wind, install the outdoor unit with its suction side facing the wall.
- 2) Never install the outdoor unit at a site where the suction side may be exposed directly to wind.
- 3) To prevent exposure to wind, it is recommended to install a baffle plate on the air discharge side of the outdoor unit.
- 4) In heavy snowfall areas, select an installation site where the snow will not affect the unit.




Installation Manual SiBE04-624

Outdoor Unit Installation Drawings

1. Precautions for humidifying hose installation work.

- Moisture on the outdoor unit is brought to the indoor unit together with air around the outdoor unit during humidifying operation. Install the outdoor unit in a clean and calm location.
- When embedding © humidifying hose:
 - 1) Cannot be installed to the existing embedded piping. Embedding work is separately necessary.
- The length of the © humidifying hose is marked on the hose packing material.
 - 1) Use an extension hose (sold separately) when extending the © humidifying hose.
 - 2) The length of the © humidifying hose needs to be set to ensure humidifying capacity. Cut off any excess hose. Use the remote controller to set the hose length.
- When it is difficult to install without cutting the © humidifying hose, cut the hose and join it with included ® joint or ® elbow
 after the installation. When doing this, bind the hose using included ® binding band so that there is no air leakage.
 (Refer to Connecting the Humidifying Hose on page 8.)
- When laying the © humidifying hose inside the wall, block the ends of the © humidifying hose with tape or the like to prevent water or anything else from entering it until it is connected to the indoor unit and outdoor unit ducts.
- Do not bend the © humidifying hose more than 90°.




SiBE04-624 Installation Manual

Installation Guidelines

· Where a wall or other obstacle is in the path of outdoor unit's intake or exhaust airflow, follow the installation guidelines below.

• For any of the below installation patterns, the wall height on the exhaust side should be 1200mm or less.



Unit: mm


More than 300

Top view

More than 50 ₹

Precautions on Installation

- · Check the strength and level of the installation ground so that the unit will not cause any operating vibration or noise after installed.
- In accordance with the foundation drawing, fix the unit securely by means of the foundation bolts. (Prepare four sets of M8 or M10 foundation bolts, nuts and washers each which are available on the market.)
- It is best to screw in the foundation bolts until their length are 20mm from the foundation surface.



Outdoor Unit Installation

1. Installing outdoor unit.

- 1) When installing the outdoor unit, refer to "Precautions for Selecting the Location" and the "Outdoor Unit Installation Drawings".
- 2) If drain work is necessary, follow the procedures below.

2. Drain work (heat pump-models).

- 1) Use ® drain plug for drainage.
- If the drain port is covered by a mounting base or floor surface, place additional foot bases of at least 30mm in height under the outdoor unit's feet.
- In cold areas, do not use a drain hose with the outdoor unit.
 (Otherwise, drain water may freeze, impairing heating performance.)




Installation Manual SiBE04-624


Outdoor Unit Installation

3. Flaring the pipe end.

- 1) Cut the pipe end with a pipe cutter.
- 2) Remove burrs with the cut surface facing downward so that the chips do not enter the pipe.
- 3) Put the flare nut on the pipe.
- 4) Flare the pipe.
- 5) Check that the flaring is properly made.



	Set exactly at the position shown below.					
	A Die	\setminus	Flare tool for R410A	Conventional flare tool		
			Clutch-type	Clutch-type (Rigid-type)	Wing-nut type (Imperial-type)	
		Α	0-0.5mm	1.0-1.5mm	1.5-2.0mm	
L						





MARNING

- 1) Do not use mineral oil on flared part.
- 2) Prevent mineral oil from getting into the system as this would reduce the lifetime of the units.
- 3) Never use piping which has been used for previous installations. Only use parts which are delivered with the unit.
- 4) Do never install a drier to this R410A unit in order to guarantee its lifetime.
- 5) The drying material may dissolve and damage the system.
- 6) Incomplete flaring may cause refrigerant gas leakage.

4. Refrigerant piping.

- 1) Align the centres of both flares and tighten the flare nuts 3 or 4 turns by hand. Then tighten them fully with the torque wrenches.
 - Use torque wrenches when tightening the flare nuts to prevent damage to the flare nuts and escaping gas.
- 2) To prevent gas leakage, apply refrigeration machine oil on both inner and outer surfaces of the flare. (Use refrigeration oil for R410A.)





Flare nut tightening torque		
Gas side	Liquid side	
3/8 inch	1/4 inch	
32.7-39.9N • m	14.2-17.2N • m	
(333-407kgf • cm)	(144-175kgf • cm)	

Valve cap tigh	Valve cap tightening torque		
Gas side	Liquid side		
3/8 inch	1/4 inch		
21.6-27.4N • m (220-280kgf • cm)	21.6-27.4N • m (220-280kgf • cm)		
Service port cap	10.8-14.7N • m		
tightening torque	(110-150kgf • cm)		


SiBE04-624 Installation Manual

5. Purging air and checking gas leakage.

· When piping work is completed, it is necessary to purge the air and check for gas leakage.

⚠ WARNING

- 1) Do not mix any substance other than the specified refrigerant (R410A) into the refrigeration cycle.
- 2) When refrigerant gas leaks occur, ventilate the room as soon and as much as possible.
- 3) R410A, as well as other refrigerants, should always be recovered and never be released directly into the environment.
- 4) Use a vacuum pump for R410A exclusively. Using the same vacuum pump for different refrigerants may damage the vacuum pump or the unit.
- If using additional refrigerant, perform air purging from the refrigerant pipes and indoor unit using a vacuum pump, then charge additional refrigerant.
- Use a hexagonal wrench (4mm) to operate the stop valve rod.
- All refrigerant pipe joints should be tightened with a torque wrench at the specified tightening torque.



1) Connect projection side of charging hose (which comes from gauge manifold) to gas stop valve's service port.



2) Fully open gauge manifold's low-pressure valve (Lo) and completely close its high-pressure valve (Hi). (High-pressure valve subsequently requires no operation.)



 Do vacuum pumping and make sure that the compound pressure gauge reads -0.1MPa (-76cmHg). (The vacuum pump should run for at least 10 min.)



Close gauge manifold's low-pressure valve (Lo) and stop vacuum pump. (Keep this state for a few minutes to make sure that the compound pressure gauge pointer does not swing back.)*1.



5) Remove covers from liquid stop valve and gas stop valve



Turn the liquid stop valve's rod 90 degrees counterclockwise with a hexagonal wrench to open valve. Close it after 5 seconds, and check for gas leakage. Using soapy water, check for gas leakage from indoor unit's flare and outdoor unit's flare and valve rods. After the check is complete, wipe all soapy water off.



Disconnect charging hose from gas stop valve's service port, then fully open liquid and gas stop valves. (Do not attempt to turn valve rod beyond its stop.)



8) Tighten valve caps and service port caps for the liquid and gas stop valves with a torque wrench at the specified torques.

*1. If the compound pressure gauge pointer swings back, refrigerant may have water content or a loose pipe joint may exists. Check all pipe joints and retighten nuts as needed, then repeat steps 2) through 4).

6

Installation Manual SiBE04-624

Outdoor Unit Installation

6. Refilling the refrigerant.

Check the type of refrigerant to be used on the machine nameplate.

Precautions when adding R410A

Fill from the liquid pipe in liquid form.

It is a mixed refrigerant, so adding it in gas form may cause the refrigerant composition to change, preventing normal operation.

1) Before filling, check whether the cylinder has a siphon attached or not. (It should have something like "liquid filling siphon attached" displayed on it.)

Filling a cylinder with an attached siphon



Stand the cylinder upright when filling.

There is a siphon pipe inside, so the cylinder need not be upside-down to fill with liquid.

Filling other cylinders



Turn the cylinder upside-down when filling.

• Be sure to use the R410A tools to ensure pressure and to prevent foreign objects entering.

7. Refrigerant piping work.

7-1 Cautions on pipe handling.

- 1)Protect the open end of the pipe against dust and moisture.
- 2)All pipe bends should be as gentle as possible. Use a pipe bender for bending.


(Bending radius should be 30 to 40mm or larger.)



7-2 Selection of copper and heat insulation materials.

When using commercial copper pipes and fittings, observe the following:

- 1) Insulation material: Polyethylene foam
 - Heat transfer rate: 0.041 to 0.052W/mK (0.035 to 0.045kcal/mh•°C)
 - Refrigerant gas pipe's surface temperature reaches 110°C max. Choose heat insulation materials that will withstand this temperature.
- 2) Be sure to insulate both the gas and liquid piping and to provide insulation dimensions as below.



Gas side	Gas side Liquid side		Liquid pipe thermal insulation
O.D. 9.5mm	O.D. 6.4mm	I.D. 12-15mm	I.D. 8-10mm
Thickness 0.8mm		Thickness 10mm Min.	


3) Use separate thermal insulation pipes for gas and liquid refrigerant pipes.

SiBE04-624 Installation Manual

Pump Down Operation

In order to protect the environment, be sure to pump down when relocating or disposing of the unit.

- 1) Remove the valve cap from liquid stop valve and gas stop valve.
- 2) Carry out forced cooling operation.
- 3) After five to ten minutes, close the liquid stop valve with a hexagonal wrench.
- After two to three minutes, close the gas stop valve and stop forced cooling operation.



How to force cooling operation mode

- Using the indoor unit operation/stop button Press the indoor unit operation/stop button for at least five seconds. (Operation will start.)
 - Forced cooling operation will stop automatically after around 15 minutes.
 To force a test run to stop, press the indoor unit operation/stop button.




After closing the liquid stop valve, close the gas stop valve within three minutes, then stop the forced operation.

Connecting the Humidifying Hose


1. Connecting the humidifying hose.

- 1) Connect the © humidifying hose to the outdoor humidifying duct.
- 2) Apply a (F) binding band to prevent the (©) humidifying hose from coming off.



2. Connecting the cut humidifying hoses.

• When installing the cut © humidifying hoses, follow the instructions below.



• Use not more than 2 elbows to ensure humidifying capacity.

System Configuration 103


Installation Manual SiBE04-624


Wiring

⚠ WARNING

1) Do not use tapped wires, stranded wires (CAUTION (1)), extension cords, or starburst connections, as they may cause overheating, electrical shock, or fire.

- 2) Do not use locally purchased electrical parts inside the product. (Do not branch the power for the drain pump, etc., from the terminal block.) Doing so may cause electric shock or fire.
- 3) Be sure to install an earth leak detector. (One that can handle higher harmonics.)
 (This unit uses an inverter, which means that it must be used an earth leak detector capable handling harmonics in order to prevent malfunctioning of the earth leak detector itself.)
- 4) Use an all-pole disconnection type breaker with at least 3mm between the contact point gaps.
- 5) The earth leakage circuit breaker must operate at 30mA or lower.
- . Do not turn ON the safety breaker until all work is completed.
 - 1) Strip the insulation from the wire (20mm).
 - 2) Connect the connection wires between the indoor and outdoor units so that the terminal numbers match. Tighten the terminal screws securely. We recommend a flathead screwdriver be used to tighten the screws. The screws are packed with the terminal board.





⚠ CAUTION (1)

In case using stranded wires is unavoidable for some reason, make sure to install the round crimp-style terminals on the tip.


Place the round crimp-style terminals on the wires up to the covered part and secure in place.




SiBE04-624 Installation Manual

<Ground terminal installation>

1) Use the following method when installing a single core wire.




2) Use the following method when installing the round crimp-style terminal.



⚠ CAUTION (2)

When connecting the connection wires to the terminal board using a single core wire, be sure to perform curling. Problems with the work may cause heat and fires.



Test Run and Final Check

1. Trial operation and testing.

- Measure the supply voltage and make sure that it falls in the specified range.
- See "Test Run and Final Check" in the installation manual that came with the indoor unit for details on how to perform the test run and what to check for.

2. Test items.

Test Items	Symptom (diagnostic display on RC)	Check
Outdoor unit is installed properly on a solid base.	Fall, vibration, noise	
No refrigerant gas leaks.	Incomplete cooling/heating function	
Refrigerant gas and liquid pipes and indoor drain hose extension are thermally insulated.	Water leakage	
Draining line is properly installed.	Water leakage	
System is properly earthed.	Electrical leakage	
The specified wires are used for interconnecting wire connections.	Inoperative or burn damage	
Outdoor unit's air intake or exhaust has clear path of air. Stop valves are opened.	Incomplete cooling/heating function	

10

3P177302-2

System Configuration SiBE04-624

2. System Configuration

After the installation and test operation of the room air conditioner have been completed, it should be operated and handled as described below. Every user would like to know the correct method of operation of the room air conditioner, to check if it is capable of cooling (or heating) well, and to know a clever method of using it.

In order to meet this expectation of the users, giving sufficient explanations taking enough time can be said to reduce about 80% of the requests for servicing. However good the installation work is and however good the functions are, the customer may blame either the room air conditioner or its installation work because of improper handling. The installation work and handing over of the unit can only be considered to have been completed when its handling has been explained to the user without using technical terms but giving full knowledge of the equipment.

3. Instruction

Safety Precautions

Safety Precautions

- Keep this manual where the operator can easily find them. Read this manual attentively before starting up the unit.

- For safety reason the operator must read the following cautions carefully.

 This manual classifies precautions into WARNING and CAUTION. Be sure to follow all precautions below: they are all important for ensuring safety.

∕!\WARNING

If you do not follow these instructions exactly, the unit may cause property damage, personal injury or loss of life.

⚠ CAUTION

If you do not follow these instructions exactly, the unit may cause minor or moderate property damage or personal injury.

Never do

Be sure to follow the instructions



Be sure to earth the air conditioner.

Never cause the air conditioner (including the remote

Never touch the air conditioner (including the remote controller) with a wet hand.

controller) to get wet



♠ WARNING

In order to avoid fire, explosion or injury, do not operate the unit when harmful, among which flammable or corrosive gases, are detected near the unit.



- It is not good for health to expose your body to the air flow for a long time
- Do not put a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury. Do not attempt to repair, relocate, modify or reinstall the air condi-
- tioner by yourself. Incorrect work will cause electric shocks, fire etc. For repairs and reinstallation, consult your Daikin dealer for advice and information
- Do not insert fingers, poles, or other objects into the moving parts of the front panel or the outlet vent panel
- The refrigerant used in the air conditioner is safe. Although leaks should not occur, if for some reason any refrigerant hap-pens to leak into the room, make sure it does not come in conact with any flame as of gas heaters, kerosene heaters or gas range.
- If the air conditioner is not cooling (heating) properly, the refrigerant may be leaking, so call your dealer. When carrying out repairs accompanying adding refrigerant, check the content of the repairs with our service staff.
- Do not attempt to install the air conditioner by your self. Incorrect work will result in water leakage, electric shocks or fire. For installa-
- tion, consult the dealer or a qualified technician. In order to avoid electric shock, fire or injury, if you detect any abnormally such as smell of fire, stop the operation and turn off the breaker. And call your dealer for instructions.

/!\ CAUTION

The air conditioner must be earthed. Incomplete earthing may result in electric shocks. Do not connect the earth line to a gas pipe, water pipe, lightning rod, or a telephone earth line.



- In order to avoid any quality deterioration, do not use the unit for cooling precision instruments, food, plants, animals or
- works of art Never expose little children, plants or animals directly to the air flow Do not place appliances which produce open fire in places exposed to the air flow from the unit or under the indoor unit. It may cause
- incomplete combustion or deformation of the unit due to the heat. Do not block air inlets nor outlets. Impaired air flow may result in
- insufficient performance or trouble. Do not stand or sit on the outdoor unit. Do not place any object on the unit to avoid injury, do not remove the fan guard.
- Do not place anything under the indoor or outdoor unit that must be kept away from moisture. In certain conditions, moisture in the air
- may condense and drip.

 After a long use, check the unit stand and fittings for damage. Do not touch the air inlet and aluminum fins of outdoor unit. It may
- cause injury. The appliance is not intended for use by young children or infirm per-
- Young children should be supervised to ensure that they do not play with the appliance.
- sons without supervision

To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the air condi-



- Before cleaning, be sure to stop the operation, turn the breaker off or
- pull out the supply cord. Do not connect the air conditioner to a power supply different from the one as specified. It may cause trouble or fire.

 Depending on the environment, an earth leakage breaker must be
- installed. Lack of an earth leakage breaker may result in electric shocks, or fire.
- Arrange the drain hose to ensure smooth drainage. Incomplete
- draining may cause wetting of the building, furniture etc.

 Do not place objects in direct proximity of the outdoor unit and do not let leaves and other debris accumulate around the unit Leaves are a hotbed for small animals which can enter the unit. Once in the unit, such animals can cause malfunctions, smoke or fire when making contact with electrical parts.
- Do not operate the air conditioner with wet hands.



2

- · Do not wash the indoor unit with excessive water, only use a slightly wet cloth
- Do not place things such as vessels containing water or anything else on top of the unit. Water may penetrate into the unit and degrade electrical insulations, resulting in an electric shock.

Installation site.

System Configuration

- To install the air conditioner in the following types of environments. consult the dealer.
 - · Places with an oily ambient or where steam or soot occurs.
 - Salty environment such as coastal areas
 - Places where sulfide gas occurs such as hot springs.
- · Places where snow may block the outdoor unit.

The drain from the outdoor unit must be discharged to a place of good drainage

Consider nuisance to your neighbours from noises.

- For installation, choose a place as described below
 - A place solid enough to bear the weight of the unit which does not amplify the operation noise or vibration.
 - A place from where the air discharged from the outdoor unit or the operation noise will not annoy your neighbours

Electrical work.

For power supply, be sure to use a separate power circuit dedicated to the air conditioner.

System relocation.

 Relocating the air conditioner requires specialized knowledge and skills. Please consult the dealer if relocation is necessary for moving or remodeling

3.2 Names and Functions of Parts


Names of Parts

■ Indoor Unit


- 1. Streamer unit: (page 20-22.)
- 2. Deodorizing filter for streamer (Black)
- 3. Air inlet
- 4. Front panel
- 5. Upper panel
- 6. Air filter (Light blue): (page 19.)
- 7. Titanium apatite photocatalytic air-purifying filter (Black): (page 20-22.)
- 8. Air supply filter (Yellow): (page 23.)
- 9. Horizontal louver: (page 10.)
- 10. Vertical louver:
 - In the air outlet. (page 10.)
- 11. Air outlet
- 12. Room humidity sensor:
 - It senses the air humidity around the indoor unit.
- 13. Room temperature sensor:
 - It senses the air temperature around the indoor unit
- 14. Display
- 15. Indoor unit ON/OFF switch:
 - Push this switch once to start operation.
 Push once again to stop it.
- 16. Multi-colored indicator lamp:
 - The lamp color changes according to the operation.
 HEATING......Red
 - HEATING...... Red
 "URURU" HUMIDIFYING /
 - HUMID HEATING Orange
 COOLING Green
 - "SARARA" DRYING /
 DRY COOLING Yellov
 - The lamp color also changes according to the optional function.
 - FLASH STREAMER AIR PURIFYING / FRESH AIR SUPPLY VENTILATION ... White (Only for the first 2 seconds during operation of the air conditioner.)
- 17. TIMER lamp (Orange): (page 12.)
- 18. MOISTURIZING lamp (Green): (page 9.)
- 19. Signal receiver:
 - Receives / sends signals from/to the remote controller.
 - The multi-colored indicator lamp blinks with beep sound to indicate signal reception.
 - Operation starttwo beeps
 Settings changedone beep
 - Operation stoplong beep

Outdoor Unit


- 20. Humidify unit air outlet: (Front side)
- 21. Air inlet: (Back and left side)
- 22. Air outlet
- 23. Humidify unit air intake: (Front and back)
- 24. Outdoor temperature sensor:
 - It senses the air temperature around the outdoor unit. (Back side)
- 25. Refrigerant piping, humidifying hose and inter-unit cable
- 26. Drain hose:
 - Drains water coming from the indoor unit.
- 27. Earth terminal:
 - It is inside of this cover.



Outdoor Unit



Remote Controller



■ Remote Controller

1. Transmitter / Receiver

2. Display:

 It displays the current settings.
 (In this illustration, each section is shown with all its displays ON for the purpose of explanation.)

* The protection sheet is on the display to protect against scratch. Remove it before use.

3. INFORMATION button:

 Displays the indoor temperature and humidity and the outdoor temperature. (page 16.)

4. COUNTDOWN OFF TIMER button:

• Sets time to stop. (page 12.)

5. ON/OFF button:

 Stops operation selected with the direct operation button. Another press will restart the same operation.

6. Direct operation button:

- AUTO button (page 9.)
- "URURU" HUMIDIFYING button (page 8.)
- HEATING button (page 8.)
- "SARARA" DRYING button (page 7.)
- COOLING button (page 7.)

7. POWERFUL button:

Makes cooling or heating more powerful. (Canceled in 20 minutes.) (page 13.)

8. TEMPERATURE adjustment buttons:

· It changes the temperature setting.

9. HUMIDITY buttons:

• It changes the humidity setting.

10. FLASH STREAMER AIR PURIFYING / FRESH AIR SUPPLY VENTILATION button:

• Cleans the room air. (page 11.)

11. AIRFLOW DIRECTION / AIRFLOW RATE / COMFORT AIRFLOW / COOLING BREEZE button:

Adjusts air direction and volume. (page 10.)

12. MOISTURIZING button:

 Keeps humidity high to moisturizes your skin. (page 9.)

13. HOME LEAVE VENTILATION button:

• Ventilates the room during home leaving.

14. SET UP button:

 Sets the unit operation and remote controller display according to your preference. (page 14.)

15. TIMER SELECT button

16. TIMER Setting button:

• Sets the time for timer-on or timer-off. (page 12.)

17. CLOCK button:

• Sets the present time. (page 6.)

18. MOLD SHOCK OUT button:

 Continuously runs the dehumidifying operation to keep the room air dry and clean. (page 16.)

19. MOLD PROOF button:

 Dries the inside of the unit to prevent mold and odor growth. (page 15.)

20. COMFORT SLEEP button:

Controls the room temperature to support comfort sleep and pleasant wake-up. (page 13.)

21. RESET button:

• Cleaning indicator reset. (page 17.)

22. CANCEL button

4

3.3 Preparation before Operation

Preparation Before Operation

■ To set the batteries

- 1. Press with a finger and slide the cover to take it off.
- 2. Set two dry batteries (AAA).
- 3. Set the cover as before.
 - Characters on the display will blink. Set the present time. (page 6.)

■ How to use

- To use the remote controller, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote controller, such as a curtain, the unit will not operate.
- The maximum distance for communication is about 7m.
- Do not drop the remote controller. Do not get it wet. (Damage to LCD may occur.)

■ To fix the remote controller holder on the wall


- 1. Choose a place from where the signals reach the unit.
- Fix the remote controller holder to a wall or pillar using the included screws.
- 3. Hook the holes on back of the remote controller to the protruding tabs on the remote controller holder.
- Attach the Titanium apatite photocatalytic air-purifying filter, deodorizing filter for streamer, and air supply filter (page 20, 23.)


Turn on the power breaker


• Turning on the power breaker will cause the front panel and horizontal louver to open once and then close again. (This is a normal procedure.)



 During operation (i.e. when the panel is open or being opened or closed), do not touch the panel with your hands.







ATTENTION

• Wrap the terminals with tape to insulate them before discarding batteries. Mixing with other metals or batteries may cause heat, explosion or fire.

PRECAUTION

■ About batteries

- The included batteries are provided to be used at first. Depending on when the air conditioner was manufactured, these batteries may run out in less than a year.
- We recommend replacing once a year, although if the remote controller display begins to fade or if reception deteriorates, please replace with new alkaline batteries.
- When replacing the batteries, use batteries of the same type, and replace the two old batteries together.
- Batteries close to their expiration dates will have to be replaced sooner.
- To prevent breakage or injury due to leaking or explosion, remove the batteries if the unit is not used for a long period of time

■ About remote controller

- Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult the shop if that is the case.
- If the remote controller signals happen to operate another appliance, move that appliance to somewhere else, or consult the shop.
- Direct sunlight on the transmitter/receiver may cause the unit to work harder.

■ To set the clock

* Time cannot be set during unit operation.

1. Press " ... ".. Do not hold the button.

∰ >**β**¦<u></u>ģģ:

0:00 is displayed.

🕘 blinks.

2. Press " select of the present time.



• Holding the button changes the time faster.


3. Press " ... "...

⊕ _{15\$30}

blinks.

is displayed.

· Setting is complete.



ATTENTION

If other messages than time appear on the display with the step 1 operation, do not operate the button for about 60 seconds. The display will return to normal.

■ Tips for saving energy

Be careful not to cool (heat) the room too much.

Keeping the temperature setting at a moderate level helps save energy.

Cover windows with a blind or a curtain.

Blocking sunlight and air from outdoors increases the cooling (heating) effect.

Clogged air filters cause inefficient operation and waste energy. Periodically clean the filter.

■ Please note

- The air conditioner consumes power even when it is not operating.
- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker OFF.
- When the outdoor temperature is below -15°C, turn on the breaker more than 1 hour before starting the operation. (This is to warm up the compressor.)

■ Operating conditions

• Running the unit under conditions not listed below may cause the safety device to activate, stopping the unit. Also, condensation may form on the indoor unit and drip. (DRY / COOLING operation)


COOLING	Outdoor temperature : 21 to 43°C Indoor temperature : 18 to 32°C Indoor humidity : 80% max.	HEATING	Outdoor temperature : -20 to 24°C Indoor temperature : 10 to 30°C Indoor humidity : 70% max.
DRY	Outdoor temperature : 10 to 42°C Indoor temperature : 18 to 30°C Indoor humidity : 80% max.	HUMIDIFYING	Outdoor temperature : -10 to 24°C Indoor temperature : 12 to 30°C Indoor humidity : 70% max.

■ Reachable Humidity

The ability of humidification drops when the outdoor temperature and humidity are low.

(Co. Fig. 1 or reference)

(See Fig.1 as reference.)



Condition; Model: FTXR50EV1B Indoor temperature setting: 20°C Airflow rate: Max. Room volume: 120m³ Air change rate: 0.5/hour Humidifying hose length: 7.5m

Recommended temperature setting


For cooling : $26^{\circ}\text{C} - 28^{\circ}\text{C}$ For heating : $20^{\circ}\text{C} - 22^{\circ}\text{C}$

6

3.4 Cooling · "SARARA" DRYING Operation

COOLING · "SARARA" DRYING Operation


■ COOLING operation



^{*} It is recommended to switch to COOLING operation if you want to lower temperature preferentially during DRY COOLING operation.

■ "SARARA" DRYING operation

To lower humidity



■ To change the airflow direction and airflow rate (page 10.)

The airflow rate is set to "AUTO" during DRY COOLING or "SARARA" DRYING operation. Airflow rate cannot be changed.


■ To stop operation

4. Press "ON/OFF".

The multi-colored indicator of the unit will go off.

■ To change the temperature or humidity setting

	COOLING	DRY COOLING	DRY
△ TEMP		18°C – 32°C	−3°C − STD
△ HUM %	OFF ₹	HIGH	HIGH
MULTI-MONITOR ON/OFF	Green	Yel	low



NOTE

- Note on ON / OFF button
 - Pressing "ONOTE" will start the same operation as the last time.
- Note on COOLING operation
- This air conditioner cools the room by blowing the hot air in the room outside, so if the outside temperature is high, performance drops.
- Note on DRY COOLING
 - Pressing the humidity button down in COOLING mode set the unit to DRY COOLING.
 - Removes more humidity than the normal COOLING operation. It is recommended, however, to set temperature slightly lower than the room temperature to lower humidity because this operation mode does not heat air supplementary.
- Note on "SARARA" DRYING operation
- Removes humidity with less lowering of the room temperature by heating air supplementary.
- The operation mode change from COOLING to "SARARA" DRYING may raise humidity temporarily.

7

Heating · "URURU" HUMIDIFYING Operation 3.5

HEATING · "URURU" HUMIDIFYING Operation

■ HEATING operation









To raise temperature and humidity







■ "URURU" HUMIDIFYING operation

To raise humidity







■ To change the airflow direction and airflow rate (page 10.)


■ To stop operation

4. Press "OON/OFF".

The multi-colored indicator of the unit will go off.

■ To change the temperature or humidity setting

	HEATING	HUMID HEATING	HUMIDIFYING
△ TEMP °° ▽		10°C – 30°C	
△ HUM % ▽	OFF ₹		LOW 2 STD 2 HIGH 2 CONT
MULTI-MONITOR ON/OFF	Red	Or	ange



NOTE

■ Note on HEATING operation

- Since this air conditioner heats the room by taking heat from outdoor air to indoors, the HEATING capacity becomes smaller in lower outdoor temperatures. If the HEATING effect is insufficient, it is recommended to use another HEATING appliance in combination with the air condi-
- The heat pump system heats the room by circulating hot air around all parts of the room. After the start of HEATING operation, it takes some time before the room gets warmer.
- In HEATING operation, frost may occur on the outdoor unit and lower the HEATING capacity. In that case, the system switches into defrosting operation to take away the frost.
- During defrosting operation, hot air does not flow out of indoor unit.

■ Note on HUMID HEATING and "URURU" HUMIDIFYING operation

- The ability of the unit to humidify drops when the outdoor temperature and humidity are low, or when the set fan strength is low.
- The operation noise is higher than in normal HEATING.
- The outdoor noise or odor may be captured because the outdoor air is heated with the heater and resultant moisture is taken into the room for humidification.
- The top of the outdoor unit may get warm during operation, but this is not a malfunction.
- The operation noise may change depending on the outdoor temperature and humidity. (Water supply is not necessary because moisture from the outdoor air is taken into the room.)

■ Note on "URURU" HUMIDIFYING operation

- Can adjust the room humidify only according to your preference.
- When the room temperature gets low, slight heating may be on to continue humidification

8

3.6 AUTO / MOISTURIZING Operation

AUTO Operation

After pressing the AUTO button, the air conditioner will operate according to room conditions in an automatic mode.

1. Press "(AUTO)".

MULTI-MONITOR ONOFF COOLING: Green

- The color of the multi-colored indicator changes according to the actual operations.
- When the AUTO button is pressed, the color according to the operation selected by the air conditioner will light up.
- To change the airflow direction and airflow rate (page 10.)
- To stop operation
 - 2. Press "(DON/OFF)".

The multi-colored indicator of the unit will go off.

■ To change the temperature setting



NOTE


■ Note on AUTO operation

- In AUTO operation, the system selects an appropriate operation mode (COOLING or HEATING) based on the room temperature at the start of the operation.
- The system automatically reselects setting at a regular interval to bring the room temperature to user setting level.
- If you do not like AUTO operation, you can manually select the operation mode and setting you like.

MOISTURIZING Operation

This mode moisturizes your skin.

1. Press "() during operation.



- The airflow rate and airflow direction settings are changed to auto and COMFORT AIRFLOW MODE respectively.
- In MOISTURIZING operation, COOLING BREEZE mode cannot be selected.

■ To change the temperature setting

- The same changes as COOLING and HEATING are possible. (page 7, 8.)
- Humidity and airflow rate cannot be changed.

■ To change the airflow direction (page 10.)

The recommended airflow direction is COMFORT AIRFLOW MODE, but it can be changed.

■ To cancel the MOISTURIZING operation

- 2. Press " (again.
 - The operation mode goes back to the previous one. The multi-colored indicator on the unit also goes back to the previous color.
 - The MOISTURE lamp on the unit will go off.

NOTE

■ Note on MOISTURIZING operation

- The relative humidity is higher than in normal operation.
- $\bullet\,$ Can be used for COOLING, DRY COOLING, HEATING and HUMID HEATING.
- The operation noise is slightly louder.

HUMIDIFY

AUTO

HUMIDIFY

AUTO

HEAT

TEMP

COLEAN

FRESH

TEMP

COLEAN

TEMP

COLEAN

TEMP


COLEAN

TEMP

COLEAN

TEMP

<AUTO>



3.7 Adjusting Airflow Direction · Comfort Airflow Mode · Cooling Breeze · Airflow Rate

ADJUSTING AIRFLOW DIRECTION · COMFORT AIR-FLOW MODE · COOLING BREEZE · AIRFLOW RATE

More comfortable airflow is provided with airflow direction and airflow rate adjustment.

■ To change vertical and horizontal airflow directions

1. Press " or " during operation.

(In case of vertical direction) • The airflow direction indication will display.

The horizontal and vertical louvers respectively move vertically and horizontally automatically.

■ If you want to fix airflow direction

2. Press "()" or "()" again.

■ To use 3-D AIRFLOW

3. Press "and then "during operation.

Government of the vertical and horizontal airflow direction indications will display.

The horizontal and vertical louvers move alternately.

■ To cancel 3-D AIRFLOW

4. Press "()" or " again.

■ COMFORT AIRFLOW MODE and COOLING BREEZE operation


5. The indication will change every time " is pressed.



- COMFORT AIRFLOW MODE operation
 - The airflow direction and airflow rate are adjusted so that the air from the unit does not blow directly on the occupants of the room.
 - < COOLING/DRYING> The flap will go up.
 - <HEATING/HUMIDIFYING> The flap will go down.
 - The airflow rate is set to "AUTO".
- COOLING BREEZE operation
 - COOLING BREEZE operation is for COOLING, "SARARA" DRYING and FLASH STREAMER AIR PURIFYING operation.

■ To change the airflow rate

- 6. Press "@FAN" during operation. (Refer to right table.)
 - COOLING or HEATING with "*_** or other weak airflow rate may not cool or heat the room sufficiently.
 - Indoor unit quiet operation
 When the air flow is set to "\(\frac{1}{2} \)", the noise from the indoor unit will become quieter.



Operating mode	Airflow rate setting	*	≋BREEZE	
"SARARA" DRYING		•	•	
DRY COOLING	[<u>Ā</u>]	•	•	
MOISTURIZING		•		
AUTO / COOLING		•	•	
HEATING		•		
HUMID HEATING] . t <u>A</u>	•		
"URURU" HUMIDIFYING	全中中心			
FLASH STREAMER AIR PURIFYING / FRESH AIR SUPPLY VENTILATION			•	
COMFORT AIRELOW MODE operation is possible.				

SPREEZE: COOLING BREEZE operation is possible.

Five levels of air flow rate setting from "\$" to "\$" plus " [A] " " ** are available.

NOTE

• If the unit is operated with the horizontal louvers pointed down and stopped in COOLING, "SARARA" DRYING, or DRY COOLING operation, the louvers will move automatically after about one hour. (This it to prevent condensation from forming on them.)

■ ATTENTION

• Be sure to use the remote controller to adjust the airflow direction. Manual operation of the louvers may cause it to work improperly.

■ Note on COMFORT AIRFLOW MODE operation

The airflow direction is as fig. 1;

■ Note on COOLING BREEZE operation


 The vertical movement of the horizontal louvers with "1/f breeze" rhythm provides comfort air like natural breeze. The room temperature is felt cooler with cooling breeze.

■ Note on Adjusting the vertical airflow direction

 The movable area for the horizontal louver is different depending on the operation mode.

■ Note on 3-D AIRFLOW

 Using 3-D AIRFLOW circulates cold air, which tends to be collected at the bottom of the room, and hot air, which tends to be collected near the ceiling, throughout the room, preventing areas of cold and hot from developing.



10

3.8 FLASH STREAMER AIR PURIFYING · FRESH AIR SUPPLY VENTILATION Operation / HOME LEAVE VENTILATION

FLASH STREAMER AIR PURIFYING · FRESH AIR SUPPLY VENTILATION Operation

The absorption power of the Titanium apatite photocatalytic air-purifying filter and air supply filter and the resolving power of the streamer discharge reduce bad odors and viruses, cleaning the room air.

1. Press "CLEAN FRESH".

(Can be used together with heating or cooling, or on its own.)

• Changes every time the button is pressed. (Use instead of FAN operation.)



■ To change the airflow direction and airflow rate (page 10.)

ATTENTION

 Temperature and humidity cannot be changed during FLASH STREAMER AIR PURI-FYING or FRESH AIR SUPPLY VENTILATION operation only.

NOTE

- Note on FLASH STREAMER AIR PURIFYING operation
- The streamer discharge energy and Titanium apatite photocatalytic air-purifying filter clean the air in the room.
- Note on FRESH AIR SUPPLY VENTILATION operation
 - Fresh air is taken from outdoor through the outdoor unit.
 - The outdoor noise and odor may be captured because the outdoor air is taken into the room. The operation noise is slightly louder.
 - The operation noise may change depending on the outdoor temperature and humidity.
- What is streamer discharge?
 - It generates high-speed electron with high oxidizing power in the unit to resolve odor and harmful gas.
 - (It is safe because the high-speed electron is generated and goes away inside the unit.)
 - * The streamer discharge fizzes, but this is not a malfunction.

HOME LEAVE VENTILATION

Ventilates the room during your absence to maintain it comfortable.

1. Press "€®".




- Stops automatically after 4 hours.
- The default setting is 4 hours.
- To change the time to stop
 - 2. Press "OFF ".
 - It can be set to between 1 and 9 hours, in 1-hour increments.
 - To use both HOME LEAVE VENTILATION and ON TIMER, set the ON TIMER first. (page 12.)
- To change the airflow direction (page 10.)
 - Temperature, humidity and airflow rate cannot be changed.
- To cancel the HOME LEAVE VENTILATION
 - 3. Press "(CANCEL)".


NOTE

- Note on HOME LEAVE VENTILATION
 - The FRESH AIR SUPPLY VENTILATION operation and COUNTDOWN OFF TIMER can be set with one button at the same time.

<FLASH STREAMER AIR PURIFYING /
FRESH AIR SUPPLY VENTILATION>



<HOME LEAVE VENTILATION>



3.9 TIMER Operation

TIMER Operation

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. The timer operates only one time. Set the timer for each use.

■ COUNTDOWN OFF TIMER operation

Set the time to stop.

- 1. Press "OFF ".
 - The displayed time, which changes in 0.5 hour increments every time the button is pressed, is set. The time from 0.5 to 9.5 hours can be set.



■ ON/OFF TIMER operation

Set time for ON TIMER or OFF TIMER.

- Check that the clock is correct. If not, set the clock to the present time. (page 6.)
- The present time display disappears when the time ON/OFF TIMER is reserved.
- Press "OFF" for OFF TIMER and press "ON" for ON TIMER.



- 3. Press " $\begin{bmatrix} \mathbf{A} \\ \text{select} \end{bmatrix}$ " to set the time to be reserved.
 - Pressing the button changes the time in 10 minutes. Holding the button makes the time change faster.
- 4. Press "OFF" for OFF TIMER and press "ON" for ON TIMER.


The displayed time is set.





■ To cancel the TIMER operation

- 5. Press "CANCEL".
 - The TIMER lamp will go off and the TIMER will be canceled.



NOTE

■ In the following cases, set the timer again.


- After a breaker has turned OFF.
- After a power failure.
- · After replacing batteries in the remote controller.

■ Note on TIMER operation

- Starting COUNTDOWN OFF TIMER and OFF TIMER causes the unit to automatically change the set temperature 1 hour later to prevent the room from becoming too cold or too hot. (Turns up 0.5°C during COOLING or DRY COOLING and turns down 2°C during HEATING or HUMID HEATING.)
- Reserving the ON TIMER will cause the unit to start running up to 1 hour before, in order to make sure the temperature reaches the temperature set on the remote controller by the set time.
- When operating the unit via the COUNTDOWN OFF TIMER or OFF TIMER, the actual length of operation may vary from the time entered by the user.
- Once you set ON/OFF TIMER, the time setting is kept in the memory.
 However, the COUNTDOWN OFF TIMER does not have this memory function.
 (The memory is canceled when remote controller batteries are replaced.)
- Cannot operate with COMFORT SLEEP operation.

■ To combine ON TIMER and OFF TIMER

- See the right example for reserving in combination of COUNTDOWN OFF TIMER and ON TIMER as well as OFF TIMER and ON TIMER.
- To cancel combined reservation
 - Press "ON" and then "CANCEL" to cancel the ON TIMER only.
 - Press " OFF " and then " CANCEL " to cancel the OFF TIMER only.
 - Press "@:" several times to reach 9.5 hours and then press it one more time to cancel the COUNTDOWN OFF TIMER only.




12

3.10 COMFORT SLEEP / POWERFUL Operation

COMFORT SLEEP Operation

Controlling the room temperature supports comfort sleep and pleasant wake-up.

- Check that the clock is correct. If not, set the clock to the present time. (page 6.)
- The present time display disappears when the COMFORT SLEEP operation is set.
 - 1. Press " uring operation.



2. Press " at the time to wake up.



 Pressing the button changes the time in 10 minutes. Holding the button makes the time change faster.



C-SLEEP is displayed.

- When settings are made while the unit is not running, press " (ON/OFF)" to start the operation.
- To cancel the comfort sleep operation
 - 4. Press "CANCEL".


ATTENTION

- - * Too low set temperature may cause you to get chilled while asleep.

NOTE

- Note on COMFORT SLEEP operation
 - Can be used for COOLING, DRY COOLING, MOISTURE COOLING, HEATING, HUMID HEATING and MOISTURE HEATING.
 - Cannot be used with TIMER operation.
- How to use COMFORT SLEEP operation effectively
 Starting COMFORT SLEEP operation lowers the set temperature by 2°C in 3 hours
 - and starts raising it by 1°C 1 hour before the set time, offering V-curve temperature control. (See the right figure.)

 Set the airflow direction so that the air from the unit
 - does not directly blow on the occupants of the room.



POWERFUL Operation

POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode.

- 1. Press " range operation.
 - POWERFUL operation ends in 20 minutes









- To change the airflow direction (page 10.)
 - Temperature, humidity and airflow rate cannot be changed.


■ To cancel POWERFUL operation


- 2. Press " ragain.
 - The operation mode goes back to the previous one. The multi-colored indicator
 on the unit also goes back to the previous color.

NOTE

■ Note on POWERFUL operation

- Can be used for COOLING, DRY COOLING, HEATING, HUMID HEATING and MOISTURE HEATING. (Cannot be used while the unit is not running.)
 Pressing "" during COOLING, DRY COOLING or MOISTURE COOLING changes the operation mode to POWERFUL COOLING.
 - Pressing " Turing HEATING, HUMID HEATING or MOISTURE HEATING changes the operation mode to POWERFUL HEATING.
- The operation noise is slightly louder during POWERFUL operation.





3.11 SET UP


SET UP

Sets the unit operation and remote controller display according to your preference.

- 1. Hold "SETUP" for about 2 seconds.
 - The setup mode will be activated.
- 2. The item will change every time "SET UP" is pressed.
- 3. The settings will change every time " $\left| \frac{\mathbf{A}}{\mathbf{SELECT}} \right|$ " is pressed respectively.
 - Direct the remote controller toward the main unit to make settings.

		is delault
Item	Setting	Description
CHILD PROOF LOCK ON/OFF	OFF ◀▶ ON	Restricts the remote controller operations to avoid misuse by children. (See NOTE.)
MOLD PROOF ON/OFF	OFF ◀▶ ON	If the unit is set to "MOLD PROOF ON", it may automatically enter MOLD PROOF operation mode after operating in DRYING, DRY COOLING or COOLING operation mode, depending on the amount of time it had been operating. This is to dry out the interior of the air conditioner. (page 15.)
MONITOR BRIGHTNESS	HIGH◀▶LOW◀▶OFF	Changes the brightness of the indoor unit display.
BEEP volume	LOW ◀ ▶ HIGH ◀ ▶ OFF	Sets the receiving tone volume.
CONTRAST Setting	1 ♦▶ 6 ♦▶ 16	Sets the grayscale for the remote controller LCD. Selectable from contrast 1 to 16.

Setting complete : The display on the remote control goes back to normal if no setting is made for 10 seconds.



NOTE

■ Note on CHILD PROOF LOCK

- The button operations other than "SETUP" are disabled in CHILD PROOF LOCK mode.
- To cancel the CHILD PROOF LOCK, set to "OFF" following the above steps from 1 to 3.

System Configuration 119

3.12 MOLD PROOF Operation

MOLD PROOF Operation

Dries the inside of the unit to prevent mold and odors.

■ Auto operation

(approximately once every 2 weeks)

If the unit is set to "MOLD PROOF ON", the MOLD PROOF operation will start automatically after the unit has been run in "SARARA" DRYING or COOLING mode, depending on the amount of time the unit has been run (approximately once every 2 weeks). (page 14.) The default is set to "MOLD PROOF OFF".

■ Manual operation


1. Hold "Mode" for about 2 seconds while the unit is not running.



The MOLD PROOF operation will start. The display will return to normal.


- The front panel and horizontal louver will open.
- The MOLD PROOF operation runs for about 3 hours, changing the color of the multi-colored indicator lamp of the unit.

<Color of multi-colored indicator lamp>



■ If you want to stop MOLD PROOF operation during operation

- 2. Hold "Molb@" (again) for about 2 seconds.
 - The front panel and horizontal louver will close.
 - The multi-colored indicator of the unit will go off.



(In case of manual operation)

NOTE

■ Note on MOLD PROOF operation

- Dries out the interior of the air conditioner using FAN and HEATING operation mode to exhaust humidity to the outdoor. This prevents mold and odor growth. This function is not designed to remove existing dust or mold.
- During MOLD PROOF operation, the room temperature may rise and humidity from the machine may be sent into the room. Some odors may be noticed, too.
- The mode may not be used if the outside temperature or humidity is very high.
- The exhausting operation may not be run depending on the outdoor temperature.
- MOLD PROOF operation mode is not available if the unit is shut off using the COUNTDOWN OFF TIMER. MOLD PROOF operation mode
 only comes on automatically if the unit has been stopped using the operation/stop switch on the remote controller or the main unit.
- If MOLD PROOF operation is stopped during AUTO mode, the operation comes on automatically next time, depending on the amount of time the unit had been operating. To cancel the AUTO mode, set to "MOLD PROOF OFF". (page 14.)

3.13 MOLD SHOCK Operation / INFORMATION DISPLAY

MOLD SHOCK OUT Operation

This mode dehumidifies the air in the room and prevents mold growth. Continuous drying operation lowers the room humidity rapidly.


1. Hold "MOLDS" for about 2 seconds while the unit is not running.



The MOLD SHOCK OUT operation will start. The display will return to normal.

- The front panel and horizontal louver will open.
- The MOLD SHOCK OUT operation runs for about 3 hours, changing the color of the multi-colored indicator lamp on the unit.

<Color of multi-colored indicator lamp>



• Blinks in order during the MOLD SHOCK OUT operation.

■ If you want to stop MOLD SHOCK OUT operation during operation

- 2. Hold "MOLDS" (again) for about 2 seconds.

 - The front panel and horizontal louver will close.
 The multi-colored indicator of the unit will go off.

NOTE

■ Note on MOLD SHOCK OUT operation

- The mode may not be used depending on the outdoor temperature. <Operating range> Outdoor temperature of from 12 to 40°C
- Temperature and humidity may not satisfy your preference during MOLD SHOCK OUT operation. Run this operation mode while no one is in the room.


It is generally said that mold growth can be reduced when the humidity is below 60%

INFORMATION DISPLAY

Displays the room temperature and humidity and outdoor temperature.

1. Press " (INFO) ".


After pressing "(INFO)", point the remote controller at the air conditioner unit for 2 seconds.




■ The display changes every time "(NFO)" is pressed. NOTE

■ Note on INFORMATION DISPLAY

- The signal from the air conditioner is not being received properly if "Reception Failed" is displayed when you press "(NFO)". Repeat, aiming the remote controller at the air conditioner.
- During operation, the outdoor temperature may sometimes be displayed higher than it actually is in COOLING or "SARARA" DRYING mode or lower in HEATING mode (especially if frost has accumulated on the outdoor unit), due to the effects of the air blown from the outdoor unit or the temperature of the heat exchanger.
- The lowest indoor and outdoor temperature which can be displayed is -9°C. This will be displayed even if the actual temperature is lower. The highest temperature is 39°C. This will be displayed even if the actual temperature is higher.
- The indoor and outdoor temperatures and the humidity which are displayed are those near the sensors attached to the main air conditioner unit.
- The displayed temperature and humidity should only be taken as approximations, as they may be affected if there are objects around the sensors or due to direct sunlight, depending on where the air conditioner is installed.





16

3.14 Care and Cleaning

Care and Cleaning

Quick reference for cleaning

⚠ CAUTION

- Before cleaning, be sure to stop the operation and turn the breaker OFF.
 Do not touch the metal parts in the indoor unit. Doing so may cause injury.
- 1. Front panel

Wipe off if it gets dirty. (Cleaning : page 18.)

2. Air filter

Vacuum/Rinse if "CLEAN FILTER" displays. (Cleaning: page 19.)

3. Air supply filter (Yellow)

Cannot be washed with water.

Vacuum once in about 3 months.

• Replace once in about 1 year. (Cleaning: page 23.)

4. Titanium apatite photocatalytic air-purifying filter (Black)

Soak if "CLEAN STREAMER" displays.

• Replace once in about 3 years. (Cleaning: page 21.)

5. Deodorizing filter for streamer (Black)

Soak if "CLEAN FILTER" display.

 Replace once in about 3 years. (Cleaning : page 21.)

6. Upper panel


Wipe off if it gets dirty. (Cleaning: page 18.)

7. Streamer unit

Soak if "CLEAN STREAMER" displays.

• Replace once in about 3 years.

(Cleaning : page 21.)



To reset the filter cleaning indicator

While the unit is not operating, the filter cleaning indicator may be displayed on the remote controller depending the amount of time the unit had been operating. This sign indicates the cleaning timing for the air filter, Titanium apatite photocatalytic air-purifying filter, deodorizing filter for streamer or





- 1. After cleaning, press " or about 2 seconds directing the remote controller toward the main unit with powered on.
 - · Indication disappears.



NOTE

- "CLEAN FILTER" sign will appear after about 340 hours of operation.
- "CLEAN STREAMER" sign will appear after about 1800 hours of operation.
- Operating the unit without cleaning with the "CLEAN STREAMER" sign displayed will lower the deodorizing capability.
- Periodical cleaning leads to energy saving.

Attaching and removing the front panel




• Only open the front panel after turning the unit off.

Opening the panel during operation may cause the panel to fall off.


1. Open the front panel.

Placing a finger on the panel tab on either side of the front panel.




2. Remove the front panel.

• Spread out the shaft hole and remove the rotating shaft. (Both left and right sides.)



3. Attach the front panel.

 Place the revolving axes on either side of the front panel into the holes and slowly close.
 (Press either side of the front panel.)




Attaching and removing the upper panel

1. Remove the front panel and pull out the air filter. (page 19.)


2. Remove the upper panel.

- Hold the 2 tabs on either side of the upper panel and pull forward to remove.
- 2) Remove the tab in the center and lift.



3. Attach the upper panel.

- Insert the 3 tabs on back of the upper panel and then push it down.
- Push the upper panel down until it clicks.



Cleaning for each case

- Wipe it with a soft cloth soaked in water. (Only neutral detergent may be used.)
- In case of washing the front panel with water, dry it with cloth, dry it up in the shade after washing.

⚠ CAUTION

- When removing or attaching the front panel, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front panel, support the front panel securely with hand to prevent it from falling.
- For cleaning, do not use hot water above 40°C, benzine, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes, nor other hand stuff.
- After cleaning, make sure that the front panel is securely fixed.
- Wipe the front panel with a soft cloth. Wiping with a hard cloth may scratch it.

18

Care and Cleaning


Cleaning the air filter



is displayed on the remote controller)

1. Open the front panel.

Open the front panel by placing a finger on the panel tab on either side
of the front panel and then secure it using the supporting plate on the
right.




2. Pull out the air filters.

• Push a little upwards the air filter.



• Pull the air filter down.




3. Clean the air filter.

- Wash the air filters with water or clean them with vacuum cleaner.
- If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.



4. Set the air filter as it was and close the front panel.

- Insert the air filter with the "FRONT" marking to the front.
- Be sure to insert the two tabs below.
- Return the supporting plate to its previous position.
- Press either side of the front panel.




5. Reset the filter cleaning indicator. (page 17.)

ATTENTION

• Using without cleaning will lower the COOLING or HEATING capability, wasting electricity.

Attaching and removing the deodorizing filter for streamer, Titanium apatite photocatalytic air-purifying filter, streamer unit


1. Open the front panel and pull out the air filter. (page 19.)



Removing


2. Remove the deodorizing filter for streamer.

 Discharge the tab and pull out the knob in a downward direction.




3. Pull out the streamer unit.

 Hold the center of the handle and pull out in a downward direction.



4. Remove the Titanium apatite photocatalytic air-purifying filter.

 Pull up the filter frame, discharge the tabs on both sides of the Titanium apatite photocatalytic air-purifying filter from the hooks, and pull down the filter in a downward direction.




Attaching

- 5. Replace the streamer unit to its original position.
 - Attach the streamer unit in opposite procedure to removing 3.
- 6. Attach the deodorizing filter for streamer.
 - Insert the deodorizing filter for streamer until it clicks.



7. Attach the Titanium apatite photocatalytic air-purifying filter.

 Insert the 2 upper tabs on the Titanium apatite photocatalytic air-purifying filter into the guides on the main unit and then hook up the 2 lower tabs.



8. Replace the air filter to its original position and close the front panel.


Care and Cleaning

Cleaning the deodorizing filter for streamer, Titanium apatite photocatalytic air-purifying filter and streamer unit




■ Attaching and removing each part (page 20.)

Deodorizing filter for streamer / Titanium apatite photocatalytic air-purifying filter



Streamer unit



■ Resetting the filter cleaning indicator (page 17.)

ATTENTION


Using without cleaning lowers the deodorizing capability.

How to replace

■ Deodorizing filter for streamer

(Once in about 3 years)


Remove from the filter frame and replace the filter with a new one.



- The deodorizing filter for stream and the titanium apatite photocatalytic air-purifying filter do not have front and back sides.
- Dispose a used filter as burnable waste. (material: paper)

■ Titanium apatite photocatalytic airpurifying filter (Once in about 3 years)

Discharge the 4 tabs of the filter frame and replace the filter with a new one.





How to disassemble and assemble the streamer unit

■ Before disposing the streamer unit, disassemble it.

How to disassemble

- Use gloves for safety.
- Apply one hand to ||||||||| part and push the plastic part with another hand.
- Disassemble the streamer unit into the plastic cover and the discharge plate.
- Match up the securing parts of the various parts of the streamer unit and assemble as it was.





ACAUTION

Be careful not to cut yourself when disassembling and assembling the streamer unit.

System Configuration 127


Care and Cleaning

Attaching, cleaning and replacing the air supply filter

(Clean once in about 3 months and replace once in about 1 year.)

Cannot be washed with water.

- 1. Open the front panel to pull out the air filter and Titanium apatite photocatalytic airpurifying filter. (page 19, 20.)
- 2. Pull out the air supply filter.




3. Cleaning

- · Remove dust with a vacuum cleaner.
- The component of the filter is weak in water. Do not rinse the filter

Replacing

Discharge the 4 tabs of the filter frame and replace the filter with a new one.

Dispose a used filter as unburnable waste. (material: polyester)



- Replace the air supply filter to its original position.
- 5. Set the Titanium apatite photocatalytic airpurifying filter and the air filter as they were and close the front panel. (page 19, 20.)

ACAUTION

• Do not forget to replace the filter to its original position after cleaning it. Operating the unit in HUMIDIFYING mode without attaching the filter may cause condensation to form inside the panel or others, causing water to leak.

Cleaning the indoor unit and the remote controller

• Wipe with a soft dry cloth.

For cleaning, do not use hot water above 40°C, benzine, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes, nor other hand stuff.

NOTE

- The deodorizing filter for stream and the titanium apatite photocatalytic air-purifying filter should be cleaned regularly. We recommend replacing the filter in the following situations.
 - If it is damaged during cleaning because it is made of paper.
 - · If it is very dirty after long use.

Item	Part No.
Air purifying filter set	KAF974B42S
Air supply filter (with frame)	KAF963A43

- To order Titanium apatite photocatalytic air-purifying filter, deodorizing filter for streamer, air supply filter and streamer unit contact to the service shop there you bought the air conditioner.
- Using the dirty parts will:
 - Prevent proper air purification.
 - Prevent proper deodorizing.
 - Reduce COOLING and HEATING capacity.
 - Cause the unit to produce foul odors.

Check

- Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.
- Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.
- Check that the drain comes smoothly out of the drain hose during COOLING or DRY operation.
 - If no drain water is seen, water may be leaking from the indoor unit.
 Stop operation and consult the service shop if this is the case.
- Is the earth wire out or disconnected in the middle?
 - An incomplete ground wire may cause electrical shock. Contact the service shop.

Before a long idle period

1. Operate the "MOLD PROOF" for several hours on a fine day to dry out the inside.

MOLD PROOF operation

Hold "(MOLDQ)" for about 2 seconds while the unit is not running.



The operation will stop in about 3 hours.

- 2. After operation stops, turn off the breaker for the room air conditioner.
- 3. Clean the air filters and set them again.
- 4. Take out batteries from the remote controller.

24

3.15 Troubleshooting

Trouble Shooting

■ These cases are not troubles.

The following cases are not air conditioner troubles but have some reasons. You may just continue using it.

Case	Explanation
Operation does not start soon. When ON/OFF button was pressed soon after operation was stopped. When the mode was reselected.	This is to protect the air conditioner. You should wait for about 3 minutes.
Hot air does not flow out soon after the start of heating operation.	The air conditioner is warming up. You should wait for 1 to 4 minutes.
Makes a noise.	Clicking sound can be heard either when the unit is running or stopped This is either the sound of the valves regulating the refrigerant or the electrical parts working. Sound of running water Refrigerant is flowing through the air conditioner. Blowing sound The flow of refrigerant through the air conditioner is switching. Creaking sound The air conditioner itself is expanding or shrinking due to a change in the humidity. Clopping sound Can be heard coming from inside the air conditioner when the ventilator is on and the room is shut. Open a window or turn off the ventilator. Clicking sound can be heard either when the unit is running or stopped This is the sound of the electrical parts working when the front panel opens or closes. Blowing, cracky or burning sound This is the sound of streamer discharging.
Fizzes during HUMIDIFYING or VENTILATING operation.	This is the sound of humidified or ventilated air being discharged. The operation noise may change depending on the outdoor temperature and humidity.
Makes a sound during HUMIDIFYING operation.	Operation noise changes This is because the fan for humidification moves or stops.
The indoor unit makes a noise even after HUMIDIFYING operation is stopped.	The fan for humidification rotates for about 3 minutes after the operation stops for product protection.
Units stops during HEATING and the sound of running water can be heard.	The frost on the outdoor unit is being removed. You should wait for about 3 to 10 minutes.
The outdoor unit emits water or steam.	 In HEATING operation The frost on the outdoor unit melts into water or steam when the air conditioner is in defrost operation In COOLING operation Moisture in the air condenses into water on the cool surface of outdoor unit piping and drips.
Mist comes out of the indoor unit.	This happens when the air in the room is cooled into mist by the cold air flow during COOLING operation. This is because moisture on the heat exchanger evaporates when "SARARA" DRYING operation is run after COOLING or DRY COOLING operation.
The indoor unit gives out odor.	This happens when smells of the room, furniture, or cigarettes are absorbed into the unit and discharged with the air flow. (If this happens, we recommend you to have the indoor unit washed by a technician. Consult the service shop where you bought the air conditioner.) The outdoor odor may be captured. Stop the "URURU" HUMIDIFYING operation to eliminate the cause of odor.
Cold air blows at the start of "SARARA" DRYING operation.	This is because the air conditioner is not warmed up.
The outdoor fan rotates while the air conditioner is not in operation.	 After operation is stopped: The outdoor fan continues rotating for another 60 seconds for system protection. While the air conditioner is not in operation: When the outdoor temperature is very high, the outdoor fan starts rotating for system protection.
The operation stopped suddenly. (Multi-colored indicator lamp is on.)	For system protection, the air conditioner may stop operating on a sudden large voltage fluctuation. It automatically resumes operation in about 3 minutes.
Unit stops suddenly (when in ON TIMER mode).	Reserving the on timer will cause the unit to start running up 1 hour before, in order to make sure the temperature reaches the temperature set on the remote controller by the set time. Using the remote controller during this time (other than the operation/stop button) will stop the unit. Restart the unit with the remote controller.
Unit operates even though the multi- colored indicator lamp is off.	The multi-colored indicator lamp will go off if "Monitor OFF" is set using the remote controller.
Unit continues to operate even after "SARARA" DRYING, DRY COOLING or COOLING operation is stopped.	The MOLD PROOF operation will start. (If you don't want it, set to "MOLD PROOF OFF" using the remote controller. (page 15.))
Room lamp flickers during HUMIDIFYING operation.	It might happen the flickers of lighting in the case of insufficient power supply.

25

■ Check again.

Please check again before calling a repair person.

Case	Check
The air conditioner does not operate. (Multi-colored indicator lamp is off.)	 Hasn't a breaker turned OFF or a fuse blown? Isn't it a power failure? Are batteries set in the remote controller? Is the timer setting correct?
The air conditioner does not operate. (Multi-colored indicator lamp flashes.)	 Turn off the breaker and then start the unit using the remote controller. If the lamp still flashes, consult the service shop where you bought the air conditioner. Turn off the breaker.
Operation stops suddenly. (Multi-colored indicator lamp flashes.)	 Are the air filters clean? Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? Clean the air filters or take all obstacles away and turn the breaker OFF. Then turn it ON again and try operating the air conditioner with the remote controller. If the lamp still flashes, consult the service shop where you bought the air conditioner. Turn off the breaker.
Cooling (Heating) effect is poor.	 Are the air filters clean? Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? Is the temperature setting appropriate? Are the windows and doors closed? Are the air flow rate and the air direction set appropriately? Is the ventilator fan spinning?
An abnormal functioning happens during operation.	 Do you put your hand in the main unit while it is operating? (Do you touch inside the unit?) Putting your hand (or touching) inside the unit may cause malfunctions due to static discharge. Do not put your hand in the main unit. The air conditioner may malfunction with lightning or radio waves. Turn the breaker OFF, turn it ON again and try operating the air conditioner with the remote controller.
Front panel does not open. (Multi-colored indicator lamp flashes.)	Is there something caught in the front panel? Remove the object and attempt operation again using the remote controller. If the panel still does not open, contact your dealer if the operation lamp is still flashing.
The multi-colored indicator lamp flashes for a certain amount of time (about 2 minutes) at the start of or during FLASH STREAMER AIR PURIFYING operation.	 Is the streamer unit installed securely? Turn off the breaker, check to see if the streamer unit is installed securely, turn the power on, and then operate the unit again using the remote controller. If the lamp still flashes, consult the service shop where you bought the air conditioner.

Trouble Shooting

■ Call the service shop immediately.

№ WARNING

When an abnormality (such as a burning smell) occurs, stop operation and turn the breaker OFF. Continued operation in an abnormal condition may result in troubles, electric shocks or fire. Consult the service shop where you bought the air conditioner.

■ Do not attempt to repair or modify the air conditioner by yourself. Incorrect work may result in electric shocks or fire.

Consult the service shop where you bought the air conditioner.

If the air conditioner does not cool (or heat), leaking refrigerant is a possible cause, so please contact your dealer. Please talk to a service repairman about any repairs needed when adding refrigerant.

Refrigerant used for the air conditioner is safe. Refrigerant does not leak usually, but if it leaks into the room and comes in contact with any kind of flame, including those in fan heaters, gas stoves, gas heaters, etc., toxic gas may be generated.

If one of the following symptoms takes place, call the service shop immediately.

- The power cord is abnormally hot or damaged.
- An abnormal sound is heard during operation.
- An object or water got into the unit.
- The safety breaker, a fuse, or the earth leakage breaker cuts off the operation frequently.
- A switch or a button often fails to work properly.
- There is a burning smell.
- Water leaks from the indoor unit.
- Cool or warm air comes from the unit but the multi-colored indicator lamp blinks for a certain amount of time (about 2 minutes) at the start of or during operation.



Turn the breaker OFF and call the service shop.



This indicates the malfunction or initial failure of the humidifying unit or some sensors. The unit is operating in COOLING / HEATING mode as a temporary operation. Contact your dealer.



■ After a power failure

The air conditioner automatically resumes operation in about 3 minutes. You should just wait for a while.

• MOLD SHOCK OUT mode, MOLD PROOF mode and COMFORT SLEEP mode will be canceled. Re-set.

■ Lightning

If lightning may strike the neighbouring area, stop operation and turn the breaker OFF for system protection.

Disposal requirements



Your air conditioning product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.

Do not try to dismantle the system yourself: the dismantling of the air conditioning system, treatment of the refrigerant, of oil and of other parts must be done by a qualified installer in accordance with relevant local and national legislation.

Air conditioners must be treated at a specialized treatment facility for re-use, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. Please contact the installer or local authority for more information.

Batteries must be removed from the remote controller and disposed of separately in accordance with relevant local and national legislation.

We recommend periodical maintenance.


In certain operating conditions, the inside of the air conditioner may get foul after several seasons of use, resulting in poor performance. It is recommended to have periodical maintenance by a specialist aside from regular cleaning by the user. For specialist maintenance, contact the service shop where you bought the air conditioner.

The maintenance cost must be born by the user.

■ FAULT DIAGNOSIS BY REMOTE CONTROLLER

In the ARC447A1, the temperature display sections on the main unit indicate corresponding codes.

1. When the CANCEL button is held down for 5 seconds, a "@" indication flashes on the temperature display section.



2. Press the CANCEL button repeatedly until a continuous beep is produced.

• The code indication changes as shown below, and notifies with a long beep.

	CODE	MEANING
SYSTEM	00	NORMAL
	UA	INDOOR-OUTDOOR UNIT COMBINATION FAULT
	U0	REFRIGERANT SHORTAGE
	U2	DROP VOLTAGE OR MAIN CIRCUIT OVERVOLTAGE
	U4	FAILURE OF TRANSMISSION (BETWEEN INDOOR UNIT AND OUTDOOR UNIT)
	U7	CIRCUIT BOARD TRANSMISSION FAULT
INDOOR UNIT	AH	STREAMER FAULT
	A1	INDOOR PCB DEFECTIVENESS
	A5	HIGH PRESSURE CONTROL OR FREEZE-UP PROTECTOR
	A6	FAN MOTOR FAULT
	CC	HUMIDITY SENSOR FAULT
	C4	FAULTY HEAT EXCHANGER TEMPERATURE SENSOR
	C7	FRONT PANEL OPEN/CLOSE FAULT
	C9	FAULTY SUCTION AIR TEMPERATURE SENSOR
	UA	HOSE LENGTH NOT SET
	EA	COOLING-HEATING SWITCHING FAULT
	E1	CIRCUIT BOARD FAULT
OUTDOOR UNIT	E5	OL STARTED
	E6	FAULTY COMPRESSOR START UP
	E7	DC FAN MOTOR FAULT
	E8	OVERCURRENT INPUT
	FA	EJECTION PRESSURE FAULT
	F3	HIGH TEMPERATURE DISCHARGE PIPE CONTROL
	F6	HIGH PRESSURE CONTROL (IN COOLING)
	H0	SENSOR FAULT
	H1	DAMPER FAULT
	H6	OPERATION HALT DUE TO FAULTY POSITION DETECTION SENSOR
	H8	CT ABNORMALITY
	H9	FAULTY SUCTION AIR TEMPERATURE SENSOR
	J3	FAULTY DISCHARGE PIPE TEMPERATURE SENSOR
	J6	FAULTY HEAT EXCHANGER TEMPERATURE SENSOR
	L3	ELECTRICAL PARTS HEAT FAULT
	L4	HIGH TEMPERATURE AT INVERTER CIRCUIT HEATSINK
	L5	OUTPUT OVERCURRENT
	P4	FAULTY INVERTER CIRCUIT HEATSINK TEMPERATURE SENSOR
HUMIDIFY UNIT	PA	HEATER LINE BROKEN FAULT
	PH	HUMIDIFYING FAN OUTLET THERMISTOR FAULT, HEATER TEMPERATURE FAULT
	P9	HUMIDIFYING FAN LOCK
L	1	

NOTE

A short beep and two consecutive beeps indicate non-corresponding codes.
 To cancel the code display, hold the CANCEL button down for 5 seconds. The code display also cancel itself if the button is not pressed for 1

28

3P177300-1

Instruction SiBE04-624

134 System Configuration

Part 6 Service Diagnosis

	enient Service Check Function	. • .
Trou	bleshooting	139
2.1	Error Code Indication by Remote Controller	
2.2	Air conditioner does not run.	141
2.3	Air conditioner runs but does not get cooling (heating)	143
2.4	When operation starts, safety breaker works	145
2.5		
2.6	Air does not humidified enough	
2.7	Indoor Unit PCB Fault	150
2.8	Peak-cut Control or Freeze-up Protection	151
2.9	Fan Motor System (DC Motor) Fault	153
2.10	Streamer Unit Fault	155
2.11	Thermistor System Fault	157
2.12	Front Panel Open / Close Fault	158
2.13	Humidity Sensor Fault	159
2.14	Signal Transmission Error (Indoor Unit - Outdoor Unit)	160
2.15	Incompatible Power Supply between Indoor Unit and Outdoor Unit	162
2.16	Incomplete Setting for Hose Length	163
2.17	Outdoor Unit PCB Fault	164
2.18	OL Activation (Compressor Overload)	165
2.19	Compressor Lock	166
2.20	DC Fan Lock	167
2.21	Input Over Current Detection	168
2.22	Four Way Valve Fault	170
2.23	Discharge Pipe Temperature Control	172
2.24	High Pressure Control in Cooling	173
2.25	Compressor Sensor System Fault	175
2.26	Damper Fault	176
2.27	Position Sensor Fault	177
	•	
	•	
	•	
	· · · · · · · · · · · · · · · · · · ·	
	· ·	
	· · · · · · · · · · · · · · · · · · ·	
		197
2.39		
2.40	Lights-out of Microcomputer Status Lamp	201
Chec		
3.1	Thermistor Resistance Check	202
	2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8 2.10 2.11 2.12 2.13 2.14 2.15 2.16 2.17 2.18 2.20 2.21 2.22 2.23 2.24 2.25 2.26 2.27 2.30 2.31 2.32 2.33 2.34 2.35 2.36 2.37 2.38 2.39 2.30 2.31 2.32 2.33 2.34 2.35 2.36 2.37 2.38 2.39 2.30 2.30 2.30 2.30 2.30 2.30 2.30 2.30	2.2 Air conditioner does not run. 2.3 Air conditioner runs but does not get cooling (heating). 2.4 When operation starts, safety breaker works. 2.5 Air conditioner makes big noise and vibration. 2.6 Air does not humidified enough. 2.7 Indoor Unit PCB Fault. 2.8 Peak-cut Control or Freeze-up Protection. 2.9 Fan Motor System (DC Motor) Fault. 2.10 Streamer Unit Fault. 2.11 Thermistor System Fault. 2.12 Front Panel Open / Close Fault. 2.13 Humidity Sensor Fault. 2.14 Signal Transmission Error (Indoor Unit - Outdoor Unit). 2.15 Incompatible Power Supply between Indoor Unit and Outdoor Unit . 2.16 Incomplete Setting for Hose Length. 2.17 Outdoor Unit PCB Fault. 2.18 OL Activation (Compressor Overload). 2.19 Compressor Lock. 2.20 DC Fan Lock. 2.21 Input Over Current Detection. 2.22 Four Way Valve Fault. 2.23 Discharge Pipe Temperature Control. 2.24 High Pressure Control in Cooling. 2.25 Compressor Sensor System Fault. 2.26 Damper Fault. 2.27 Position Sensor Fault. 2.28 DC Voltage / DC Current Sensor Fault. 2.29 Thermistor System Fault. 2.29 Thermistor System Fault. 2.29 Thermistor System Fault. 2.30 Abnormal Temperature in Electrical Box 2.31 Temperature Rise in Radiation Fin. 2.32 Output Overcurrent. 2.33 Insufficient Gas. 2.34 Over Voltage Protection / Low Voltage Protection 2.35 Outdoor Unit PCB Fault or Communication Circuit Fault. 2.36 Signal Transmission Error on Outdoor Unit PCB 2.37 Fan Motor System Fault / Fan Lock 2.38 Heater Wire Fault . 2.39 Humidification Fan Outlet Thermistor Fault / Abnormal Heater Temperature. 2.40 Lights-out of Microcomputer Status Lamp. Check.


3.2	Installation Condition Check	203
3.3	Outdoor Fan System Check (DC Motor)	203
3.4	Power Supply Waveform Check	204
3.5	Capacitor Voltage Check	204
3.6	Main Circuit Electrolytic Capacitor Check	205
3.7	Refrigerant System Check	205
3.8	"Inverter Checker" Check	206
3.9	Power Transistor Check	207
3.10	Discharge Pressure Check	208
3.11	Electronic Expansion Valve Check	209
3.12	Indoor Unit PCB Output Check	210
3.13	Rotating Pulse Input on Outdoor Unit PCB Check	211
3.14	Humidity Sensor Check	212
3.15	Main Circuit Short Check	212
3.16	Four-way Valve Performance Check	213
3.17	Solenoid Valve for Dehumidification Check	214

1. Convenient Service Check Function

■ Failure diagnosis with operation lamp

The operation lamp on the display of the indoor unit flashes when any of the following failure is detected.

- 1. When a protection device of the indoor or outdoor unit is activated or when the thermistor malfunctions and the machine does not work.
- 2. When a signal transmission error occurs between the indoor and outdoor units. For detailed troubleshooting, refer to the following pages "Troubleshooting" (139~).




■ Failure diagnosis by remote controller

With the wireless remote controller supplied with the unit, or sold separately, error codes by failure diagnosis can be confirmed. (Press timer cancel button down for 5 seconds continuously.)

ARC447A series

(R5904)



(R5075)

- 1. Hold the timer cancel button down for 5 seconds, with the remote controller set toward the indoor unit.
- 2. The temperature display on the remote controller changes to the error code display and a long beep notifies this indication change.


<Note>

To cancel indication of error code, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.

■ Failure diagnosis by LED indication

The following failure diagnosis can be done by LED indication on the outdoor unit PCB.

The outdoor unit has 2 green LED(LED A, LED5) on the PCB.
 The flashing green LED indicates "in order" condition.
 The turned ON or OFF LED indicates the failure related to the microcomputer.



- PCB is set upside down (with backside up) to improve its quality.
- LED can be visually inspected through a inspection slit.

2. Troubleshooting

2.1 Error Code Indication by Remote Controller

* Various cases may be possible.

Code	Unit	Description	Reference page
		Air conditioner does not run.	141
		Air conditioner runs but does not get cooling (heating).	143
Basic Fail	lure Diagnosis	When operation starts, safety breaker works.	145
		Air conditioner makes big noise and vibration.	147
0.1		Air does not humidified enough.	148
8 !		Indoor unit PCB fault	150
85		Peak-cut control or freeze-up protection	151
88		Fan motor system fault	153
88	Indoor	Streamer unit fault	155
54	ilidool	Indoor heat exchanger thermistor fault	157
[7		Front panel open / close fault	158
£3		Room temperature thermistor fault	157
££		Humidity sensor fault	159
ε:		Outdoor unit PCB fault	164
85		OL activation (compressor overload)	165
88		Compressor lock	166
٤٦		DC fan lock	167
83	Outdoor	Input overcurrent detection	168
83		Four way valve fault	170
F3		Discharge pipe temperature control	172
۶8		High pressure control in cooling	173
H0		Compressor sensor system fault	175
81	Humidifying unit	Damper fault	176
8 8		Position sensor fault	177
H8		DC voltage / DC current sensor fault	179
XS		Outdoor air thermistor fault	180
J3		Discharge pipe thermistor fault	180
J5	Outdoor	Outdoor heat exchanger thermistor fault	180
13		Abnormal temperature in electrical box	182
٤4		Temperature rise in radiation fin	184
45		Output overcurrent	186
py		Radiation fin thermistor fault	180
23		Fan motor system fault / fan lock	196
28	Humidifying unit	Heater wire fault	197
PH		Humidification fan outlet thermistor fault / abnormal heater temperature	199
LICI LICI		Insufficient gas	141
U2	System	Over voltage protection (OVP) / low voltage protection (LVP)	143
UY		Signal transmission error (indoor unit - outdoor unit)	160
٠,	Outdoor	Outdoor unit PCB fault or communication circuit fault	191

Code	Unit	Description	Reference page
U7	System	Signal transmission error on outdoor unit PCB	194
110	UR System	Incompatible power supply between indoor unit and outdoor unit	162
CI I	Indoor	Incomplete setting for hose length	163
_	System	Lights-out of microcomputer status lamp	201

2.2 Air conditioner does not run.


Method of Malfunction Detection

Malfunction Decision Conditions

Supposed Causes

- Power supply is OFF
- Improper power supply voltage
- Improper connection of wire
- Incorrect combination of indoor unit and outdoor unit
- Battery shortage of remote controller
- Invalid address setting
- Protection device works (dirty air filter, insufficient gas, over filling, mixed air, etc.)
- Transmission error between indoor unit and outdoor unit (Defective PCB on outdoor unit)

Troubleshooting



2.3 Air conditioner runs but does not get cooling (heating).

Method of Malfunction Detection

Malfunction Decision Conditions


Supposed Causes

- Incorrect temperature setting
- Incorrect combination of indoor unit and outdoor unit
- Blocked air filter
- Insufficient power
- Refrigerant piping is too long
- Improper setting of piping length
- Defective field piping (squeezed, etc.)

Troubleshooting



Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.





When an air conditioner does not cool or heat the room, refrigerant leak is considered to be one of the reasons.

Make sure that there is no gas leakage or breaks due to over tightened flare part. (Though the refrigerant used in an air conditioner is itself harmless, but it can generate toxic gases when it leaks into room and contacts flames, such as fan and other heaters, stoves, and ranges. In case of leakage, ventilate the room immediately.)

2.4 When operation starts, safety breaker works.

Method of Malfunction Detection

Malfunction Decision Conditions


Supposed Causes


- Insufficient capacity of safety breaker
- Earth leakage breaker is too sensitive
- Not exclusive circuit
- The supply voltage is not within rated voltage ±10%.
- The size of connecting wire is thin (indoor power supply unit)
- Air is mixed (over filling)
- Damaged outdoor unit PCB (short circuit)

Troubleshooting



Check No.29 Refer to 212





2.5 Air conditioner makes big noise and vibration.

Method of Malfunction Detection

Malfunction Decision Conditions


Supposed Causes

- Piping length is too short
- Mounting wall is too thin
- Insufficient vibration prevention measures
- Deformation of the unit
- Improper quantity of refrigerant

Troubleshooting



Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



2.6 Air does not humidified enough.


Method of Malfunction Detection

Malfunction Decision Conditions

Supposed Causes

- Hose length is not set
- Incorrect setting
- Short circuited at outdoor unit
- Blocked humidification filter
- Insufficient heat insulation of duct
- Indoor ventilation is made too often
- Ceiling is very high.

Troubleshooting



2.7 Indoor Unit PCB Fault

Remote Controller Display

8:

Method of Malfunction Detection

Check zero-cross detection from the power supply of the indoor unit

Malfunction Decision Conditions When no zero-cross detection is performed in approximately 10 continuous seconds


Supposed Causes

- Defective indoor unit PCB (Faulty EEPROM data)
- Improper connector connection
- Defective indoor terminal board

Troubleshooting

Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



i Not

■ Between terminal board and indoor control PCB.

2.8 Peak-cut Control or Freeze-up Protection

Remote Controller Display

85

Method of Malfunction Detection

Peak-cut control (high pressure control)
During heating operation, the temperature detected by the indoor heat exchanger thermistor is used for the high pressure control (stop, outdoor fan stop, etc.).

■ Freeze-up protection control (operation halt) is activated during cooling operation according to the temperature detected by the indoor heat exchanger thermistor.

Malfunction Decision Conditions

■ Peak-cut control

On heating operation, when indoor heat exchanger temperature is about 65°C or more

■ Freeze-up protection
On cooling operation, indoor heat exchanger temperature is 0°C or less

Supposed Causes

- Halt due to dirty indoor unit filter
- Halt due to dirty indoor heat exchanger
- Halt due to short circuit
- Faulty detection due to defective indoor heat exchanger thermistor
- Reheating dehumidification solenoid valve remains closed (on cooling operation)
- Faulty detection due to defective indoor unit PCB


Troubleshooting





Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Check No.2 Refer to P.202



2.9 Fan Motor System (DC Motor) Fault

Remote Controller Display

85

Method of Malfunction Detection

The fan speed detected by the Hall IC during operation of high-pressure fan motor is used to determine abnormal fan operation.

Malfunction Decision Conditions When the detected fan speed is less than 50% of the HH tap under maximum fan motor rpm demanded


Supposed Causes

- Halt due to rare short circuit inside the fan motor
- Halt due to breakage of wire inside the fan motor
- Halt due to breakage of the lead wire of fan motor
- Faulty detection due to defective indoor control PCB


Troubleshooting







Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



154 Service Diagnosis

(R6003)

2.10 Streamer Unit Fault

Remote Controller Display RH

Method of Malfunction Detection

■ If the error repeats 3 times in air purifying operation.

■ Clearing condition: Continuous run for about 2 minutes (normal).

Malfunction Decision Conditions

Supposed


Causes

■ Short circuit caused by the dust or drip of water on the streamer unit electrode part.

■ Scratch or crack in the harness for the streamer unit.

■ Faulty indoor unit PCB

Troubleshooting



2.11 Thermistor System Fault

Remote Controller Display

Method of Malfunction Detection

Thermistor fault is detected based on the temperature determined by each thermistor

Malfunction Decision Conditions When power is supplied and the input of thermistor is 4.96 V or more or 0.04 V or less * (for reference)

In case of 120 Ω (equivalent to 212°C) or less or 1860 k Ω (equivalent to –50°C) or more

Supposed Causes


- Improper connector connection
- Defective thermistor
- Defective PCB for indoor unit control system
- Defective PCB for indoor humidity sensor

Troubleshooting Chart

Check No.2 Refer to P.202



Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



धः Indoor heat exchanger thermistor

£3: Room temperature thermistor

(R6005)

2.12 Front Panel Open / Close Fault

Remote Controller Display Method of Malfunction Detection

Malfunction Decision Conditions ■ The system will be shut down when the error occurs twice.


Supposed Causes

- Malfunction of the reduction motor
- Malfunction or deterioration of the front panel mechanism
- Malfunction of the limit switch

Troubleshooting

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Restart and check the movement.



(R3313

Note:

You cannot operate the unit by the remote controller when the front panel mechanism breaks down.

<To the dealers: temporary measure before repair>

- 1. Turn the breaker off.
- 2. Remove the front panel.
- Turn the breaker on.(Wait until the initialization finishes.)
- 4. Operate the unit by the indoor unit ON/OFF switch.

2.13 Humidity Sensor Fault

Remote Controller Display

Method of Malfunction Detection

Sensor faulty is detected by input value.

Malfunction Decision Conditions When the input from a temperature sensor is 4.96 V or more or 0.04 V or less*

Supposed Causes

- Improper connector connection
- Defective indoor control PCB
- Defective humidity sensor PCB


Troubleshooting



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Check No.27 Refer to P.212



\$\mathcal{L}\mathca

2.14 Signal Transmission Error (Indoor Unit - Outdoor Unit)

Remote Controller Display

Method of Malfunction Detection


The data sent from the outdoor unit is checked for problem.

Malfunction Decision Conditions When the data sent from the outdoor unit can not be received without error, or when the disable status of signal transmission continues for 15 sec. and the same status continuously repeats 3 times.

Supposed Causes

- Defective outdoor unit PCB
- Defective indoor unit PCB
- Signal transmission error between indoor and outdoor unit due to improper wiring
- Signal transmission error between indoor and outdoor unit due to breakage of relay wire (transmission wire)

Troubleshooting



(R6006)

2.15 Incompatible Power Supply between Indoor Unit and Outdoor Unit

Remote Controller Display

Method of Malfunction Detection


Check the incompatible power supply between indoor unit and outdoor unit by using signal transmission.

Method of Malfunction Detection In case that the indoor intake model is connected to outdoor intake model.

Supposed Causes

- Connected to wrong model
- Mounted improper indoor unit PCB
- Defective indoor unit PCB
- Mounted improper outdoor unit PCB or defective PCB

Troubleshooting



(R6007)

2.16 Incomplete Setting for Hose Length

Remote Controller Display

11151

Method of Malfunction Detection

This fault occurs when the humidification hose length is not stored in the EEPROMs of the indoor unit and the outdoor unit.

(Hose length is not stored at initial power on.)


Malfunction Decision Conditions When the humidification hose length is not stored in EEPROMs of the indoor unit and the outdoor unit.

Supposed Causes

Hose length is not set.

Hose length is erased by replacement of the indoor unit PCB or the outdoor unit PCB. (When both the indoor unit and the outdoor unit PCBs are replaced simultaneously, the set value is erased.)

Troubleshooting



Diagnosis by using the remote controller

WES

Set hose length by using the remote controller.

NO

To other "UA" fault diagnosis

(R3418)

2.17 Outdoor Unit PCB Fault

Remote Controller Display

E

Outdoor Unit LED Display

A⊕ 5 ⊕

Method of Malfunction Detection

- Detect within the programme of the microcomputer that the programme is in good running order.
- Detect input of zero-cross signal.


Malfunction Decision Conditions


- When the programme of the microcomputer is in bad running order.
- Zero-cross signal can not be detected.

Supposed Causes

- Out of control of microcomputer caused by external factors
 - Noise
 - Momentary fall of voltage
 - Momentary power loss
- Defective outdoor unit PCB
- Breakage of harness between PCBs

Troubleshooting





(R6008)

2.18 OL Activation (Compressor Overload)

Remote Controller Display <u>E5</u>

Method of Malfunction Detection

A compressor overload is detected through compressor OL.

Malfunction Decision Conditions

- If the compressor OL is activated twice, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).
- * The operating temperature condition is not specified.

Supposed Causes

- Refrigerant shortage
- Four way valve malfunctioning
- Outdoor unit PCB defective
- Water mixed in the local piping
- Electronic expansion valve defective
- Stop valve defective

Troubleshooting




Check No.17 Refer to P.209




Check No.31 Refer to P.213



Check No.12 Refer to P.205





2.19 Compressor Lock

Remote Controller Display

88

Outdoor Unit LED Display

A♦ 5 ♦ (-)

Method of Malfunction Detection Judging from current waveform generated when high-frequency voltage is applied to the compressor.

Malfunction Decision Conditions

- The machine is shut down when the fault count reaches 16.
- Clear condition: Continuous operation for 11 min. (without fault)

Supposed Causes

- Compressor lock
- Disconnection of compressor harness


Troubleshooting





Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Check No.14 Refer to P.206



2.20 DC Fan Lock

Remote Controller Display

Er

Outdoor Unit LED Display

A♦ 5 ♦ (-)

Method of Malfunction Detection

Identify the fan motor system fault based on fan speed detected by Hall IC during high pressure fan motor running.

Malfunction Decision Conditions

- When the fan motor is running, the fan does not rotate for 60 sec. or more.
- Shut down when the error repeats 16 times
- Clear condition: The fan continuously rotates for 11 min.(without fault)


Supposed Causes

- Failure in fan motor
- Disconnection or improper connection of harness/connector between fan motor and PCB
- The fan does not rotate because it gets caught in foreign matter

Troubleshooting



Check No.23 Refer to P.211 Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



2.21 Input Over Current Detection

Remote Controller Display

<u>E8</u>

Outdoor Unit LED Display

A۞ 5 ۞ (-)

Method of Malfunction Detection

Detect an input overcurrent by checking the inverter power consumption or the input current detected by CT with the compressor running.

Malfunction Decision Conditions

- When 14 A or more of inverter power consumption or CT input continues for 5 sec.
- The compressor stops if the error occurs, and restarts automatically after 3 minutes standby.

Supposed Causes

- Overcurrent due to defective compressor
- Overcurrent due to defective power transistor
- Overcurrent due to defective electrolytic capacitor of inverter main circuit
- Overcurrent due to defective outdoor unit PCB
- Detection error due to defective outdoor unit PCB
- Overcurrent due to short circuit

Troubleshooting



Check No.3 Refer to P.203




Check No.11 Refer to P.205




Check No.16 Refer to P.208



Check No.14 Refer to P.206



*Input over current may be caused by improper wiring inside the machine. If the machine stops due to input over current after connecting or disconnecting wires to replace part, check wiring for proper connection.



(R6012)

2.22 Four Way Valve Fault

Remote Controller Display

ER

Outdoor Unit LED Display

A → 5 → (-)

Method of Malfunction Detection

The room temperature thermistor, the indoor heat exchanger thermistor, the outdoor air thermistor, and the outdoor heat exchanger thermistor are checked to see if they function within their normal ranges in the operating mode.

Malfunction Decision Conditions

■ When one of the follow condition continues for 10 min, the compressor stops, and restarts automatically after 3 minutes standby.

Cooling / drying

(Room temperature – temperature of indoor heat exchanger) < – 5°C

Heating

(Temperature of indoor heat exchanger – room temperature) < – 5°C

- Shut down when the error repeats twice
- Clear condition: Continuous operation for 60 minutes.

Supposed Causes

- Improper connector connection
- Defective thermistor
- Defective outdoor unit PCB
- Defective coil or harness of 4-way valve
- Defective 4-way valve
- Insufficient gas
- Foreign substance mixed in refrigerant

Troubleshooting




Check No.2 Refer to P.202



Check No.12 Refer to P.205



Check No.31 Refer to P.213



2.23 Discharge Pipe Temperature Control

Remote Controller Display

F

Outdoor Unit LED Display

A⊕ 5⊕ (-)

Method of Malfunction Detection

Discharge pipe temperature control (stop, frequency attenuation, etc.) is executed based on the temperature detected by the discharge pipe thermistor.

Malfunction Decision Conditions

- The compressor stops when the discharge pipe temperature is 118°C or more. (Fault condition is cleared when the discharge pipe temperature is below 85°C)
- Shut down when the error repeats 4 times
- Clear condition : Continuous operation for 60 minutes

Supposed Causes

- Insufficient gas
- Faulty operation of 4-way valve
- Defective discharge pipe thermistor
 (Defective heat exchanger thermistor or outdoor air thermistor)
- Defective outdoor unit PCB
- Water mixed in the field piping
- Defective electronic expansion valve
- Defective stop valve
- Defective indoor solenoid valve

Troubleshooting



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.


Check No.2 Refer to P.202



Check No.12 Refer to P.205



Check No.17 Refer to P.209



2.24 High Pressure Control in Cooling

Remote Controller Display

FE

Outdoor Unit LED Display

A⊕ 5⊕ (-)

Method of Malfunction Detection


During cooling, high pressure control (stop, frequency attenuation, etc.) is executed according to the temperature detected by the heat exchanger thermistor.

Malfunction Decision Conditions During cooling, when the temperature detected by the heat exchanger thermistor is 63°C or more. (Fault condition is cleared when the temperature is below 52°C.)

Supposed Causes

- Insufficient installation space
- Defective outdoor fan
- Defective electronic expansion valve
- Defective heat exchanger thermistor
- Defective outdoor unit PCB
- Defective stop valve
- Defective solenoid valve for dehumidification

Troubleshooting



(R3433)

2.25 Compressor Sensor System Fault

Remote Controller Display

1117

Outdoor Unit LED Display

A: → 5: → (-)

Method of Malfunction Detection Fault condition is identified by DC current which is detected before compressor startup.

Malfunction Decision Conditions ■ When the DC current before compressor startup is other than 0.5 to 4.5 V (detected by converting the sensor output to voltage), or the DC voltage is 50 V or less.

Supposed Causes

- Defective PCB
- Harness disconnection / defective connection

Troubleshooting



Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Replace the outdoor unit PCB.

2.26 Damper Fault

Remote Controller Display

| | | |

Outdoor Unit LED Display

A**⊅** 5**⊅**

Method of Malfunction Detection

Detected by the limit switch (LS) in the humidification unit.

Malfunction Decision Conditions


■ Limit switch does not turn on or off when the operation of humidification unit starts or finishes. For example, when turning on the power supply, when humidification operation (including air intake) starts, or when inner heating dry cleaning starts.

Supposed Causes

- Faulty damper operation due to frost
- Faulty damper operation due to foreign material
- Limit switch fault (including improper connection)
- Defective motor for damper

Troubleshooting

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R3435)

2.27 Position Sensor Fault

Remote Controller Display

Outdoor Unit LED Display

A⊕ 5⊕ (-)

Method of Malfunction Detection

Startup failure of the compressor is identified by rpm information of the compressor and by electric component position detector.

Malfunction Decision Conditions

- When the compressor does not run for 15 sec. after receiving operation start command
- The machine shuts down if the fault occurs 16 times
- Clear condition: The compressor continuously runs for 10 min. without fault

Supposed Causes

- Detection error due to disconnection of compressor harness
- Startup failure due to defective compressor
- Startup failure due to defective outdoor unit PCB
- Startup failure due to closed stop valve
- Input voltage fault

Troubleshooting



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.


Check No.16 Refer to P.208



Check No.29 Refer to P.212



Check No.14 Refer to P.206



(R3436)

2.28 DC Voltage / DC Current Sensor Fault

Remote Controller Display

Outdoor Unit LED Display

A⊕ 5⊕ (-)

Method of Malfunction Detection

DC voltage or DC current sensor system fault is identified based on the compressor operation frequency and the input current detected by the product of DC current and DC voltage.

Malfunction Decision Conditions When the compressor operation frequency is more than 62 Hz and when the input current is less than 0.75 A for 90 sec. continuously (Input current is below 0.5 A)

- The machine shuts down when the fault occurs 4 times.
- Fault counter will be reset to zero if the machine will not stop during accumulated compressor operation time of 60 min. after restored from fault conditions.

Supposed Causes

■ Defective outdoor unit PCB

Troubleshooting



Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Replace the outdoor unit PCB.

2.29 Thermistor System Fault

Remote
Controller Display

<u>P4, 43, 46, 49</u>

Outdoor Unit LED Display

Method of Malfunction Detection This fault is identified based on the thermistor input voltage to the microcomputer.

A thermistor fault is identified based on the temperature detected by each thermistor.

Malfunction Decision Conditions When power is supplied and the thermistor input is 4.98 V or more or when the thermistor input is 0.02 V or less for 5 sec. continuously

For J3,

"Discharge pipe thermistor < heat exchanger thermistor" is take into consideration to identify the fault.


Supposed Causes


- Improper connection of connector
- Defective thermistor
- Defective indoor unit PCB
- For J3, defective heat exchanger thermistor (Cooling: outdoor heat exchanger thermistor, heating: indoor heat exchanger thermistor)

Troubleshooting



Check No.2 Refer to P.202





P3: Radiation fin thermistor

45: Outdoor heat exchanger thermistor

서명 : Outdoor air thermistor (R3441)

2.30 Abnormal Temperature in Electrical Box

Remote Controller Display

13

Outdoor Unit LED Display

Method of Malfunction Detection

Temperature rise in the electrical box is identified based on the temperature of the radiation fin detected by the fin thermistor with the compressor off.

Malfunction Decision Conditions When the temperature of the radiation fin is 122°C or more during the compressor off. (When the temperature drops below 113°C, fault condition is cleared.)

Supposed Causes

- Fin temperature rise due to defective outdoor fan
- Fin temperature rise due to short circuit
- Detection error due to defective fin thermistor
- Detection error due to improper connection of connector
- Detection error due to defective outdoor unit PCB

Troubleshooting




Check No.2 Refer to P.202



Check No.3 Refer to P.203



Check No.5 Refer to P.203



(R6014)

2.31 Temperature Rise in Radiation Fin

Remote Controller Display

14

Outdoor Unit LED Display

A⊕ 5⊕

Method of Malfunction Detection


Temperature rise in the radiation fin is identified based on the temperature of the radiation fin detected by the fin thermistor with the compressor on.

Malfunction Decision Conditions

- The compressor stops when the radiation fin temperature is 86 °C or more. (Fault condition is cleared when the radiation fin temperature is below 67 °C.)
- Shut down when the error repeats 255 times
- Clear condition : Continuous operation for 60 minutes

Supposed Causes

- Fin temperature rise due to defective outdoor fan
- Fin temperature rise due to short circuit
- Detection error due to defective fin thermistor
- Detection error due to improper connection of connector
- Detection error due to defective outdoor unit PCB



2.32 Output Overcurrent

Remote Controller Display

15

Outdoor Unit LED Display

A: 5: 5

Method of Malfunction Detection

An output overcurrent is detected by checking the current that flows in the inverter DC section.

Malfunction Decision Conditions

- A position signal error occurs while the compressor is running.
- A speed error occurs while the compressor is running.
- The machine shuts down when the signal of output overcurrent is sent 8 times from the output overcurrent detection circuit to the microcomputer.
- Clear condition: The machine continuously runs for about 11 min. (without fault)

Supposed Causes

- Overcurrent due to defective power transistor
- Overcurrent due to wrong internal wiring
- Overcurrent due to abnormal supply voltage
- Overcurrent due to defective PCB
- Detection error due to defective PCB
- Overcurrent due to closed stop valve
- Overcurrent due to defective compressor
- Overcurrent due to poor installation condition
- Defective indoor solenoid valve

Troubleshooting



Check No.3 Refer to P.203




Check No.15 Refer to P.207



Check No.16 Refer to P.208



Check No.14 Refer to P.206



2.33 Insufficient Gas

Remote Controller Display

111

Outdoor Unit LED Display

A⊕ 5⊕ (-)

Method of Malfunction Detection

Gas shortage detection I:

Gas shortage is detected by checking the input current value and the compressor running frequency. If the gas is short, the input current is smaller than the normal value.

Gas shortage detection III:

Gas shortage is detected by checking the difference between ambient temperature and heat exchanger temperature. If the gas is short, the difference is smaller than the normal value.

Malfunction Decision Conditions

Gas shortage detection I:

The following conditions continue for 7 minutes.

- Input current × input voltage ≤ 2800 / 256 × output frequency –350 (W)
- Output frequency > 54 (Hz)

Gas shortage detection III:

When the difference of the temperature is smaller than A, it is regarded as insufficient gas.

		\mathbb{A}
Cooling	room temperature — indoor heat exchanger temperature	4.0°C
Cooling	outdoor heat exchanger temperature — outdoor temperature	4.0°C
Llooting	indoor heat exchanger temperature — room temperature	4.0°C
Heating	outdoor temperature — outdoor heat exchanger temperature	4.0°C

If a gas shortage error takes place 4 times straight, the system will be shut down. The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed Causes

- Refrigerant shortage (refrigerant leakage)
- Refrigerant heat exchanger drift
- Poor compression performance of compressor
- Closed stop valve
- Defective electronic expansion valve
- Defective solenoid valve for dehumidifying


Troubleshooting



Check No.2 Refer to P.202



Check No.17 Refer to P.209



(R3446)

2.34 Over Voltage Protection / Low Voltage Protection

Remote Controller Display

Outdoor Unit LED Display

A⊕ 5⊕ (-)

Method of Malfunction Detection

Detect an abnormal increase or drop of voltage by the detection circuit or DC voltage detection

Malfunction Decision Conditions

- When an overcurrent signal is sent to the microcomputer from the overcurrent detection circuit, or the voltage detected by DC voltage detection circuit is less than 150 V and that voltage continues for about 0.1 sec.
- The machine shuts down if the fault conditions occurs 255 times
- Fault counter is reset when the machine continuously runs for 60 min. without fault.


Supposed Causes

- Abnormal supply voltage, momentary power failure
- Defective overcurrent detector or defective DC voltage detection circuit
- Failure in PAM controlled parts

Troubleshooting



Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



190 Service Diagnosis

(R3449)

2.35 Outdoor Unit PCB Fault or Communication Circuit Fault

Remote Controller Display	
Outdoor Unit LED Display	
Method of Malfunction Detection	
Malfunction	

A: → 5 -

- 1. Detect within the programme of the microcomputer that the programme is in good running order.
- 2. When indoor-outdoor unit signal transmission can not be performed for more than 15 sec.
- 3. Detection of the presence or absence of zero-cross signal.


Malfunction Decision Conditions

- 1. When the programme of the microcomputer is in bad running order.
- 2. When indoor-outdoor unit signal transmission can not be performed for more than 15 sec.
- 3. When zero-cross signal can not be detected for more than 10 sec.


Supposed Causes

- Display disabled due to power supply fault
- Communication circuit fault in outdoor unit PCB
- Out of control of microcomputer caused by external factors
 - Noise
 - Momentary voltage drop
 - Momentary power loss
- Defective outdoor unit PCB
- Defective thermal fuse in outdoor terminal board


Troubleshooting



Check indoor unit also, because a comunication circuit fault may be caused by the problem related to the indoor unit.








2.36 Signal Transmission Error on Outdoor Unit PCB

Remote **Controller Display Outdoor Unit LED A**∌ 5 (-) **Display Method of** Communication error between microcomputer mounted on the main body and inverter. Malfunction **Detection** Malfunction ■ When the data sent from the microcomputer of the inverter can not be received 15 times **Decision** successively or for 15 sec, the machine shuts down. ■ Fault counter is reset when the data from the microcomputer of the inverter can be **Conditions** successfully received. **Supposed** Defective outdoor unit PCB

Causes

Disconnection or breakage of harness between PCBs

Troubleshooting



(R6018)

2.37 Fan Motor System Fault / Fan Lock

Remote Controller Display

23

Outdoor Unit LED Display

Method of Malfunction Detection

During humidification fan motor running, fan motor system fault is identified based on the fan speed (rpm) detected by Hall IC.

Malfunction Decision Conditions

<Humidification fan>

When fan speed does not reach 100 rpm within 7 sec. after fan motor start up.

Supposed Causes


<Humidification fan>

- Defective motor for humidification fan
- Breakage of relay harness or loose connector
- Detection fault of fan speed due to defective outdoor unit PCB

Troubleshooting



Check No.23 Refer to P.211 Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



2.38 Heater Wire Fault

Remote Controller Display

FR

Outdoor Unit LED Display

A⊕ 5⊕

Method of Malfunction Detection

A fault is identified when the outlet temperature of humidification fan does not reach a certain temperature within a given time after the heater turned on.

Malfunction Decision Conditions When the temperature detected by the thermistor is lower than the outdoor temperature (at heater turned off) + 6°C, and this condition continues for 30 min.


Supposed Causes

- Breakage of heater filament
- Breakage of heater harness
- Abnormal temperature detected by outdoor temperature thermistor
- Abnormal temperature detected by humidification fan outlet thermistor
- Damaged main relay
- Blown thermal fuse
- Damaged heater control part
- Extremely low voltage

Troubleshooting



Check No.2 Refer to P.202



2.39 Humidification Fan Outlet Thermistor Fault / Abnormal Heater Temperature

Remote Controller Display

PH

Outdoor Unit LED Display

A⊕ 5⊕

Method of Malfunction Detection

Detect short circuit and wire breakage of humidification thermistor.

When humidification fan outlet temperature becomes high, this condition is identified as an abnormal heater temperature fault.

Malfunction Decision Conditions When power is supplied and the thermistor input is 4.90 V or more, or 0.06 V or less. If the humidification fan outlet temperature is more than 90°C, this condition is identified as abnormal heater temperature fault.

Supposed Causes

- Short circuit and wire breakage of humidification thermistor
- Disconnected connector
- Heater has a high power
- Thermistor temperature detection error
- Defective rotor motor
- Defective dehumidification fan motor
- Defective heater control part
- Defective humidification fan


Troubleshooting



Check No.2 Refer to P.202



Check No.5 Refer to P.203



2.40 Lights-out of Microcomputer Status Lamp

Remote Controller Display

Outdoor Unit LED Display

A ● 5 ● (-)


Method of Malfunction Detection When a microcomputer fault is detected, LED A or LED 5 turns off.


Malfunction Decision Conditions

Supposed Causes

- Outdoor unit PCB is not power supplied
- Power supply failure due to noise

Troubleshooting





Check SiBE04-624

3. Check


3.1 Thermistor Resistance Check

Check No.2

Remove the connectors of the thermistors on the PCB, and measure the resistance of each thermistor using tester.

The relationship between normal temperature and resistance is shown in the graph and the table below.

	Thermistor	R25°C=20kΩ B=3950
Temperature (°C)		
-20		211.0 (kΩ)
–15		150
-10		116.5
- 5		88
0		67.2
5		51.9
10		40
15		31.8
20		25
25		20
30		16
35		13
40		10.6
45		8.7
50		7.2




■ For the models in which the thermistor is directly mounted on the PCB.



SiBE04-624 Check

3.2 Installation Condition Check


Check No.3



3.3 Outdoor Fan System Check (DC Motor)

Check No.5





(R3756)

Check SiBE04-624


3.4 Power Supply Waveform Check

Check No.8

Check the voltage waveform between power supply terminals on the terminal board for disturbance using oscillo-tester.

- Check to see if the power supply waveform is a sine wave (Fig.1).
- Check to see if there is waveform disturbance near the zero cross (sections circled in Fig.2)

[Fig.1] [Fig.2]




3.5 Capacitor Voltage Check

Check No.10

Before this checking, be sure to check the main circuit for short-circuit (Check No 29).

- Checking the capacitor voltage
- With the circuit breaker still on, measure the voltage according to the drawing of the model in question. Be careful never to touch any live parts.




SiBE04-624 Check

3.6 Main Circuit Electrolytic Capacitor Check


Check No.11

- Do not touch the live parts within 10 min. after the breaker is turned off.
- Even after that, when you touch the parts, check that there is no DC voltage with a tester.
- Check the conductivity with a tester. It is OK if the tester shows good conductivity when pins are replaced.



3.7 Refrigerant System Check

Check No.12



(110022)

Check SiBE04-624

3.8 "Inverter Checker" Check

Check No.14


1. Characteristics

If abnormal stop occurs due to compressor startup failure or overcurrent output when using inverter unit, it is difficult to judge it results from the compressor failure or other failure (control PC board, power transistor, etc.). The inverter analyzer makes it possible to judge the cause of trouble easily and securely. (Connect this analyzer as a quasi compressor instead of compressor and check the output of inverter)

2. Operation Method

- 1) Be sure to turn the power off.
- 2) Install the Inverter Analyzer instead of a compressor.

Note: Make sure the charged voltage of the built-in smoothing electrolytic capacitor drops to 10 VDC or below before carrying out the service work.



Reference

If the connector terminal of compressor is not a faston terminal (difficult to remove the wire on the terminal), it is possible to connect a wire available on site to the unit from output side of PC board. (Do not connect it to the compressor at the same time, otherwise it may result in incorrect detection.)

3) Turn the power on and operate the air conditioner.

3. Diagnose method (Diagnose can be made according to 6 LEDs lighting status as follows:)

- (1) When all LEDs are lit uniformly, \rightarrow Compressor malfunction (to be replaced)
- (2) When some of LEDs are not lit (LEDs are not lit or go off, etc.): Check the individual power transistor. (Refer to check No.15)
- * When the power transistor and control PC board are integrated:
 - → Replace the control PC board.
- * When the power transistor can be checked individually :
 - ↓ Check the resistance value. (Refer to check No.15)

If NG : \rightarrow The power transistor may have a failure. (Replace the power transistor).

If the power transistor is normal, check if there is any solder cracking on filter PC board.

- * If any solder cracking is found: → Replace the filter PC board (or repair the soldered section).
- * If filter PC board is normal: → Replace the control PC board.


SiBE04-624 Check

Caution

1) When the output frequency is low, the LED flashes slowly. As the frequency increases, the LED flashes quickly. (It looks like the LED is lit)

- ② If the operation is carried out with no load (the condition of the compressor is disconnected), some of units may stop operation with "CT system error" (due to no electric current) or "startup failure" (because the compressor does not turn). In this case, check if the LED is flashing during "operation" to "malfunction stop". (Refer to the service manual of each air conditioner for checking whether the alarm LEDs for CT system, startup failure, etc. are provided or not.)
- ③ On completion of diagnose by this checker, be sure to re-crimp the faston terminal for resetting the system.

(Otherwise, the terminal may be burned due to loosening.)



How to activate the inverter test mode

- 1) Hold the "CLOCK" button for 5 seconds.

 (The matrix display will appear on the remote controller.)
- 2) Display " SETTING on the matrix display of the remote controller and press the "CLOCK" button.
- 3) "7" will be displayed.
- 4) Press the "CLEAN / FRESH" button for inverter test mode.

3.9 Power Transistor Check

Check No.15


- Do not touch the live parts within 10 min. after the breaker is turned off.
- Even after that, when you touch the parts, check to see that supply voltage of the power transistor is less than 50 V with a tester.
- Measure resistance at connector terminal on PCB or at the relay connector.

(-) terminal of a tester	Power transistor (+)	UVW	Power transistor (–)	UVW
(+) terminal of a tester	UVW	Power transistor (+)	UVW	Power transistor (–)
Resistance in OK	several k Ω ~several M Ω			
Resistance in NG	0 or ∞			

Check SiBE04-624

3.10 Discharge Pressure Check

Check No.16




SiBE04-624 Check

3.11 Electronic Expansion Valve Check

Check No.17

Check the electronic expansion valve (EV) as follows:

- Check if the EV connector properly inserted into the control PCB. Collate the number of EV main body with that of the connector.
- 2. Check to see that clatter (latching sound) is heard from all of the EVs when turning on the power supply again after turning it off.
- 3. If there are EVs which do not sound clatter, disconnect the connectors of these EVs and check them for conductivity.



(R6028

- 4. If there is no clatter (latching sound) on all of the EVs in step 2, the outdoor PCB is defective.
- 5. For EVs for which conductivity is established in step 3, connect the coil which sounded clatter to the EV main body which did not sound, and make sure the latching sound be heard again.

If latching sound is heard, outdoor unit PCB is defective.

If there is no latching sound, the EV main body is defective.



Latching sound varies by each valve.

Check SiBE04-624


3.12 Indoor Unit PCB Output Check

Check No.18

<Control PCB (A1P)>

- 1. Check for proper connection.
- 2. Check that the supply voltage applied to the motor is output between No.4 pin and No.7 pin).
- 3. Check that the motor control voltage is output (between No.3 pin and No.4 pin).

Check that the rpm command voltage is output (between No.2 pin and No.4 pin).



(R4023)

SiBE04-624 Check

3.13 Rotating Pulse Input on Outdoor Unit PCB Check

Check No.23

< For propeller fan motor or humidification fan>

Make sure voltage of $270 \pm 30 \text{ V}$ is applied.

- 1. Set power ON and operation OFF. Remove connector S70 or S72.
- 2. Check that the voltage between No. 4 pin and No.7 pin is 270 VDC.
- 3. Check that the control voltage between No. 3 pin and No. 4 pin is 15 VDC.
- 4. Check that the RPM command voltage between No. 2 pin and No. 4 pin is 5 VDC.
- 5. Set power OFF and operation OFF. Connect connector S70 or S72.
- 6. Check whether two pulses (0 15 V) are input at No. 1 pin and No. 4 pin when the fan motor is rotated 1 turn by hand.

Fuses are commonly used as follows. Refer to the corresponding circuit diagram.


FU1	SW power supply 4-way valve Hygroscopic fan
FU2	Outdoor fan Humidification fan

When FU2 is melted, check outdoor fan for proper function.

If NG in step 2 \rightarrow Defective PCB \rightarrow Replace the PCB.

If NG in step $4 \rightarrow$ Defective Hall IC \rightarrow Replace the DC fan motor.

If OK in both steps 2 and $4 \rightarrow$ Replace the PCB.



(R3477)

■ Propeller fan motor: S70, Humidification fan motor: S72

<For Hygroscopic fan>

Check that the connectors HK1, HK2, HK3 for proper connection.

- 1. Check that the supply voltage between HK1 and HK3 is 5VDC. *Check when the machine is not in suspend mode.
- 2. If NG in step 1 \rightarrow Defective PCB \rightarrow Replace the PCB.

FU1	SW power supply 4-way valve Hygroscopic fan
FU2	Outdoor fan Humidification fan


Therefore, when the FU2 is melted, check rotor motor for proper function.

Check SiBE04-624

3.14 Humidity Sensor Check

Check No.27

- 1. Check for proper connection.
- 2. Check sensor input level (*1).
- 3. Change ambient conditions (*2) and check that input level changes accordingly.
 - *1 Input level varies depending on the sensor.
 - *2 Changes in humidity, temperature, air flow rate. To do this, merely breathe upon.



(R6023)

3.15 Main Circuit Short Check

Check No.29

- Measure the resistance between pins at both ends of DB1.
- If the resistance is ∞ or less than 1 kΩ, the main circuit short.

(-) terminal of the tester (in case of digital, (+) terminal)	(~)	(+)	(~)	(-)
(+) terminal of the tester (in case of digital, (-) terminal)	(+)	(~)	(-)	(~)
Resistance in OK	several k Ω ~several M Ω	8	∞	several k Ω ~several M Ω
Resistance in NG	0 or ∞	0	0	0 or ∞


SiBE04-624 Check

3.16 Four-way Valve Performance Check

Check No.31

< Caution on resetting the power supply >

* Be sure to wait for 30 sec. or more after turning off the power supply.




Check SiBE04-624

3.17 Solenoid Valve for Dehumidification Check

Check No.32

Faulty criterion:

In dehumidification test operation mode, PCB is identified as a faulty when the solenoid valve does not turn on within 2 sec. after compressor start-up. (When reheating dehumidifying is not used, the operation mode is similar to cooling operation.)



(R6026)

Part 7 Removal Procedure


1.	Indo	or Unit	.216
	1.1	Removal of the Air Filters / Front panel	216
	1.2	Removal of the Upper Panel	222
	1.3	Removal of the Front Grille	225
	1.4	Removal of the Assembly of the Open/Close Mechanism	228
	1.5	Removal of the Assembly of the Reduction Motor	230
	1.6	Removal of the Electrical Box	233
	1.7	Removal of the PCB	238
	1.8	Removal of the Dehumidifying Solenoid Valve Coil	244
	1.9	Removal of the Connecting Duct	245
	1.10	Removal of the Drain Hose	247
	1.11	Removal of the Swing Motor	249
	1.12	Removal of the Heat Exchanger	251
	1.13	Removal of the Propeller Fan / Fan Motor	254
	1.14	Removal of Horizontal Blades / Vertical Blades	257
	1.15	Removal of the Streamer Unit	259
2.	Outd	oor Unit	.263
	2.1	Removal of the Humidify Unit	263
	2.2	Removal of the Heater Assembly / Humidifying Rotor	
		(Moisture Absorption Element) / Humidifying Rotor Motor	266
	2.3	Removal of the Humidifying Assembly	270
	2.4	Removal of the Moisture Absorption Fan Motor	273
	2.5	Removal of the Propeller Fan / Fan Motor	274
	2.6	Removal of the Duct in Humidifier	279
	2.7	Removal of the Electrical Box	280
	2.8	Removal of the PCB	284
	2.9	Removal of the Sound Blanket	287
	2.10	Remove the Thermistor Assembly	289
	2.11	Removal of the Reactor / Partition Plate	291
	2.12	Removal of the Four Way Valve	292
	2.13	Removal of the Expansion Valve	294
	2.14	Removal of the Compressor	295


1. Indoor Unit


1.1 Removal of the Air Filters / Front panel


Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.











Step	Procedure		Points
		(R5637)	
6. Re	emove the air supply		 Insert the filters along with the guide for easy
1	Lift the air supply filter		installation.
2	Undo the lower 2 hooks of the air supply filter and open the frame.	(R5639)	 Install the air supply filter correctly so that the "Front" mark comes front. Humidifying operation without installing the air supply filter will form condensation inside the panel and it causes water leakage. There are 4 hooks for the air supply filter.
7. Re	Open the front panel Open the front panel further than the stopping position.	(R5640)	





1.2 Removal of the Upper Panel

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.










1.3 Removal of the Front Grille

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.









1.4 Removal of the Assembly of the Open/Close Mechanism

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.







1.5 Removal of the Assembly of the Reduction Motor

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step		Procedure	Points
	emove the assembly of		Jun us.
	e reduction motor		
1	Disconnect the connector for reduction motor [S51].	[S51]	
		(R5670)	
2	Loosen the 1 screw of the assembly of the reduction motor.	Limit switch	■ The figure above shows the hook on the connector for
			the assembly of reduction motor.
		(R5672)	When touching the electrical parts like the limit switch, be sure to conduct the work after discharging static electricity of the human body. It may cause trouble of the PCB.
2. Re	emove the reduction		
mo	otor		
1	Loosen the 1 screw.	(R5673)	








1.6 Removal of the Electrical Box


Procedure


Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.














1.7 Removal of the PCB


Procedure


Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.















1.8 Removal of the Dehumidifying Solenoid Valve Coil

Procedure


Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.




1.9 Removal of the Connecting Duct

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.







1.10 Removal of the Drain Hose

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.







1.11 Removal of the Swing Motor

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.





1.12 Removal of the Heat Exchanger


Procedure

Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step Procedure **Points** 1. Remove the refrigerant **Preparation** ■ Remove the drain hose piping according to "Removal of Put a wooden block Drain Hose". under the indoor unit and pull out the refrigerant piping, drain hose, connection wirings, and so on. (R5740) 2 Disconnect the flare nut of the connection of Caution gas pipe with 2 In pump-down work, be sure spanners. to stop the compressor before disconnecting the refrigerant pipe. If the refrigerant pipe is disconnected with the compressor running and the stop valve being open, air may be sucked in and cause an over-pressure in (R5741) refrigeration cycle, thus resulting in pipe rupture or accidental injury. 3 Disconnect the flare ■ Be careful that remaining nut of the connection of drain will not wet the floor. liquid pipe with 2 spanners. ■ If the drain hose is embedded in the wall, Caution disconnect the drain hose From the point of beforehand. view of Carry out the removal works environmental protection, be sure to with 2 pair of spanners. use a vacuum pump for air purging. (R5742)


Step Procedure **Points** 2. Remove the indoor unit When the pipes are disconnected, protect the Remove the indoor unit both openings of pipe side from the installation and unit side from entering plate. of moisture. (R5744) 3. Remove the heat Undo the 2 hooks on the exchanger side with a flat screwdriver. Unfasten the hook of the pipe fixing plate at the back of the unit and pull out the pipe. (R5745) 2 Widen the auxiliary pipe by about 10-20 degrees.





1.13 Removal of the Propeller Fan / Fan Motor

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.









1.14 Removal of Horizontal Blades / Vertical Blades

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.








1.15 Removal of the Streamer Unit


Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.










2. Outdoor Unit


2.1 Removal of the Humidify Unit


Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.



Outdoor Unit SiBE04-624






Outdoor Unit SiBE04-624

2.2 Removal of the Heater Assembly / Humidifying Rotor (Moisture Absorption Element) / Humidifying Rotor Motor


Procedure


Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.



Step		Procedure	Points
3	Loosen the 2 screws to	<u> </u>	
	remove the heater assembly.	(R5800)	
4	Undo the 1 hook.		
		Hook (R5801)	
5	Inside of the heater assembly.	Heater Thermal fuse	Heater and thermal fuse should be replaced as the heater assembly.
6	Loosen the 4 screws of the thermal protector.	Thermal protector (R5803)	■ The thermal protector is removable. Remove it before the lead wire.

Outdoor Unit SiBE04-624






Outdoor Unit SiBE04-624

2.3 Removal of the Humidifying Assembly


Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.



Step		Procedure	Points
4	Remove the humidifying assembly.	(R5813)	■ The humidifying assembly should be replaced as an assembly set. (Disassembling of the assembly can cause a noise.)
5	Detach the seal material to release the humidifying thermistor.	(R5814)	■ Inside structure of the upper part of the humidifying assembly.
exl da	emove the air supply and haust changeover mper Loosen the 3 screws of the air supply and exhaust changeover damper.	(R5816)	assembly.


Outdoor Unit SiBE04-624



2.4 Removal of the Moisture Absorption Fan Motor

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.




Outdoor Unit SiBE04-624

2.5 Removal of the Propeller Fan / Fan Motor


Procedure


Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.


Step		Procedure	Points
	move the shelter		Preparation
1	Loosen the 1 screw of the shelter.	Shelter (R5825)	 Remove the humidify unit according to "Removal of Humidify Unit". Be careful not to forget to install, not to lose, and not to break the shelter and electrical box cover.
2	Open the fixing plate		
	and detach the harnesses.	(R5826)	
3	Remove the shelter.		
		Shelter (R5827)	
	move the electrical box over).		
1	Loosen the 1 screw of the electrical box (cover).	(R5828)	
-			



Outdoor Unit SiBE04-624








2.6 Removal of the Duct in Humidifier

Procedure


Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.





2.7 Removal of the Electrical Box


Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.












2.8 Removal of the PCB

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.









2.9 Removal of the Sound Blanket

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.







2.10 Remove the Thermistor Assembly

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.






2.11 Removal of the Reactor / Partition Plate

Procedure


Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.



2.12 Removal of the Four Way Valve

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.



Step


- Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries.
- Before working, make sure that the refrigerant is empty in the circuit.
- Be sure to apply nitrogen replacement when heating up the brazed part.
- 2. Remove the four way valve
 - Heat up the 4 brazed parts of the four way valve. Remove it in the order of (a), (b), (c), (d).
 - 2 Heat up the brazed part and pull out the piping side with pliers.


Warning
Ventilate when
refrigerant leaks
during the work.
(If refrigerant
contacts fire, it will
cause to arise toxic
gas.)


Caution
Be careful not to get
yourself burnt with
the pipes and other
parts that are heated
by the gas welding
rod.

Caution
From the viewpoint of global environment protection, do not discharge the refrigerant gas in the atmosphere. Make sure to recover the refrigerant gas with the recovery system.

Procedure







Points

Cautions for restoration

- Restore the piping by nonoxidation brazing.
 In case of you cannot use the nitrogen gas, restore as quickly as possible.
- It is required to prevent the carbonization of the oil inside the four way valve and the deterioration of the gaskets affected by heat. For the sake of this, wrap the four way valve with wet cloth and provide water so that the cloth will not be dried and avoid excessive heating. (Keep below 120°C)
- Be careful so as not to break the pipes by pressing it excessively by pliers when withdrawing it.

In case of the difficulty with gas brazing machine

- Disconnect the brazed part where is easy to disconnect and restore.
- Cut pipes on the main unit by a miniature copper tube cutter in order to make it easy to disconnect.
- Note: Do not use a metal saw for cutting pipes by all means because the sawdust come into the circuit.

2.13 Removal of the Expansion Valve

Procedure

Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.


Points

Step Procedure 1. Remove the peripheral **Preparation** ■ Remove the sound blanket · Four way valve coil according to "Removal of • Expansion valve coil Sound Blanket". Putty and so on so as not to be ■ When assembling, make sure to catch the hook of the damaged by the brazing expansion valve coil as flame. before. Remove the four any valve coil. Warning Ventilate when refrigerant leaks during the work. (If refrigerant contacts fire, it (R5891) Remove the expansion will cause to arise toxic gas.) valve coil. Caution Be careful not to get yourself burnt with the pipes and other parts that are heated by the gas welding rod. Caution From the viewpoint of global environment protection, do not discharge the refrigerant (R5892) gas in the atmosphere. Make 3 Remove the putty. sure to recover the refrigerant gas with the recovery system. ■ Before working, make sure Be careful so as not to burn that the refrigerant is the heat exchanger fin. empty in the circuit. ■ When assembling, make ■ Be sure to apply nitrogen sure to catch the hook of the replacement when heating expansion valve coil as before. up the brazed part. 2. Remove the expansion Remove the 2 brazed parts in the order of (a), (B5894)

2.14 Removal of the Compressor

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.




Step


- Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries.
- Before working, make sure that the refrigerant is empty in the circuit.
- Be sure to apply nitrogen replacement when heating up the brazed part.
- 2. Remove the compressor
 - Disconnect the brazing part of the compressor on the discharge side.
 - Heat up and disconnect the brazing part on the suction side.

3 Lift up and remove the compressor.

> Caution From the viewpoint of global environment protection, do not discharge the refrigerant gas in the atmosphere. Make sure to recover the refrigerant gas with the recovery system.

Procedure







Points

Warning Ventilate when refrigerant leaks during the work. (If refrigerant contacts fire, it will cause to arise toxic gas.)

∖ Caution Be careful not to get yourself burnt with the pipes and other parts that are heated by the gas welding rod.

Cautions for restoration


- 1. Restore the piping by nonoxidation brazing. In case of you cannot use the nitrogen gas, restore as quickly as possible.
- 2. It is required to prevent the carbonization of the oil inside the four way valve and the deterioration of the gaskets affected by heat. For the sake of this, wrap the four way valve with wet cloth and provide water so that the cloth will not be dried and avoid excessive heating. (Keep below 120°C)
- Be careful so as not to break the pipes by pressing it excessively by pliers when withdrawing it.

In case of the difficulty with gas brazing machine

- 1. Disconnect the brazed part where is easy to disconnect and restore.
- 2. Cut pipes on the main unit by a miniature copper tube cutter in order to make it easy to disconnect.

Note: Do not use a metal saw for cutting pipes by all means because the sawdust come into the circuit.

(R5901)



296

Part 8 Others

1.	Others		
	1.1	Test Run from the Remote Controller	298
	1.2	Field Setting	299

Others SiBE04-624

1. Others

1.1 Test Run from the Remote Controller

For Heat pump

In cooling mode, select the lowest programmable temperature; in heating mode, select the highest programmable temperature.


- Trial operation may be disabled in either mode depending on the room temperature.
- After trial operation is complete, set the temperature to a normal level. (26°C to 28°C in cooling mode, 20°C to 24°C in heating mode)
- For protection, the system disables restart operation for 3 minutes after it is turned off.

Trial Operation and Testing

- 1. Measure the supply voltage and make sure that it falls in the specified range.
- 2. Trial operation should be carried out in either cooling or heating mode.
- 3. To perform a test run for humidifying operation, activate test run mode from the remote controller following the instructions below and press the "HUMIDIFY" button.
- 4. Operate the unit in accordance with the operation manual to check that it operates normally.
- Even when the air conditioner is not operating, it consumes some electric power. If the customer is not going to use the unit soon after it is installed, turn off the breaker to avoid wasting electricity.

Trial operation from Remote Controller

- Hold the "CLOCK" button for 5 seconds.
 (The matrix display will appear on the remote controller.)
- (2) Display " SETTING I on the matrix display of the remote controller and press the "CLOCK" button.
- (3) "7" will be displayed and the unit will enter test run mode.
- (4) Press the button corresponding to the test run mode.
 - Test run mode will stop automatically after around 30 minutes.
 Press the ON/OFF button to force the test-run to stop.



SiBE04-624 Others


1.2 Field Setting

1.2.1 Humidifying Hose Length

Setting the humidifying hose length.

Set the humidifying hose length to ensure humidifying capacity. Use the remote controller
to set the humidifying hose length. When doing this, power on the unit as communication
is established between the unit and the remote controller.

(The humidifying hose length includes the rear of the indoor unit.)



(1) Hold "CLOCK button" for more than 5 seconds.

(To cancel, do not operate the button for 10 seconds. The display will return to normal.)

(2) Press "SELECT ▲ . button".

Select "SETTING2, PIPE"

(3) Press "CLOCK button" to activate the hose length setting mode.

(Be sure to direct the remote controller toward the main unit while operating it.)

The display will show the currently set hose length.

(Default is no setting.)

(4) Press "SELECT ▲ . button" to set the humidifying hose length.

Pressing "SELECT \blacktriangle . button" changes the hose length.

You may set the hose length to 5 levels, ~3M, 3.1~4M, 4.1~6M, 6.1~8M, 8.1~10M.

(5) Press "CLOCK button" after selecting the hose length.

(Direct the remote controller toward the main unit while operating it.)

(6) Hold "CLOCK button" for more than 5 seconds.

The humidifying hose length setting is complete.

If you set the wrong humidifying hose length, cancel the setting displaying

" PIPE SET" with the step 4) operation and reset it.

When the unit cannot be powered on.

When setting the humidifying hose length without powering on the unit, the display shows
 "PIPE LEN" with the step 5) operation shown above but the remote controller UNDEF

remembers the set hose length.


(When the customer uses the unit, the humidifying hose length information is sent to the indoor unit to be set.)

Others SiBE04-624


1.2.2 How to set the different addresses

When 2 indoor units are installed in one room, the 2 wireless remote controllers can be set for different addresses.

- 1) Remove the front grille. (3 screws)
- 2) Cut the address jumper "JA". (See Fig. 1)



 Remove the remote controller lid and cut the address jumper "J4". (See Fig. 2)



(R5989)

1.2.3 Jumper Setting

Jumper (On indoor control PCB)	Function	When connected (factory set)	When cut
JC	Power failure recovery function	Auto-restart	Unit does not resume operation after recovering from a power failure. Timer ON-OFF settings are cleared.
JB	Fan speed setting when compressor is OFF on thermostat. (effective only at cooling operation)	Fan speed setting; Remote controller setting	Fan rpm is set to "0" <fan stop=""></fan>

Part 9 Appendix

1.	Piping Diagrams	302
	1.1 Indoor Units	
	1.2 Outdoor Units	
	Wiring Diagrams	303
	2.1 Indoor Units	
	2.2 Outdoor Units	


Appendix 301

Piping Diagrams SiBE04-624

1. Piping Diagrams

1.1 Indoor Units


FTXR28/42/50EV1B



4D054058

1.2 Outdoor Units

RXR28/42/50EV1B




3D053874

SiBE04-624 Wiring Diagrams

2. Wiring Diagrams

2.1 Indoor Units


FTXR28/42/50EV1B



3D052768

2.2 Outdoor Units

RXR28/42/50EV1B



Wiring Diagrams SiBE04-624



- Daikin Industries, Ltd.'s products are manufactured for export to numerous countries throughout the world. Daikin Industries, Ltd. does not have control over which products are exported to and used in a particular country. Prior to purchase, please therefore confirm with your local authorized importer, distributor and/or retailer whether this product conforms to the applicable standards, and is suitable for use, in the region where the product will be used. This statement does not purport to exclude, restrict or modify the application of any local legislation.
- Ask a qualified installer or contractor to install this product. Do not try to install the product yourself. Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorized parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Read the User's Manual carefully before using this product. The User's Manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any inquiries, please contact your local importer, distributor and/or retailer.

Cautions on product corrosion

- 1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
- 2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided and choose an outdoor unit with anti-corrosion treatment.





JQA-1452

About ISO9001

ISO 9001 is a plant certification system defined by the International Organization for Standardization (ISO) relating to quality assurance. ISO 9001 certification covers quality assurance aspects related to the "design, development, manufacture, installation, and supplementary service" of products manufactured at the plant.



EC99J2044



JQA-E-90108

About ISO 14001

ISO 14001 is the standard defined by the International Organization for Standardization (ISO) relating to environmental management systems. Our group has been acknowledged by an internationally accredited compliance organisation as having an appropriate programme of environmental protection procedures and activities to meet the requirements of ISO 14001.

Dealer

DAIKIN INDUSTRIES, LTD.

Umeda Center Bldg., 2-4-12, Nakazaki-Nishi, Kita-ku, Osaka, 530-8323 Japan

Tokyo Office:

JR Shinagawa East Bldg., 2-18-1, Konan, Minato-ku, Tokyo, 108-0075 Japan http://www.daikin.com/global/

©All rights reserved